

**WiFi Smart Devices Manual**

**Works with Alexa**

Simplified steps to install App on your smart device and pair with Amazon Alexa and Google Assistant using Smart Life App on Apple Store / Google Play Store

Ver: E1707\_alexa

Works with Amazon Alexa. Compatible with any smart phone or tablet including Android devices and Apple.

Download or scan the QR code and install the Smart Life App for either iOS or Android. Once downloaded or scan the QR code, the app will ask you to register your device. Enter your phone number or email which ever one makes you feel comfortable and select the country you live in. If phone number selected you will receive a text with a registration code. If you choose email you will then create a password.

Input the Registration Code you received via text if phone method used or create password if email method chosen.

**Adding a New Device in Quick Connection**

- Make sure the Wi-Fi smart device is standby (the blue light button flash in 2 times per second if the smart device is plug on switch) after plug in the socket. Otherwise, you should press the power button keep to 6 seconds to reset the device (for plug or switch, bulb should be turned on/off the power in 3 times continuously.)
- The smart Wi-Fi devices only supports 2.4GHz Wi-Fi router.
- Open app and click "+" to add device.
- Select Wi-Fi network, input Wi-Fi password, Connect and click.
- Once connected the app will prompt the connection> click OK

**Adding a New Device in AP Mode**

- Make sure the Wi-Fi device is standby (the blue light button of Wi-Fi device flashes in 1 times in 2 seconds) after plug in the socket.
- Press "+" in the main menu of app
- Click "AP Mode" and press Next Step in Add Device
- Select Wi-Fi and input Wi-Fi password, press Next in Set up Wi-Fi for device

Once App is installed on your device and you have added your smart device to your app you will be able to control it.

Next step is to sync with Alexa or echo:

- Go to Home menu on Alexa App
- Select "Skills" in home menu of Amazon Alexa
- Type (Smart Life) on search window and find
- Click on the App (Smart Life) and press Enable to link with echo/Alexa;
- Input the registrated user name and password to log in Smart Life app;

Your Smart life App has been skilled with Alexa, and you now can control any device added to your Smart life App, remember that if you rename the device you added, it must be to a simple name Alexa can recognize Ex: Turn off light.

"Echo turn off living room light" or "Alexa turn off" (What ever you have plugged in smart socket or what ever name you choose for that device plugged or added in your App.)

Using Google Home to control smart devices Link Smart Life account in Home Control

Tap "Home Control" in the hamburger menu on the Google Home app's home page, then tap "+".

Please click the Discover Devices in Smart Home to search the devices what you installed near the Alexa, or talk to Alexa to Discover Devices.

Control your smart devices through Google Home Now you can control your smart devices through Google Home.

**Q & A**

**Why failed to add device?**

- Please check whether device is powered on;
- Whether phone is connected via Wi-Fi;
- Whether device is ready for configuration. To get the device ready before configuration, normally you can manually press on the device to get it ready. Please refer to "Product Instructions" or Device Reset Instruction for details. Notice Each time to add device, reset Wi-Fi to get device ready for configuration and make sure router is working properly.

4. Check routers or related- If router is dual-band router, select 2.4G network and add device. You also need to enable router's broadcasting function. Set up wireless router: Set encryption method as WPA2-PSK and authorization type as AES, or set both as auto. Wireless mode cannot be 11n only. Don't use Chinese to name router Wi-Fi. To stay strong Wi-Fi signal, please keep device and router within certain distance. Whether connected devices have reached the maximum number of router's connections. If so, please try by turning off the Wi-Fi connection of some device. Router's wireless MAC filtering function is enabled. Remove the device from the filter list and make sure that router is not prohibiting device from connection. 5. Make sure the password entered in App is correct when adding new device

**How to reset device?**

- Reset plug, switch, etc. Keep press reset button for 6 seconds until indicator light flashes; or for bulb to turn on/off the power in 3 times continuously, representing successful reset; Indicator light quickly flashes (2 times per second), representing quick connect mode; Indicator light slowly flashes (one time per 3 seconds), representing AP mode;
- Under AP mode, long press reset button for 5 seconds until indicator light slowly flashes, representing switching to AP mode and vice versa.
- Reset smart light> Turn off light first. Switch light with the steps: Switch on-off-on-off-on (time interval cannot exceed 10 seconds), flashing lights represents successful reset; if no light flashes, please repeat the steps above;
- Quick light flashes (4 times per second), represent AP mode; Slow light flashes (2 times per 3 seconds) represent AP mode;

Under AP mode, turn off lights and then switch light with the steps: Switch on-off-on-off-on (time interval cannot exceed 10 seconds). Light begins to slowly flash, representing that it has switched to AP mode and vice versa.

**How to add device under AP mode?**

- Make sure that indicator light or light quickly flash;
- Phone has connected to Wi-Fi router and been able to connect to Internet;
- Tap "Add device" in app and enter correct Wi-Fi password. Touch to search device around;
- In the device list, select and add the device.

**How to add device under AP mode?**

- Make sure that indicator light quickly flashes or light slowly flashes;
- Tap "Add device" in App and then "AP mode" in the top right corner. Connect to device hotspot first and then Wi-Fi;
- Tap "Next" to add device.

**Can I control device with 2G/3G/4G network?**

When adding device for the first time, it requires that device and phone need to be under the same Wi-Fi environment. After successfully adding device, you can remote control device with 2G/3G/4G network

**How can I share my device with family?**

Open App, go to "Profile" > "Device Sharing" > "Shares Sent", tap "Add Sharing", then you can share the device with the added family members.

**How can I manage the devices shared by others?**

Open App, go to "Profile" > "Device Sharing" > "Shares Received", then you can find the devices shared by other users. It also allows to add remarks to users or delete certain shares by long pressing or swiping left.

**Product Data sheet**

Item	property	Parameter	Remark
1	Input voltage	AC120V	
2	Input frequency	50Hz/60Hz	
3	WiFi standard	WiFi 802.11 b/g/n	
4	WiFi frequency	2.4GHz	
5	Receive Sensitivity	-92dBm	
6	PA output	1W 540m	
7	Indicator light	Blue and Red led	

**Notice**

Model: KW-US-101

- Please check if there is damage caused by transportation, if yes, please contact supplier for replacement.
- Please follow the specification instruction and notice to keep products in a good and safe use condition.
- Put the socket in proper condition and out of reach of the children.
- Plug in fully to the socket while using.
- The total power of being electric connected appliances could not be bigger than the maximum power of the socket.
- Do not disassemble or install the socket, otherwise there may cause security risks.

English version:

- Disconnection means: Type 1B
- Pollution degree: 2
- Rated impulse voltage: 1500V
- Automatic action: 6000cycles
- Rating: AC120V 50/60Hz 10A 1200W Resistive
- Caution: Risk of electric shock; Dry location use only. Used indoor only.

**FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF warning for Mobile device:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

1

2

3

4

5

6

7

8

9

10

11

12

13