


HEADPHONES x 2

Blast out tunes.



EAR PADS x 2

Padding for your ears.




STOPPERS x 2

Soften the edges.




2.5MM CURLY CABLE

Connect the headphones.



3.5MM CABLE

Connect other devices.



MICRO USB CABLE

For charging.



HEADBAND

Holds the pieces in place.



HEADPAD

Padding for your head.



REPLACEMENT PARTS?

Visit help.kano.me.



1. CURLY CABLE

Pull the curly cable through the headpad's cable channel.

2. HEADBAND

Snap the headpad onto the metal headband. Make sure it's in the middle!

3. HEADPHONES

Slide the headphones on to the headband. Adjust for the perfect fit.



4. CABLE

Connect the cable to the port of each headphone.

5. EAR PADS

Attach the pads to the headphones.

6. STOPPERS

Add the stoppers to the headband's edges.



POWER

2 second hold: Power on
 3 second hold: Power off
 5 second hold: Pairing mode

Single press: Pause/Play
 Double press: Next song
 Triple press: Previous song

STATUS LED

Flashing blue: Searching for device
 Solid blue: Power on
 Flashing red: Low battery



VOLUME

Use Volume + and Volume - to adjust the volume.

VOLUME LIMITER

Press Volume + and - to deactivate volume limiter. Press again to activate.

CHARGE

Connect the small end of the cable to your headphones and the bigger end to a power plug.

WIRELESS HEADPHONES

BY KANO COMPUTING



FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC ID: 2ATYD-1014

IC Caution:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference,
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This Class [B] digital apparatus complies with Canadian ICE-003.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Cet appareil numérique de la classe [B] est conforme à la norme NMB-003 du Canada.

L'appareil a été évalué pour répondre aux exigences générales d'exposition RF.