

User manual







Intended Use

Product to be used as a lamp.

Read and understand the operating manual. Strictly follow the instructions.

(refer to www.ledlenser.com).

About the Product

Do not swallow small parts. Keep small parts out of reach of children. The product is not suitable for children.

The product should only be used as intended. Strictly follow the instructions.

Strictly follow the instructions in the enclosed Quick Start Guide regarding the specifications of permitted batteries.

Notes on Ambient Conditions

Only use the product in a temperature range between -20 and 40 $^{\circ}\text{C}.$

Avoid direct and durable sunlight. Avoid high humidity and/or moisture.

Do not expose the product to solvents and/or vanors

Do not use the product in an explosive atmosphere. Do not expose the product to strong vibrations

Notes on Handling of Product

Do not wear products with headband around your neck. Do not use the product as a tool.

Risk of heat build-up e.g. if the product is covered during operation.

The LEDs of the product correspond to the risk group 2 according to DIN EN 62471-1.

Risk of blinding! Do not look directly into the beam of light. The light beam should not be directed into the eye. Do not use the product for eye examinations (eye pupil examinations). Increased risk of blinding. The eye's ability to respond decreases under the influence of drugs, medicines, alcohol.

Risk of retinal lesions. The product emits blue light (400- 780 nm). Do not look directly into the beam of light.

Do not use any light-bundling instruments together with the product.

Do not short-circuit the contacts of the product

Products with permanent magnets are a danger for persons with heart pacemakers. They should always keep a safety distance to the components with permanent magnet.

If you do not use the product for a longer period of time, remove the batteries from the product.

Notes on Maintenance/Repair

Do not modify or adapt the product.

Repairs and maintenance must only be carried out by authorized personnel. For customer service, refer to www.ledlenser.com

Notes on Batteries

Never use batteries and rechargeable batteries together. Consult the enclosed Quick Start Guide to know whether batteries and/or rechargeable batteries may be used for this product.

Store batteries/rechargeable batteries out of reach of children. Never expose batteries/rechargeable batteries to temperatures over 60°C (e.g. direct sunlight) or to open fire.

Do not expose batteries/rechargeable batteries to moisture. Do not short-circuit batteries/rechargeable batteries.

Observe the polarity.

Do not recharge batteries. Do not damage or open batteries/rechargeable batteries. Do not use rechargeable batteries or batteries capable of high current for battery-operated products.

Do not use full and empty batteries or old and new batteries together. Always replace the complete set of batteries/rechargeable batteries.

Only recharge batteries with a suitable charger.

Regularly recharge batteries (approx. every 3 months) if they are not used for a longer period of time.

Dispose of the batteries according to the national guidelines.



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.