


# REMOTE CONTROL TRUCK


## PRODUCT DETAILS




### RC Car Battery Installation Steps



1. Open the battery compartment




2. Install the battery




3. Lock the battery compartment

### Remote control battery Installation Steps



1. Open the battery compartment



2. Install the battery  
3. Lock the battery compartment

## PAIR THE RC CAR AND REMOTE CONTROL




Push the up and down buttons to move the car forward and backward.


Press the left and right button to make the car turn left and right.

Remote control distance: Approximately 40-50 meters  
Usage time: Around 25-30 minutes when fully charged  
Charging time: Approximately 3 hours


## LITHIUM BATTERY CHARGING METHOD



The red light is on when the battery is charged, and off when fully charged.



Can be charged using the computer USB charging port.



Connect as shown in the figure.

### FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

## WARNING

When the remote control can not work, turn off the RC car and controller. Then restart both the car and the remote control. Remember to match frequency before you play.

### BATTERY INSTRUCTIONS

1. Rechargeable batteries should be removed from toys before charging.
2. Do not mix old and new batteries.
3. Keep batteries away from kids under 3.
4. The light will flash on and off when battery is low.