

4"

6"

8"

对折线

(TOLL-FREE CUSTOMER SUPPORT (877) 269-8490)

FCC NOTE
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Shielded interference cable must be used with the equipment in order to comply with the limits for a digital device pursuant to Subpart B of Part 15 of FCC Rules. Specifications and designs are subject to change without any notice or obligation on the part of the manufacturer.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device*

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

LIMITED WARRANTY

Walker's warranties this product to the original purchaser to be free from defects in materials and workmanship, under normal use and conditions for a period of one year parts from the date of purchase.

Under this warranty, this unit will be replaced or repaired at our option. Copy of the original receipt or gift receipt, is required for any warranty service. To enact the warranty, the customer is required to contact our Customer Service Group at 877-268-8490 to receive an Return Authorization (RA) number **PRIOR** to sending the product back.

This warranty is void if any of the following occur:

1. The unit is not accompanied by a copy of the receipt or gift receipt from the original purchaser.
2. The unit has been tampered with, opened or punctured.
3. The unit has been immersed in water or other liquids, allowed to be filled with dirt or dust, or otherwise physically abused.
4. The one year limited warranty has expired. Please inquire about other options from your Customer Service Representative.

This shall be the exclusive written warranty of the original purchaser and neither this warranty nor any other warranty, expressed or implied, shall extend beyond the 12-month period listed above. In no event shall Walker's, Inc. be liable for consequential property damage, or consequential personal injury. (Some states do not allow limitations on implied warranties or exclusions of consequential damages, so that these restrictions may not apply to you). This warranty gives you specific legal rights, and you may have other rights, which vary from state to state.

Record Serial # for future reference: Serial # _____

Return bottom portion to Walker's, Inc. – PO Box 535189 – Grand Prairie, TX 75053-5189

Warranty Registration

Model: _____ Date of Purchase: _____

Purchased From _____

City: _____ State: _____ Zip: _____


Primary Use: _____

Your Name: _____

Address: _____


City: _____ State: _____ Zip: _____

Email Address: _____ Serial #: _____



Getting Started

1. Before attaching the Walkie Talkie, rotate the position of the rubber USB-C cover. Pull the rubber audio jack cover and fold away from the housing.
2. Attach the walkie talkie to your FireMax by lining up the audio jack with the audio jack port, then lining up the USB-C connector. Slide Walkie Talkie in then press towards muff cup to snap into place.
3. Rotate antenna out for best reception.
4. Press and hold the power button for two seconds to turn on the headset and walkie talkie.



Walkie-Talkie Overview

Labels: USB-C, 3.5mm Audio Jack, Antenna, LCD Screen, Walkie Talkie Volume/Menu Navigation Buttons, FireMax Ambient Volume Buttons, FireMax Frequency Mode Button, Power/Select Button, Push-to-talk Button.

FRONT

Functions

Power On/ Off:
Press and hold the power button for 2 seconds to turn the head set and walkie talkie on or off.

Ambient Volume Adjust:
Press the volume up or down buttons to the right of the LCD screen to change the volume of the ambient pass-through.

NOTE:
When Ambient volume reaches minimum there will be a double beep.
When Ambient volume reaches maximum there will be a double beep.

Walkie Talkie Volume Adjust:
Press the volume up or down buttons to the left of the LCD screen to change the walkie talkie speaker volume.

NOTE:
When walkie talkie speaker volume reaches minimum there will be a double beep.
When walkie talkie speaker volume reaches maximum there will be a double beep.

Frequency Modes:
Press the Mode button to cycle through the following frequency modes:

- **Universal:** General use with no filter applied
- **Clear Voice:** Emphasizes human vocal frequencies
- **High Frequency:** Low frequencies reduced and high frequencies are boosted, amplifying noises such as bushes rustling or branches cracking.
- **Power Boost:** Amplified version of Universal

Radio Operation

Channel Selection:
Press the Power/Menu button one time to enter the menu. "CH" will display. Press the up or down buttons until the desired channel appears on the screen. The Firemax Walkie Talkie supports standard GMRS/FRS channels 1 through 22. Press the Power/Menu button four more times to exit the menu.
Alternatively, the menu will exit after a few seconds of inactivity.

Communication:
All radios in your group must be set to the same channel. Position the microphone about 1 inch away from your mouth. To talk, press and hold the Push-to-Talk (PTT) button and speak. The PTT icon will flash on the screen while transmitting. Release PTT button when finished.

Using Sub-Channels:
Selecting a sub-channel will cause you Razor Walkie Talkie to only receive transmission from other radios set to the same channel and sub-channel. This allows multiple groups to communicate on the same channel independently. Note that other radios will receive transmissions from your channel regardless of sub-channel.

1. Press the Power/Menu button two times to enter the sub-channel menu. "SUB" will be displayed.
2. Press the up or down buttons to scroll through and select any of 99 subchannels. Press the Power/Menu button three more times to exit the menu. Alternatively, the menu will exit after a few seconds of inactivity.

Voice Activated Transmit (VOX):
Voice Activated Transmit (VOX) can be enabled for hands-free operation. When activated, the unit will automatically transmit when the wearer is speaking. PTT is still available while VOX is enabled.

1. Press the Power/Menu button three times to enter the VOX menu. "VOX" will be displayed.
2. Press the up or down volume buttons to scroll through the available options. **OF** disables VOX and is the default setting. **LO** is for low sensitivity and is meant for environments with external noise such as wind. **HI** is for high sensitivity ideal for low wind areas or indoors.
3. Press the Power/Menu button two more times to exit the menu. Alternatively, the menu will exit after a few seconds of inactivity.

FCC & IC Warning

CAUTION

To ensure that your exposure to RF electromagnetic energy is within the FCC/IC allowable limits for occupational use, always Adhere to the following guidelines:

- DO NOT operate the radio without a proper antenna attached, as this may damage the radio and may also cause you to exceed FCC/IC RF exposure limits, a proper antenna is the antenna supplied with this radio by the manufacturer or antenna specifically authorized by the manufacturer for use with this radio.
- DO NOT transmit for more than 75% of total radio use time ("75% duty cycle"). Transmitting more than 75% of the time can cause FCC/IC RF exposure compliance requirements to be exceeded. The radio is transmitting when the "TX indicator" lights red. You can cause the radio to transmit by pressing the "PTT" switch.
- Only and must attach Good Sportsman's headphone (FireMax Walkie Talkie) to install.
- This device was tested simulation typical 0mm to head.
- To avoid electromagnetic interference and/or compatibility conflicts, turn off your radio in any facility where posted notices instruct you to do so. Hospitals or health care facilities may be using equipment that is sensitive to external RF energy

The information listed above provides the user with the information needed to make him or her aware of RF exposure, and what to do to assure that this radio operates within the FCC/IC RF exposure limits of this radio. This equipment must be installed and operated in accordance with provided instructions and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance. The SAR limit adopted by US/Canada is 1.6 W/kg averaged over 1 grams of tissue. The highest SAR value for this device type when properly worn on the body is 0.142 W/kg.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The information listed above provides the user with the information needed to make him or her aware of RF exposure, and what to do to assure that this radio operates within the FCC RF exposure limits of this radio.

This device contains licence-exempt transmitter(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of an integral Antenna and maximum -3.5dBi gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

BACK