

Main Module


Information

A wireless device that connects a car key and a mobile phone using BT.


Basic description

1. Install an App on your mobile device.
2. The user assembles ketFob into the product.
3. Press the register button and do Bluetooth pairing with mobile devices.
4. Register your vehicle information in the app.


keto User Guide - Hardware Information



Main Module



USB Type A Cable



Sub Module

Specification

Bluetooth : 2.402GHz ~ 2.480GHz

Power : DC 5V

Battery : Li-Pol (3.7V, 850mA), IDLE 30days

Operating Temperature : -20° C to 50° C

Functional Description



compatible with
keyfob's features



Key sharing




Android, iOS
Supported



Enhanced
Security


keto User Guide - Setup

Step 1 Assembling SUB MODULE



Insert the **Key Module** into the KETO **Sub Module**.

Step 2 Assembling KETO



Attach the **Sub Module** to the **Main Module** and tighten.

Step 3 Power In



Connect the **power cable** to the KETO.

Step 4 Bluetooth Connection

Bluetooth connection button



Press **Button** to connect the **Mobile Phone**.

- Only use the appropriate submodules for your car.
- When assembling the Sub Module, push it to the end and assemble it.
- Only use the screws that are included in the package when tightening.
- Use only the power cable included in the package or the 5 volt power line that meets the specification.

ONE  KEY

Homepage : www.onekey.kr

E-mail : contact@onekey.kr

FCC Compliance Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Industry Canada Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. Son fonctionnement est sujet aux deux conditions suivantes: (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

Industry Canada Radiation Exposure Statement

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

Déclaration d'exposition aux radiations

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.