



FS884W(w2-S5202DM)

FCC ID : 2AUG8-884W

Getting Started

80mm

Meet the FastSensor FS844W, a simple yet powerful wearable, designed to provide real-time, haptic proximity alerts when within 6 feet of another device, and additional capabilities when coupled with FastSensor's one-of-a-kind, positioning and behavior analytics platform.



Technical Specifications

Physical:

- Finishing: black with silver trim
- Dimensions: 4.9 x 20.2 x 12 mm
- Operating temperature: 0 125 o F
- Waterproof: IP67

Battery:

- Lithium polymer 80mAH
- . Up to 27 hours with one full charge
- Rechargeable USB-A connector

Radio frequencies:

• 2402 - 2480MHz

Physical Specifications (details)





Charging Directions

Firmly pull the strap closest to the white ellipses to expose the USB connector. Plug the USB connector into the provided USB cable, and the cable into the charger (not included). The LED indicator remains on during charging, and will turn off once fully charged.



FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference.

(2)This device must accept any interference received, including interference that may cause undesired operation.

2.any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.