


6. EQUIPMENT UPGRADES

For your better experience, we will continue to upgrade the sensor, please keep the phone or iPad connected to the device properly, and ensure the power is not less than 50%.



7. STATUS INDICATION

The sensor has an indicator light, it is used to indicate different states.

STATES	COMMENT
Continuous flash three times	ON State (not connected)
Flicker(15 seconds apart)	Waiting for the connection
Flicker(5 seconds apart)	Connection
Normally on	Upgrading
Light out	OFF
Continuous Flashing	Malfunction

8. FCC WARNING

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

MODIFICATION: Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the device.

9. STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

TRAMPOLINEPRO

SOMATOSENORY GAME INSTRUCTIONS



Tech+Sports
(ios&Android)




Tech+Game
(ios&Android)

(320 mm)


1. BUTTON BATTERY INSTALLATION

Please put the sensor back up, using the screwdriver to open its back cover, put the button battery into and "+" face up, ensure that the sensor is installed in the battery tank, and then close the back cover.




2. INSTALLATION METHOD

Fixed on the waist of the human body.




3. ON/OFF

ON: Shaking the sensor can be turned on normally after three times.
OFF: Stating for three minutes without using the device, it will automatically shut down.



4. CONNECTION

DOWNLOAD: Scan the dimensional code, then download and install APP.
Connection: Make sure that the bluetooth of the phone or ipad is on normally, put the sensor close to them, log in to the APP search device and select the connection.
Synchronization: Open APP after each exercise to ensure that the device normally connects to the APP. The APP will automatically synchronize the exercise data and upload it to the cloud.



5. WARRANTY CARD

Customer Information

First Name Last Name

Address

City State Zip

Phone Number - -

E-mail

Product Information

Model # Serial #

Purchase Date / / Where you purchased

(52 mm)