BEACON

A Bluetooth beacon is a small wireless device that works based on Bluetooth Low Energy. It repeatedly and securely sends out message at regular interval that other devices can see.

When the device enters its range, the location will be uploaded to be Beacon location.

Getting to know your device

• Front



Scan QR code for BLE MAC address

Back



Area to stick double sided tape

• Side



Accessories



Double Sided Tape

Getting to know your device

Power ON

Long press the button for 3s, after the successful Power ON the LED will glow.



Status check

Short press the button (less than 1S), the LED will glow while the button is pressed, indicating that the device is working properly;

After the status check is completed, if the LED flashes twice, the battery power is less than 10%.



Power Off

To turn the beacon off, press and hold the button for 3 seconds.




Getting to know your device





The beacons provide indoor locations information for room-by-room statistics.





Features

- 1 Small and light weight, easy to install.
- 2 It designed to use with Eview Personal mobile alarms and Pet trackers.
- 3 It include button battery C2477, the battery can last around 2 years.
- The beacons provide at home / out of home information in addition to optimizing mobile alarm and pet tracker's battery life.
- Built-in temperature sensor, it measures the temperature of its environment and sends data to monitor center or your mobile phone.

Hardware specifications

- 1 BLE: BLE 5.0
- Waterproof: IPX8
- 3 Button battery: C2477, the battery can last around 2 years
- 4 CPU/MCU: NRF52810

Quick Start Guide







FCC Warning

15.19 Labeling requirements.

This device compiles with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class digital device, pursuant to part 15 of the TCC fulsor. Here limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio requency energy and, fin not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, here is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measure.

Regrient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC RF Radiation Exposure Statement:

 Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

2. This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 5mm between the radiator and your body.