


# Ebo Catpal

Designed by Enabot




## Meet Ebo Catpal

- ① Interchangeable Hat
- ② Feather/Accessory Insertion Socket
- ③ Laser Pointer
- ④ Camera
- ⑤ Charging Stand
- ⑥ Smart Collar (Sold Separately)



- 1 Ebo Catpal requires the Ebo App in order to be used.



- 1 Please try to keep the charging stand 1.2m away from obstacles.

1


## Download the Ebo App

Scan the QR code, download the Ebo App and complete registration.

2

## Place the charging stand


Place the charging stand in an open space and plug it into a power source.



3

### Initialize Ebo Catpal

Place Ebo Catpal on the charging stand for initialization.



4

### Network Configuration

Follow the instructions on the Ebo App and generate your own QR code. Scan the QR code with Ebo Catpal's camera.


1 Ebo Catpal uses 2.4G WIFI. If your home WIFI setup is 5G only, please adjust router settings



5

## Network Connected


Congratulations! Your Ebo Catpal is connected to the Internet when "✓" is displayed in Ebo Catpal's eyes.




6

## Enjoy your Ebo Catpal!


Control Ebo Catpal with your smartphone.





## The Ebo App

- ① About
- ② Ebo Cards / Pet Cards
- ③ Click to Connect to Ebo Catpal
- ④ Ebo News
- ⑤ Add Your Ebo Cards / Pet Cards
- ⑥ Settings (Modify WIFI / About ebo)
- ⑦ Smart Video Editor




## The User Interface

- ① Steering Wheel
- ② Move forward
- ③ Move backward
- ④ Laser On/Off
- ⑤ Circle
- ⑥ Battery
- ⑦ Settings
- ⑧ Photo
- ⑨ Video
- ⑩ Mic On/Off
- ⑪ Speaker on/off


## Charge

Place Ebo Catpal in the positions shown in the diagram. Make sure the connector pins on the bottom of your Ebo Catpal are in contact with the connector pins on the base of the charging stand.



## Check Charge Status


The light indicator is red while charging. The light indicator is green when your Ebo Catpal and Smart Collar are fully charged.



Not Fully Charged



Fully Charged



## Restart/Turn Off/Factory Reset

Restart: Press the Reset button.


Turn Off: Press the Reset button twice.

Factory Reset: press and hold the Reset button for 5 seconds.



## Change "Hat"

Take off the hat by gently pressing down on the hat and turning it counter-clockwise. Put on the hat by gently pressing the hat on Ebo Catpal's head and turning it clockwise.



## Hat

Soldier hat and onion hat are integrated with laser pointers. Soldier hat, onion hat, and bamboo hat have sockets for feathers or accessories (silicon feathers are included in the pack).





Feather



ebo



Q&A

For more information, please visit our YouTube channel and official website.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC Regulatory Compliance statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

#### Supplier's Declaration of Conformity

47 CFR § 2.1077 Compliance Information

Unique Identifier Trade Name: 2AUR8, Model No.: CATPAL

Responsible Party – U.S. Contact Information

Sclera Digital, Inc.

11815 Laurelwood Dr. Unit 1, Studio City, CA 91604

(818)826-3128

## Enabot

E-Hub, Qianhai, Shenzhen, Guangdong, P.R.C.

Designed by Enabot, Made in China.

TM and © 2019 Enabot.

All rights reserved.

[www.enabot.com](http://www.enabot.com)