

90.00 mm

130.00 mm

Portable SPEAKER WITH BLUETOOTH VAS-3003-BK

USER MANUAL

Please read carefully before use and keep for future reference.

Warning

1. Do not drop speakers to avoid damaging internal structure.
2. Do not use this product in wet environment to avoid water droplets into the speaker.
3. Do not use any chemical solvent to wipe the surface of machine.
4. This speaker is high sealing design. Do not attempt to disassemble this speaker.


FEATURE

Bluetooth 5.0
TF Card
FM Radio
USB For Music Playback
3.5 mm AUX IN
MIC IN
Built-in Rechargeable Battery

SPECIFICATION

Product Name : Portable Speaker With Bluetooth
Bluetooth Version: Bluetooth V5.0
Bluetooth Frequency: 2.40 Ghz
FM Frequency: 87.5-108MHz
Bluetooth Operating Distance: Up to 33 Feet(10 Meters)
Function:Bluetooth, USB, TF, FM, AUX IN, MIC IN
Power Supply: DC 5V
Accessories Included: User Manual, Charging Cable, AUX IN Cable

PRODUCT OVERVIEW



1. **Mode Button, Previous&Next Track:**
Press to change mode. Rotate the knob to previous track and next track
2. **Power/Play/Pause Button, Volume Knob:**
Hold and press to power ON/OFF. Press to play or pause(Bluetooth/USB/TF).
3. **Microphone Port**
4. **USB Port(For Music Playback Only)**
5. **TF Card Port**
6. **AUX IN Port**
7. **Charging Port-DC 5V**

SET UP & BASIC OPERATION

Bluetooth Mode

1. Press the Bluetooth mode. The Bluetooth indicator will begin to flash to indicate the speaker is in pairing mode.
2. Search for the speaker in the list of Bluetooth devices named "VICTOR VAS-3003" and connect.
3. The Bluetooth indicator will be solid if pairing successfully.

AUX IN Mode

Connect one end of a 3.5 mm audio cable (not provided) to speaker's AUX INPUT jack, then connect the other end to the output jack of your audio device.

TF Mode

This speaker can play audio files such as MP3 that are stored on a TF card. Insert your TF Card (not included) into the TF Card port for playback.

USB Mode

This speaker can play audio files such as MP3 that are stored on a USB drive. Insert your USB drive (not included) into the USB port for playback.

FM Mode

Press to FM mode. Press the power/play/pause button to automatically search for stations. It will save the station once searching completed. Rotate the RREV / NEXT Knob on the unit to select station. An FM receiver is built into the speaker. Adjust the position of the speaker to improve FM radio reception.

MIC IN Mode

Inserting the microphone (not included) to mic in jack. This will activate Microphone mode.

Charging the device

The speaker has a built-in, rechargeable lithium ion battery. To avoid damage, do not attempt to remove the battery. Before first use, fully charge the device using the supplied charging cable. Charging indicator will be on when charging, and off after fully charged.

(Important 1: To avoid a complete discharge of battery, charge the speaker at least once every month.)

(Important 2: Do not play music while charging the device.)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.