

Door Magnetic Sensor

Specification

Door Magnetic Sensor

Download Spec

Last update: December 23th, 2023.

The surface-mounted door magnetic sensor always monitor the opening and closing status of doors, and signals the Smart Hub.



1. Detection Performance

Detection method

• Reed switch

Detection Gap

• > 17 mm



Door Status detection

Door Open

Alarm will be triggered when system is armed.

• Door Closed

Tamper Protection

• Rear

Remote setting and testing

• Setting and testing from RB Link App

Advanced features

• Power up enrolling

When sensor is powered up, it will automatically start paring to the hub nearby

• Find me

When enabled, the sensor starts flashing green, which can help identify the sensor from numerous door magnetic sensors.

• Signal strength detection

When enabled, senor starts flashing green/orange/red showing the wireless signal strength between the hub at current installation site.

• Low battery notification

Indicators

- Alarm: Flashing Red
- Find me: Flashing Green
- Signal strength:
 - Flashing Green: signal strength is strong, and is recommended to install device here

- Flashing Orange: signal strength is medium and device can be installed here
- Flashing Red: signal strength is bad or no signal, and device can not be installed here

3. RBF wireless technology

Wireless signal range

- Up to 1,900 m in an open space with hub
- Two-way communication with hub

Frequency bands

- 868MHz version: 863 ~ 870 MHz
- 915MHz version: 902 ~ 928 MHz

Depends on sales region.

Wireless signal modulation

• FSK / DSSS

Encrypted communication

• All the data transmitted are protected by AES-CCM encryption with a random key.

Frequency hopping (FHSS)

• To prevent radio interference and radio signal interception.

Time division multiple access (TDMA)

• With the help of clock synchronization technology, hub will slice time into different division for different RBF wireless devices. In this way, all devices will communicate with hub in a sequence.

4. Electrical Characteristic

Power Supply

- AA Battery × 1
- Up to 5.5 years (standby mode)

5. General

Operation Temperature

• From -10°C to +55°C (14°F to 131°F)

Operation Humidity

• From 10% to 90%

Storage Temperature

• From -20°C to 60°C (-4°F to 140°F)

Dimension(WxHxD)

- Body: 82mm x 42mm x 16mm
- Magnet: 82mm x 11mm x 18mm

Weight

• 55.6g

6. Compatibility

• Operates with all Roombanker Home Security Hubs, RBF repeaters.

7. Complete set

Product	Quantity
Door Magnetic Sensor (Body & Magnet)	× 1
Quick Start Guide	× 1

8. Additional information

Available models

- RBSS-MC1-868
- RBSS-MC1-915

Certifications

- CE, CB
- FCC
- ICASA
- LOA
- RCM
- NOM
- Anatel

Warranty

• Replacement and repair within 24 months of the date of sale. Batteries are not covered under warranty.

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.