


## Greetings from realme mobile

This guide briefly show you how to use the phone and its important functions. For more and detailed information of the phone and user guidance, please visit: [www.realme.com/eu/support](http://www.realme.com/eu/support).



### Warning

- ▶ Do not place the phone or battery near or inside heating equipment, cooking equipments, high pressure vessels (such as microwave ovens, induction cooker, electric oven, heater, pressure cooker, water heater, gas stove, etc.) to prevent the battery overheating which may lead to an explosion.
- ▶ The original charger, data cable and battery shall be used. Unapproved chargers, data cables, or batteries that are not certified by the manufacturer may result in electric shock, fire, explosion, or other hazards.
- ▶ Back cover can't be removed.

- ▶ When charging, please place the device in an environment that has a normal room temperature and good ventilation. It is recommended to charge the device in an environment with temperature ranging from 5°C~35°C.

### How to reboot the phone

Press and hold the Power Button and Volume Up Button at the same time until the realme boot animation is displayed to reboot the phone.

### How to Transfer Old Mobile Content to a New Mobile

You can use realme Clone Phone to easily transfer photos, videos, music, contacts, messages, apps, etc from your old phone to the new one.

1. If you have an old Android phone, first scan the QR code below, then download and install Clone Phone, next open Clone Phone on both the new and old phones, and follow the on-screen instructions to complete the operation.



<https://i.clonephone.coloros.com/download>

2. If you have an old iPhone, open Clone Phone on the new phone directly, and follow on-screen instructions to sign in to iCloud account and sync the files.

### Standard accessories

1 Phone, 1 Charger, 1 USB data cable, 1 Safety Guide, 1 Quick Guide, 1 SIM Ejector Tool, 1 Protective Case.

## Specification

Product	RMX3370	
Main screen parameter	16.8cm(6.62")	
Dimension	162.9×75.8×8.6(mm)	
Battery	2440mAh×2(cell)/18.88Wh(Min) 2500mAh×2(cell)/19.35Wh(Typ)	
Camera	64Megapixels +8Megapixels +2Megapixels Rear 16Megapixels Front	
Operating temperature	0°C-35°C	
SAR Values	FCC SAR	0.938W/kg(Head)
		0.892W/kg(Body)

Radio Waves Specifications		
Radio	Frequency	Max. Output Power
GSM	850MHz/900MHz	32.5±1dBm
	1800MHz/1900MHz	29.5±1dBm
WCDMA	Bands 1/2/4/5/6/8/19	23.5±1dBm
LTE FDD	Bands 1/3/4/66	23±1dBm
	Bands 5/8/12/13/17/18/19/20/26/28	23.5±1dBm
	Band 7	22.7±1dBm
	Band 2	22.5±1dBm
LTE TDD	Band 39	22.8±1dBm
	Bands 38/40/41	23±1dBm
5G NR	n1/n3/n38/n41/n66	23±1.2dBm
	n5/n8	23.7±1.2dBm
	n20/n28	23.5±1.2dBm
	n7	22.7±1.2dBm
Bluetooth	2.4-2.4835GHz	10±3dBm(EIRP)
2.4G Wi-Fi	2.4-2.4835GHz	15.9±2.5dBm(EIRP)
5G Wi-Fi	5.15-5.35GHz; 5.47-5.725GHz	15.7±2.5dBm(EIRP)
	5.725-5.85GHz	11±2.5dBm(EIRP)
NFC	13.56MHz	≤ 42dBuA/m @10m

## FCC Regulatory Conformance

### FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference; and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## RF Exposure Information (SAR)

This device complies with RF specifications when used near your ear or at a distance of 1.5cm from your body. Ensure that the use of belt clips, holsters and similar accessories should not contain metallic components. Keep the device away from your body to meet the distance requirement.

This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. The antenna(s) used for this transmitter must not be collocated or operate in conjunction with any other antenna or transmitter. The SAR limit set by the FCC is 1.6W/kg. The highest SAR value of this device type complies with this limit. And please see the "Quick Guide" to find the highest SAR value reported to FCC.

### Regulatory

Steps to search E-label: Go to Settings—About Phone—Certificate information(FCC E-label)

realme

Quick Guide

RMX3370

realme

