



### 802.11n-20 MHz CHANNEL 10 CARRIER LEVEL



### 802.11n-20 MHz CHANNEL 10, SPURIOUS 30 MHz ~ 3 GHz




### 802.11n-20 MHz CHANNEL 10, SPURIOUS 2 GHz ~ 25 GHz




### 802.11n-20 MHz CHANNEL 11 CARRIER LEVEL




802.11n-20 MHz CHANNEL 11, SPURIOUS  
30 MHz ~ 3 GHz




802.11n-20 MHz CHANNEL 11, SPURIOUS  
2 GHz ~ 25 GHz




802.11n-40 MHz CHANNEL 3 CARRIER LEVEL




802.11n-40 MHz CHANNEL 3, SPURIOUS  
30 MHz ~ 3 GHz




802.11n-40 MHz CHANNEL 3, SPURIOUS  
2 GHz ~ 25 GHz




### 802.11n-40 MHz CHANNEL 4 CARRIER LEVEL




### 802.11n-40 MHz CHANNEL 4, SPURIOUS 30 MHz ~ 3 GHz




### 802.11n-40 MHz CHANNEL 4, SPURIOUS 2 GHz ~ 25 GHz




### 802.11n-40 MHz CHANNEL 5 CARRIER LEVEL




802.11n-40 MHz CHANNEL 5, SPURIOUS  
30 MHz ~ 3 GHz




802.11n-40 MHz CHANNEL 5, SPURIOUS  
2 GHz ~ 25 GHz




802.11n-40 MHz CHANNEL 6 CARRIER LEVEL




802.11n-40 MHz CHANNEL 6, SPURIOUS  
30 MHz ~ 3 GHz




802.11n-40 MHz CHANNEL 6, SPURIOUS  
2 GHz ~ 25 GHz




### 802.11n-40 MHz CHANNEL 7 CARRIER LEVEL




### 802.11n-40 MHz CHANNEL 7, SPURIOUS 30 MHz ~ 3 GHz




### 802.11n-40 MHz CHANNEL 7, SPURIOUS 2 GHz ~ 25 GHz




### 802.11n-40 MHz CHANNEL 8 CARRIER LEVEL




802.11n-40 MHz CHANNEL 8, SPURIOUS  
30 MHz ~ 3 GHz




802.11n-40 MHz CHANNEL 8, SPURIOUS  
2 GHz ~ 25 GHz




802.11n-40 MHz CHANNEL 9 CARRIER LEVEL



802.11n-40 MHz CHANNEL 9, SPURIOUS  
30 MHz ~ 3 GHz




802.11n-40 MHz CHANNEL 9, SPURIOUS  
2 GHz ~ 25 GHz




### VHT-20 MHz CHANNEL 1 CARRIER LEVEL




### VHT-20 MHz CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz




### VHT-20 MHz CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz




### VHT-20 MHz CHANNEL 2 CARRIER LEVEL




VHT-20 MHz CHANNEL 2, SPURIOUS  
30 MHz ~ 3 GHz




VHT-20 MHz CHANNEL 2, SPURIOUS  
2 GHz ~ 25 GHz




VHT-20 MHz CHANNEL 6 CARRIER LEVEL



VHT-20 MHz CHANNEL 6, SPURIOUS  
30 MHz ~ 3 GHz



VHT-20 MHz CHANNEL 6, SPURIOUS  
2 GHz ~ 25 GHz







### VHT-20 MHz CHANNEL 8 CARRIER LEVEL



### VHT-20 MHz CHANNEL 8, SPURIOUS 30 MHz ~ 3 GHz




### VHT-20 MHz CHANNEL 8, SPURIOUS 2 GHz ~ 25 GHz




### VHT-20 MHz CHANNEL 9 CARRIER LEVEL




VHT-20 MHz CHANNEL 9, SPURIOUS  
30 MHz ~ 3 GHz




VHT-20 MHz CHANNEL 9, SPURIOUS  
2 GHz ~ 25 GHz




VHT-20 MHz CHANNEL 10 CARRIER LEVEL



VHT-20 MHz CHANNEL 10, SPURIOUS  
30 MHz ~ 3 GHz




VHT-20 MHz CHANNEL 10, SPURIOUS  
2 GHz ~ 25 GHz




### VHT-20 MHz CHANNEL 11 CARRIER LEVEL




### VHT-20 MHz CHANNEL 11, SPURIOUS 30 MHz ~ 3 GHz




### VHT-20 MHz CHANNEL 11, SPURIOUS 2 GHz ~ 25 GHz




### VHT-40 MHz CHANNEL 3 CARRIER LEVEL




VHT-40 MHz CHANNEL 3, SPURIOUS  
30 MHz ~ 3 GHz




VHT-40 MHz CHANNEL 3, SPURIOUS  
2 GHz ~ 25 GHz




VHT-40 MHz CHANNEL 4 CARRIER LEVEL




VHT-40 MHz CHANNEL 4, SPURIOUS  
30 MHz ~ 3 GHz




VHT-40 MHz CHANNEL 4, SPURIOUS  
2 GHz ~ 25 GHz




### VHT-40 MHz CHANNEL 5 CARRIER LEVEL




### VHT-40 MHz CHANNEL 5, SPURIOUS 30 MHz ~ 3 GHz




### VHT-40 MHz CHANNEL 5, SPURIOUS 2 GHz ~ 25 GHz




### VHT-40 MHz CHANNEL 6 CARRIER LEVEL




VHT-40 MHz CHANNEL 6, SPURIOUS  
30 MHz ~ 3 GHz




VHT-40 MHz CHANNEL 6, SPURIOUS  
2 GHz ~ 25 GHz




VHT-40 MHz CHANNEL 7 CARRIER LEVEL




VHT-40 MHz CHANNEL 7, SPURIOUS  
30 MHz ~ 3 GHz




VHT-40 MHz CHANNEL 7, SPURIOUS  
2 GHz ~ 25 GHz




### VHT-40 MHz CHANNEL 8 CARRIER LEVEL




### VHT-40 MHz CHANNEL 8, SPURIOUS 30 MHz ~ 3 GHz




### VHT-40 MHz CHANNEL 8, SPURIOUS 2 GHz ~ 25 GHz




### VHT-40 MHz CHANNEL 9 CARRIER LEVEL




VHT-40 MHz CHANNEL 9, SPURIOUS  
30 MHz ~ 3 GHz



VHT-40 MHz CHANNEL 9, SPURIOUS  
2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) CHANNEL 1 CARRIER LEVEL







802.11ax-20 MHz(SU) CHANNEL 1, SPURIOUS  
30 MHz ~ 3 GHz




802.11ax-20 MHz(SU) CHANNEL 1, SPURIOUS  
2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) CHANNEL 2 CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 2, SPURIOUS  
30 MHz ~ 3 GHz



802.11ax-20 MHz(SU) CHANNEL 2, SPURIOUS  
2 GHz ~ 25 GHz





802.11ax-20 MHz(SU) CHANNEL 3 CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 3, SPURIOUS  
30 MHz ~ 3 GHz


802.11ax-20 MHz(SU) CHANNEL 3, SPURIOUS  
2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) CHANNEL 6 CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 6, SPURIOUS  
30 MHz ~ 3 GHz




802.11ax-20 MHz(SU) CHANNEL 6, SPURIOUS  
2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) CHANNEL 8 CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 8, SPURIOUS  
30 MHz ~ 3 GHz




802.11ax-20 MHz(SU) CHANNEL 8, SPURIOUS  
2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) CHANNEL 9 CARRIER LEVEL



802.11ax-20 MHz(SU) CHANNEL 9, SPURIOUS  
30 MHz ~ 3 GHz



802.11ax-20 MHz(SU) CHANNEL 9, SPURIOUS  
2 GHz ~ 25 GHz





802.11ax-20 MHz(SU) CHANNEL 10 CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 10, SPURIOUS  
30 MHz ~ 3 GHz


802.11ax-20 MHz(SU) CHANNEL 10, SPURIOUS  
2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) CHANNEL 11 CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 11, SPURIOUS  
30 MHz ~ 3 GHz



802.11ax-20 MHz(SU) CHANNEL 11, SPURIOUS  
2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) CHANNEL 3 CARRIER LEVEL







802.11ax-40 MHz(SU) CHANNEL 3, SPURIOUS  
30 MHz ~ 3 GHz




802.11ax-40 MHz(SU) CHANNEL 3, SPURIOUS  
2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) CHANNEL 4 CARRIER LEVEL




802.11ax-40 MHz(SU) CHANNEL 4, SPURIOUS  
30 MHz ~ 3 GHz




802.11ax-40 MHz(SU) CHANNEL 4, SPURIOUS  
2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) CHANNEL 5 CARRIER LEVEL



802.11ax-40 MHz(SU) CHANNEL 5, SPURIOUS  
30 MHz ~ 3 GHz



802.11ax-40 MHz(SU) CHANNEL 5, SPURIOUS  
2 GHz ~ 25 GHz



802.11ax-40 MHz(SU) CHANNEL 6 CARRIER LEVEL

