


### 802.11g CHANNEL 2, CARRIER LEVEL




### 802.11g CHANNEL 2, BAND EDGE



### 802.11g CHANNEL 8, CARRIER LEVEL




### 802.11g CHANNEL 8, BAND EDGE




### 802.11g CHANNEL 9, CARRIER LEVEL




### 802.11g CHANNEL 9, BAND EDGE



### 802.11g CHANNEL 10, CARRIER LEVEL




### 802.11g CHANNEL 10, BAND EDGE




### 802.11g CHANNEL 11, CARRIER LEVEL



### 802.11g CHANNEL 11, BAND EDGE



### 802.11n-20 MHz CHANNEL 1, CARRIER LEVEL



### 802.11n-20 MHz CHANNEL 1, BAND EDGE



802.11n-20 MHz CHANNEL 2, CARRIER LEVEL




802.11n-20 MHz CHANNEL 2, BAND EDGE




802.11n-20 MHz CHANNEL 8, CARRIER LEVEL




802.11n-20 MHz CHANNEL 8, BAND EDGE



802.11n-20 MHz CHANNEL 9, CARRIER LEVEL




802.11n-20 MHz CHANNEL 9, BAND EDGE




802.11n-20 MHz CHANNEL 10, CARRIER LEVEL




802.11n-20 MHz CHANNEL 10, BAND EDGE




802.11n-20 MHz CHANNEL 11, CARRIER LEVEL



802.11n-20 MHz CHANNEL 11, BAND EDGE




802.11n-40 MHz CHANNEL 3, CARRIER LEVEL




802.11n-40 MHz CHANNEL 3, BAND EDGE




802.11n-40 MHz CHANNEL 4, CARRIER LEVEL




802.11n-40 MHz CHANNEL 4, BAND EDGE




802.11n-40 MHz CHANNEL 5, CARRIER LEVEL




802.11n-40 MHz CHANNEL 5, BAND EDGE




802.11n-40 MHz CHANNEL 7, CARRIER LEVEL




802.11n-40 MHz CHANNEL 7, BAND EDGE




### 802.11n-40 MHz CHANNEL 8, CARRIER LEVEL




### 802.11n-40 MHz CHANNEL 8, BAND EDGE



### 802.11n-40 MHz CHANNEL 9, CARRIER LEVEL



### 802.11n-40 MHz CHANNEL 9, BAND EDGE




### VHT-20 MHz CHANNEL 1, CARRIER LEVEL




### VHT-20 MHz CHANNEL 1, BAND EDGE




VHT-20 MHz CHANNEL 2, CARRIER LEVEL




VHT-20 MHz CHANNEL 2, BAND EDGE



VHT-20 MHz CHANNEL 8, CARRIER LEVEL




VHT-20 MHz CHANNEL 8, BAND EDGE



VHT-20 MHz CHANNEL 9, CARRIER LEVEL




VHT-20 MHz CHANNEL 9, BAND EDGE




VHT-20 MHz CHANNEL 10, CARRIER LEVEL



VHT-20 MHz CHANNEL 10, BAND EDGE




VHT-20 MHz CHANNEL 11, CARRIER LEVEL



VHT-20 MHz CHANNEL 11, BAND EDGE



VHT-40 MHz CHANNEL 3, CARRIER LEVEL




VHT-40 MHz CHANNEL 3, BAND EDGE







VHT-40 MHz CHANNEL 4, CARRIER LEVEL




VHT-40 MHz CHANNEL 4, BAND EDGE




VHT-40 MHz CHANNEL 5, CARRIER LEVEL




VHT-40 MHz CHANNEL 5, BAND EDGE




VHT-40 MHz CHANNEL 7, CARRIER LEVEL




VHT-40 MHz CHANNEL 7, BAND EDGE




VHT-40 MHz CHANNEL 8, CARRIER LEVEL




VHT-40 MHz CHANNEL 8, BAND EDGE



VHT-40 MHz CHANNEL 9, CARRIER LEVEL



VHT-40 MHz CHANNEL 9, BAND EDGE




802.11ax-20 MHz(SU) CHANNEL 1, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 1, BAND EDGE



802.11ax-20 MHz(SU) CHANNEL 2, CARRIER LEVEL



802.11ax-20 MHz(SU) CHANNEL 2, BAND EDGE




802.11ax-20 MHz(SU) CHANNEL 3, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 3, BAND EDGE



802.11ax-20 MHz(SU) CHANNEL 8, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 8, BAND EDGE




802.11ax-20 MHz(SU) CHANNEL 9, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 9, BAND EDGE




802.11ax-20 MHz(SU) CHANNEL 10, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 10, BAND EDGE




802.11ax-20 MHz(SU) CHANNEL 11, CARRIER LEVEL



802.11ax-20 MHz(SU) CHANNEL 11 BAND EDGE




802.11ax-40 MHz(SU) CHANNEL 3, CARRIER LEVEL




802.11ax-40 MHz(SU) CHANNEL 3, BAND EDGE




802.11ax-40 MHz(SU) CHANNEL 4, CARRIER LEVEL




802.11ax-40 MHz(SU) CHANNEL 4, BAND EDGE




802.11ax-40 MHz(SU) CHANNEL 5, CARRIER LEVEL




802.11ax-40 MHz(SU) CHANNEL 5, BAND EDGE




802.11ax-40 MHz(SU) CHANNEL 7, CARRIER LEVEL




802.11ax-40 MHz(SU) CHANNEL 7, BAND EDGE




802.11ax-40 MHz(SU) CHANNEL 8, CARRIER LEVEL




802.11ax-40 MHz(SU) CHANNEL 8, BAND EDGE



802.11ax-40 MHz(SU) CHANNEL 9, CARRIER LEVEL



802.11ax-40 MHz(SU) CHANNEL 9, BAND EDGE



MIMO-Aux. Antenna

802.11b CHANNEL 1, CARRIER LEVEL




802.11b CHANNEL 1, BAND EDGE




802.11b CHANNEL 11, CARRIER LEVEL



802.11b CHANNEL 11, BAND EDGE




802.11g CHANNEL 1, CARRIER LEVEL




802.11g CHANNEL 1, BAND EDGE



### 802.11g CHANNEL 2, CARRIER LEVEL




### 802.11g CHANNEL 2, BAND EDGE



### 802.11g CHANNEL 8, CARRIER LEVEL




### 802.11g CHANNEL 8, BAND EDGE



### 802.11g CHANNEL 9, CARRIER LEVEL



### 802.11g CHANNEL 9, BAND EDGE







### 802.11g CHANNEL 10, CARRIER LEVEL



### 802.11g CHANNEL 10, BAND EDGE




### 802.11g CHANNEL 11, CARRIER LEVEL



### 802.11g CHANNEL 11, BAND EDGE



### 802.11n-20 MHz CHANNEL 1, CARRIER LEVEL



### 802.11n-20 MHz CHANNEL 1, BAND EDGE

