




802.11g CHANNEL 9, SPURIOUS 30 MHz ~ 3 GHz





802.11g CHANNEL 9, SPURIOUS 2 GHz ~ 25 GHz



802.11g CHANNEL 10 CARRIER LEVEL




802.11g CHANNEL 10, SPURIOUS 30 MHz ~ 3 GHz




### 802.11g CHANNEL 11 CARRIER LEVEL




### 802.11g CHANNEL 11, SPURIOUS 30 MHz ~ 3 GHz




### 802.11g CHANNEL 11, SPURIOUS 2 GHz ~ 25 GHz




### 802.11n-20 MHz CHANNEL 1 CARRIER LEVEL




802.11n-20 MHz CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz




802.11n-20 MHz CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz




802.11n-20 MHz CHANNEL 2 CARRIER LEVEL




802.11n-20 MHz CHANNEL 2, SPURIOUS 30 MHz ~ 3 GHz




802.11n-20 MHz CHANNEL 2, SPURIOUS 2 GHz ~ 25 GHz




### 802.11n-20 MHz CHANNEL 3 CARRIER LEVEL




### 802.11n-20 MHz CHANNEL 3, SPURIOUS 30 MHz ~ 3 GHz




### 802.11n-20 MHz CHANNEL 3, SPURIOUS 2 GHz ~ 25 GHz




### 802.11n-20 MHz CHANNEL 4 CARRIER LEVEL




802.11n-20 MHz CHANNEL 4, SPURIOUS 30 MHz ~ 3 GHz




802.11n-20 MHz CHANNEL 4, SPURIOUS 2 GHz ~ 25 GHz




802.11n-20 MHz CHANNEL 6 CARRIER LEVEL




802.11n-20 MHz CHANNEL 6, SPURIOUS 30 MHz ~ 3 GHz




802.11n-20 MHz CHANNEL 6, SPURIOUS 2 GHz ~ 25 GHz




### 802.11n-20 MHz CHANNEL 7 CARRIER LEVEL



### 802.11n-20 MHz CHANNEL 7, SPURIOUS 30 MHz ~ 3 GHz




### 802.11n-20 MHz CHANNEL 7, SPURIOUS 2 GHz ~ 25 GHz




### 802.11n-20 MHz CHANNEL 8 CARRIER LEVEL




802.11n-20 MHz CHANNEL 8, SPURIOUS 30 MHz ~ 3 GHz





802.11n-20 MHz CHANNEL 8, SPURIOUS 2 GHz ~ 25 GHz




802.11n-20 MHz CHANNEL 9 CARRIER LEVEL




802.11n-20 MHz CHANNEL 9, SPURIOUS 30 MHz ~ 3 GHz




### 802.11n-20 MHz CHANNEL 10 CARRIER LEVEL




### 802.11n-20 MHz CHANNEL 10, SPURIOUS 30 MHz ~ 3 GHz



### 802.11n-20 MHz CHANNEL 10, SPURIOUS 2 GHz ~ 25 GHz




### 802.11n-20 MHz CHANNEL 11 CARRIER LEVEL







802.11n-20 MHz CHANNEL 11, SPURIOUS 30 MHz ~ 3 GHz




802.11n-20 MHz CHANNEL 11, SPURIOUS 2 GHz ~ 25 GHz




802.11n-40 MHz CHANNEL 3 CARRIER LEVEL




802.11n-40 MHz CHANNEL 3, SPURIOUS 30 MHz ~ 3 GHz




802.11n-40 MHz CHANNEL 3, SPURIOUS 2 GHz ~ 25 GHz




### 802.11n-40 MHz CHANNEL 4 CARRIER LEVEL




### 802.11n-40 MHz CHANNEL 4, SPURIOUS 30 MHz ~ 3 GHz




### 802.11n-40 MHz CHANNEL 4, SPURIOUS 2 GHz ~ 25 GHz




### 802.11n-40 MHz CHANNEL 5 CARRIER LEVEL




802.11n-40 MHz CHANNEL 5, SPURIOUS  
30 MHz ~ 3 GHz




802.11n-40 MHz CHANNEL 5, SPURIOUS  
2 GHz ~ 25 GHz




802.11n-40 MHz CHANNEL 6 CARRIER LEVEL




802.11n-40 MHz CHANNEL 6, SPURIOUS  
30 MHz ~ 3 GHz




802.11n-40 MHz CHANNEL 6, SPURIOUS  
2 GHz ~ 25 GHz




### 802.11n-40 MHz CHANNEL 7 CARRIER LEVEL




### 802.11n-40 MHz CHANNEL 7, SPURIOUS 30 MHz ~ 3 GHz




### 802.11n-40 MHz CHANNEL 7, SPURIOUS 2 GHz ~ 25 GHz




### 802.11n-40 MHz CHANNEL 8 CARRIER LEVEL




802.11n-40 MHz CHANNEL 8, SPURIOUS  
30 MHz ~ 3 GHz




802.11n-40 MHz CHANNEL 8, SPURIOUS  
2 GHz ~ 25 GHz




802.11n-40 MHz CHANNEL 9 CARRIER LEVEL




802.11n-40 MHz CHANNEL 9, SPURIOUS  
30 MHz ~ 3 GHz




802.11n-40 MHz CHANNEL 9, SPURIOUS  
2 GHz ~ 25 GHz




### VHT-20 MHz CHANNEL 1 CARRIER LEVEL




### VHT-20 MHz CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz




### VHT-20 MHz CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz




### VHT-20 MHz CHANNEL 2 CARRIER LEVEL




VHT-20 MHz CHANNEL 2, SPURIOUS 30 MHz ~ 3 GHz




VHT-20 MHz CHANNEL 2, SPURIOUS 2 GHz ~ 25 GHz




VHT-20 MHz CHANNEL 3 CARRIER LEVEL




VHT-20 MHz CHANNEL 3, SPURIOUS 2 GHz ~ 25 GHz




VHT-20 MHz CHANNEL 3, SPURIOUS 30 MHz ~ 3 GHz




### VHT-20 MHz CHANNEL 4 CARRIER LEVEL



### VHT-20 MHz CHANNEL 4, SPURIOUS 30 MHz ~ 3 GHz



### VHT-20 MHz CHANNEL 4, SPURIOUS 2 GHz ~ 25 GHz




### VHT-20 MHz CHANNEL 6 CARRIER LEVEL







VHT-20 MHz CHANNEL 6, SPURIOUS 30 MHz ~ 3 GHz





VHT-20 MHz CHANNEL 6, SPURIOUS 2 GHz ~ 25 GHz



VHT-20 MHz CHANNEL 7 CARRIER LEVEL




VHT-20 MHz CHANNEL 7, SPURIOUS 30 MHz ~ 3 GHz




### VHT-20 MHz CHANNEL 8 CARRIER LEVEL




### VHT-20 MHz CHANNEL 8, SPURIOUS 30 MHz ~ 3 GHz




### VHT-20 MHz CHANNEL 8, SPURIOUS 2 GHz ~ 25 GHz




### VHT-20 MHz CHANNEL 9 CARRIER LEVEL




VHT-20 MHz CHANNEL 9, SPURIOUS 30 MHz ~ 3 GHz




VHT-20 MHz CHANNEL 9, SPURIOUS 2 GHz ~ 25 GHz




VHT-20 MHz CHANNEL 10 CARRIER LEVEL




VHT-20 MHz CHANNEL 10, SPURIOUS 30 MHz ~ 25 GHz




VHT-20 MHz CHANNEL 10, SPURIOUS 30 MHz ~ 3 GHz




### VHT-20 MHz CHANNEL 11 CARRIER LEVEL




### VHT-20 MHz CHANNEL 11, SPURIOUS 30 MHz ~ 3 GHz




### VHT-20 MHz CHANNEL 11, SPURIOUS 2 GHz ~ 25 GHz




### VHT-40 MHz CHANNEL 3 CARRIER LEVEL




VHT-40 MHz CHANNEL 3, SPURIOUS  
30 MHz ~ 3 GHz




VHT-40 MHz CHANNEL 3, SPURIOUS  
2 GHz ~ 25 GHz



VHT-40 MHz CHANNEL 4 CARRIER LEVEL



VHT-40 MHz CHANNEL 4, SPURIOUS  
30 MHz ~ 3 GHz



VHT-40 MHz CHANNEL 4, SPURIOUS  
2 GHz ~ 25 GHz

