


Wireless Earbuds User Manual

Model: JT601
Item No.: 5517




Dear customer:
Thank you for purchasing Wireless Earbuds.
Please read this user guide carefully before operation
and save these instructions for future reference.

Packaging included:
1. Wireless Earbuds.....1 pc
2. Charging Cable.....1 pc
3. User manual1 pc

SPECIFICATIONS:

- Model # : JT601 Item No.: 5517
- Bluetooth QDID: 115952
- Declaration ID: D048523
- FCC ID: 2AUZO-JT601
- Battery: 40 mAh
- Music Play time: Up to 2.5 hours
- Speaker Output Frequency range: 150Hz - 20Khz

Function Keys:



1. Vol- / Previous Song
2. "M" Button: Power ON-OFF / Light ON/OFF / Play / Pause / Phone
3. Vol+ / Next Song
4. Charging port
5. LED Indicator

ON/OFF

Press and hold ON/OFF button to turn ON or turn OFF the earbuds. The RED light will blink when speaker is turned ON.

BLUETOOTH PAIRING

1. Press and hold ON/OFF button till to hear "Power ON" to turn ON the earbuds.
2. The RED light is blinking and earbuds is now in pairing mode.
3. Place the earbuds and Bluetooth® device (phone or music device) so that they are no further than 1 meter apart.
4. Activate the Bluetooth® function on your Bluetooth® device (phone or music device). Please refer to the manufacturer's instruction manual to enable Bluetooth® on your device.
5. Select the earbuds "BT earbuds" from the list of available Bluetooth® devices.
6. Once paired successfully, you will hear "connected". If pairing is unsuccessful, turn off the earbuds first and then re-pair following the above steps.
7. Once you have paired the earbuds with a device, the earbuds will remember this device and will pair automatically when the device's Bluetooth® is activated and in range. The earbuds will attempt to automatically connect to the last device it was paired with when switched on. If you want to pair it with a new device, please follow the steps outlined above.

PLAY MUSIC

1. Short press "M" button to pause music or to answer a call. Short press again to resume music play.
2. In Bluetooth® Mode, Short press "Vol-" button to skip to the previous song. Hold this button down for longer to decrease the volume.
3. In Bluetooth® Mode, short press "Vol+" button to skip to next song. Hold this button down for longer to increase the volume.

Hands Free Phone Call Operation

1. Short press "M" button to answer an incoming call. Long press to reject the call.
2. Short press "M" button to hang up the active call.
3. Double press "M" button to re-dial the last call.

Turn ON/OFF logo light

In Bluetooth® Mode, quick press twice "M" button to turn ON/OFF logo light .

CHARGING

The earbuds includes a built-in rechargeable battery.
It is recommended to charge the battery fully prior to first use.
Connect the USB cable to a computer or other USB charging port and the micro USB plug into charging port of the earbuds.
A red light turns ON during charging and turns OFF after full charged.

IMPORTANT NOTES

1. This product is not a toy.
2. Do not drop or damage the earbuds.
3. Do not use in humid or extrem temperatures.
4. Do not place the earbuds near an open flame.
5. Do not block the sound of the earbuds while it is in use.
6. Do not use the unit if it has been dropped or damaged in any way.
7. If damaged, do not attempt to repair or disassembled the earbuds.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID: 2AUZO-JT601

- Do not expose battery to heat sources, extended direct sunlight or other high temperature environment.
- Avoid drops and excessive impacts to the battery.
- Do not disassemble, attempt to repair or replace any part of the housing or battery.
- Do not attempt to charge the battery using any other method, apparatus, or connections other than the device's charging cable.
- Never dispose of batteries in the garbage. This is unlawful under state and federal environmental laws and regulations. Always take used batteries to your local battery-recycling center.

FCC Compliance: warning: changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

Note: this equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by HK JIATAI ELECTRON LIMITED may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.