

# Power Bank Wireless Charger

## User Manual

### ONETNES

1.0 INTRODUCTION	-----	1
2.0 FEATURES	-----	1
3.0 SPECIFICATIONS	-----	2
4.0 PACKAGE CONTENTS	-----	2
5.0 OPERATION	-----	3-4
6.0 CONNECTION DIAGRAM	-----	5-6

# Power Bank Wireless Charger

## DEAR CUSTOMER

Thank you for purchasing this product. For optimum performance and safety, please read these instructions carefully before connecting, operating or using this product. Please keep this manual for future reference.

## 1.0 INTRODUCTION

This product is a high-performance wireless charger. This product is suitable for mobile phones, MP3, MP4, digital productions, and other productions based on wireless charging 5W or 10W. Connect the power bank wireless to a power charger, and Or then you can charge your device supported wireless charging (mobile phones, etc) by put it on the charger directly. It is helpful in long time journey and convenient for business!

## 2.0 FEATURES

- 10000mAh large capacity
- Polymer battery
- Type-C charger : 5V/2A,or9V/1.1A
- Dual USB ports with different outputs:  
USB-C: 5V/3A  
USB-A: 5V/2A,  
Total:5V3A (max)
- Type-C wireless input:10W
- Overcharge and over-discharge protection
- Output over current protection and short circuit protection
- Over temperature protection with auto-recovery
- Automatic power-off
- Intelligent LED battery indicators
- Compliant with FCC,CE,UN38.3 standards
- It is light, smart and convenient to use
- Suitable for smart phone, iPod, Camera etc.

### 3.0 SPECIFICATIONS

Input/output	
Type-C charger :	5V/2A,or9V/1.1A
Output	Dual USB ports with different outputs: USB-C: 5V/3A USB-A: 5V/2A,  Total:5V3A (max)  wireless charging 5W/7.5W/10W
Port	2 USB Ports
Protection	
Overload protection	Yes
Over-current Protection	Yes
Over Temperature Protection	Yes
Short circuit protection	Yes
Performance	
Ripple And Noise	≤200mVp-p
Standby Power Dissipation	≤700uA
Power bank Efficiency	≥89%
wireless Switch Frequency	110-205K
Mechanical	
Color	black
Size(L*W*H)	167.7*75.7*18.2mm
Weight	275±10 g
Environmental	
Operating Temperature Range	0~30°C
Storage Temperature Range	-20 ~ 70°C
Operating Humidity	<85%RH
Storage Humidity	<95%RH
Certification	FCC,CE,UN38.3 QI 1.2.4 (BPP)
User Manual	English Version
Size	167.7(L)*75.7 (W)* 18.2(H)mm

### 4.0 PACKAGE CONTENTS

Before attempting to use this unit, please check the packaging and make sure the following items are contained in the shipping carton:

- Main unit×1

- User Manual×1

## 5.0 OPERATION

### Operation Procedures



1. Power button: push to turn on the power bank wireless charger
2. LED indicator lights

During charging:

LED indicator status	Battery Percentage	Remark
◎○○○❏	1%-----24%	The current LED indicator light flashing
●◎○○❏	25% ----- 49%	The current LED indicator light flashing
●●◎○❏	50% ----- 74%	The current LED indicator light flashing
●●●◎❏	75% -----99%	The current LED indicator light flashing
●●●●❏	100%	ALL LEDS Bright

During discharging:

LED indicator status	Battery Percentage	Remark
●●●●❏	75% ----- 100%	4 LED lights on
●●●○❏	50% ----- 74%	3 LED lights on
●●○○❏	25%-----49%	2 LED light on
●○○○❏	1% ----- 24%	1 LED light on
○○○○❏	0	All LED lights off

◎ flashing      ● light on      ○ light off      ❏ wireless charging

☒: Put your device (supported wireless charging) on the charger, the light will turn **Blue light breath** .When finished charging, the light will turn red. The fault turns red light flashing

3. USB-C port: connect a charger for charging or connect a device for discharging;

Input charging: 5V/2A, 9V/1.1A

Output discharging: 5V/3A (max)

**Wireless input 10W**

4. USB-A port: to connect a digital devices for discharging

Output: 5V/2A

5. wireless charging

### **Operation Notes**

1. For optimum performance, please use the wireless charger according to this user manual.
2. Please connect the wireless charger to a power adapter which output should be QC3.0 standards A to C 56K line
3. Please unplug the wireless charger after using.
4. Do not use the wireless charger with an electronic product which is not in conformity with the specifications, so as to avoid any problem caused by specification mismatching.
5. It's normal that wireless charger will be a little overheated in the use process.
6. When the wireless charger stops working under some accidents occurs, you need to check whether the device is compatible with this charger.
7. Do not let the wireless charger close to fire, such as stove, candles and etc.
8. Do not let the wireless charger soak into liquid, such as swimming pool, bathtub, etc.
9. Do not wash the wireless charger with corrosive cleaner.
10. If the wireless charger cannot work properly, please contact the store or distributor in your area.

### **FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

### **FCC Warning**

This device complies with Part 15 and Part 18 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## 6.0 CONNECTION DIAGRAM


### 6.0 OPERATION

#### Operation Procedures

- a) Charge the power bank
  - Plug to a standard wall outlet via the TYPE-C



- b) Charge the devices



c) wireless charger the devices

