

料号：602040173

### Connection & Controls

- INPUT Jack:** 1/4" mono audio jack, for connecting guitar.
- DRUM VOL Knob:** Controls the drum output level.
- MOD Knob:** Rotate to select modulation effects and adjust the rate/depth.
- DELAY Knob:** Rotate to select delay effects and adjust the delay time.
- REVERB Knob:** Rotate to select reverb effects and adjust the reverb mix.
- LED Screen:** Displays various information.
- POWER Switch:** Switches Cyclops ON/OFF.
- ▶/■ Button:** Tap to start/stop drum rhythm playback. Hold to select drum styles.
- TAP Button:** Tap to change drum tempo. Hold to enable tuner.
- AMP Knob:** Selects amp models.
- TONE Knob:** Controls the amplifier output level.
- BT Status LED:** Indicates BT status: Flashing: Stand by Ready to pair Solid Light: Connected
- MASTER Knob:** Adjusts the overall output volume.

### How to Use BT Audio

Connect: BT will be ready to pair when Cyclops is on. Activate BT function on your mobile device and then select "DONNER CYCLOPS" when it appears on the device list. When connected, the BT LED will become solid.

BT Volume: Use your mobile device to control the BT audio volume.

Disconnect: Disconnect "DONNER CYCLOPS" on device list on your mobile device to disconnect. You can also turn off BT switch on your mobile device to disconnect.

### Drum Rhythm

- Press the ▶/■ button to start or stop drum play.
- Hold the ▶/■ button to enter drum rhythm menu, then press the button repeatedly to select a drum rhythm type.
- Rotate the DRUM VOL knob to adjust drum volume.
- Press TAP button to set drum tempo. The button LED will pulse to indicate the drum tempo you set.

### Tuner

Hold TAP button 2 seconds to enable the tuner. The note name appears on the screen (the dot on the bottom right of the screen stands for "sharp"), and the pitch accuracy is indicated by the LEDs. When tuner is activated, Cyclops will be muted. Press TAP button to exit tuner.

### Amplifier List\*

Name	Based on	Cab Sim
Jazz CL	Legendary Jazz Clean amp	2x12
TWD LUX	Fender® Tweed Deluxe	2x12
UK 800	Marshall® JCM800	4x12
Vox 30T	Vox® AC30 Top Boost	2x12
PV 51	Peavey® 5150*	4x12
US RECT	MesaBoogie® Dual Rectifier	4x12
FLAT	Flat Output	/

\*The mentioned manufacturers and product names are trademarks or registered trademarks of their respective owners which were used merely to identify the sound character of this product.

### Owner's Manual

## DONNER CYCLOPS

### Introduction

Donner Cyclops is a lightweight, retro design, at-in-one mini guitar combo amplifier. The portable design is great for bedroom recording, desktop production, desktop recording, or taking out anywhere jamming with your friends.

### Specifications

- Input Impedance: 470kOhm
- Power: 5W RMS
- Speaker Size: 3"
- Frequency Response Range: 40Hz-16kHz
- Power Supply: DC 5V, AA battery x6, or USB 5V (supports power bank)
- BT Version: BT 5.3
- Working Range: < 10m
- Current Consumption: DC 5V: 120mA (static) 600mA (maximum) USB 5V: 180mA (static)
- 2A (maximum)
- Dimensions: 170\*70\*148.5mm
- Weight: 1472g

### Features

- 5 Watt output
- 7 Amplifier models (Clean x2 - Overdrive x2 - HighGain x2 - Flat)
- 8 Effects - Mod x2 (Chorus/Tremolo), Delay x2 (Warm/Pure), Reverb x2 (Room/Plate)
- 40 drum patterns (incl. 10 metronome types)
- Tap tempo for controlling drum tempo
- BT audio function
- Runs with 9V power adapter, USB bus power, or 6 AA size batteries.

### FCC Statement

This device complies with part 15 of the FCC Rules. Operator is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment may cause harmful interference to radio communications; however, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: 1) Reorient or relocate the receiving antenna. 2) Increase the separation between the equipment and the receiver. 3) Connect the equipment to an outlet on a circuit different from that to which the receiver is connected. 4) Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be operated with minimum distance 20cm between the operator & your body.

FCC ID: 2AC74-EC021

### Overview

- 7 Amplifier Models**  
Cyclops gives you seven amplifier models: six guitar amps models (based on world famous classic/modern amplifiers) and a "flat" model with an unprocessed transparent sound.
- Beef Up Your Tone**  
Cyclops offers 3 types of effects: mod, delay, reverb. Each type gives you two selections, and one-knob control makes it easy to use. Tweak them and add some spacious dimensions to your tone!
- Wireless Audio Playback**  
Cyclops features BT audio function so that you can pair it with your phone and then enjoy your favorite songs on the fly.
- Cool Retro Design**  
Cyclops is a fresh design drawn from retro elements. It will add luster to your home no matter where you put it!

### Precautions

**READ CAREFULLY BEFORE PROCEEDING**  
Please keep this manual in a convenient place for future reference.

**Power Supply**  
Always use a DC 5V center negative AC adapter. Use of an adapter other than that specified could damage the unit or cause malfunction and pose a safety hazard. Always connect the AC adapter to an AC outlet that supplies the rated voltage required by the adapter. Disconnect the AC adapter from the AC outlet when during lightning storms or not using the unit for an extended period. Carefully read the safety indications on the batteries before use. When not using the unit for an extended period, remove the batteries from the unit. If battery leakage should occur, thoroughly wipe the battery holder and the battery terminals to remove battery fluid. Close the battery holder cover when using the unit.

**Connections**  
Always turn off the power before connecting or disconnecting. Make sure to disconnect all cables and AC adapter before moving the unit. This will help prevent malfunction and damages.

**Environment Considerations**  
Avoid using the unit in any of the following conditions that could cause malfunction:

- Extremely hot or cold places
- Under direct sunlight
- Magnetic fields
- Near heaters and other heat sources
- Sturdy or dusty places
- Places that are extremely humid or exposed to splashing water
- Places with lots of vibrations

**Electrical Interference**  
Devices that are very susceptible to interference or that emits powerful electromagnetic waves (e.g. radios and TVs) should not be placed near this unit, as interference could occur. Electromagnetic interference could cause malfunction and could corrupt or destroy data. Always operate this unit at a suitable distance from these devices.

**Handling**  
Do not apply excessive force to the switches and other controls, exposing the unit to strong impacts, which could cause it to break. Do not put foreign objects or liquids into the unit. Never open the case or attempt to modify the product in any way since this can result in damage to the unit. Clean only with a soft, dry cloth.

折痕处

技术要求：  
120g白色书纸，262\*290mm，双面四色印刷  
(红色虚线为折痕，不做印刷)