



Nectar Smart Caps



Before using smart caps, review the User Guide at <https://help.getnectar.com/hc/en-us/categories/360002037854-Devices-settings>

Description

Nectar Smart Caps are designed to measure container levels using ultrasound and broadcast a BLE packet containing the measurement to the Nectar Base Station.

They have a BLE broadcasting range of 20–30 feet in radius.

Features

- **Pourer dimensions:** 3.6 × 3.6 × 12cm
- **Stopper dimensions:** 3.6 × 3.6 × 5.2cm
- **Pourer weight:** 52g
- **Stopper weight:** 50g
- **Power:** Battery
- **Radios:** BLE 4.0
- Activation button

Installation



Configure your base station(s) before activating your smart cap(s)

1. Download and install the Nectar app to your mobile device
2. Place the smart cap on its assigned products (check the printed label on the back of each cap)
3. Press and hold the Nectar logo for 3 seconds to turn on and activate each cap

Note: It may take up to 2 minutes for the first measurement to appear in the Nectar mobile app.

Battery

Do not attempt to replace the battery yourself—you may damage the battery, which could cause overheating, fire, and injury. The battery in the smart cap should only be serviced or recycled by Nectar, and must be recycled or disposed of separately from household waste. Dispose of

batteries according to your local governmental laws and guidelines.

FCC and ISED Canada Compliance

This device complies with Part 15 of the FCC Rules and ISED Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Nectar, Inc. may void the user's authority to operate the equipment.



FCC ID: 2AVAD0001A

To view regulatory information from your mobile device: **Manage > App Info > Regulatory Info**