

**MONSTER®**

**CLARITY | AIRLINKS**

**Model No.:MH21903**

**FCC ID:2AVD2-MH21903**

## **Quick Start Guide**

Please read this Quick Start Guide carefully and keep it for future use.



## Product Overview


In-ear Earphones (left & right)

Charging Case

USB-C Charging Cable

Ear Tips × 3 pairs (M size installed)

Quick Start Guide and Warranty Letter



1. Multi Function Button (MFB)

2. Indicator Light (White)

3. Microphones

4. Ear Tip

5. USB-C Charging Port

6. Pair/ Reset to Factory Settings Button

7. Charging Case

8. Charging Case Indicator Light

### **Power On/Off**

The earphones will be turned on when opening the charging case. To turn off the earphones, put back to the charging case and close. Earphones will be turned off and start charging.

### **Noise Cancellation On/Off**

Press and hold the MFB for about 2 seconds to switch different mode.

[Noise Cancellation On] – [Transparency Mode] – [Noise Cancellation Off]

Transparency Mode 請看看有沒有相關的註冊商標權

### **Charging case**

Connect the included USB-C cable to charge the charging case. During the charging process, the charging case light indicator will show the current charge status. When the charging case is fully charged, the light will turn off.

### **Pairing**

Open the charging case, the earphones will be turned on automatically. Left and right earphones will be connected automatically within few seconds. Then “pairing” voice prompt will be heard. For new device connection, go to the Bluetooth settings on your device and set it to search for new devices (new Monster device). Once the earphones are paired to the designated device, you will hear “connected”.

### **Connect other devices**

Keep the earphones in the charging case and leave the cover open. Press and hold the pair button which is located on the bottom of the charging case for about 2 seconds until the light indicator start to flash. It is now in pairing mode. Activate the Bluetooth on your device and set it to search for new devices.

### **Volume Control**

The earphones do not have volume control function. After Bluetooth connection, volume level can be controlled on the connected device.

### **Calling**

Answer/End call: Click the MFB.

Reject a call: Double-click the MFB.

### **Music**

Play/Pause music: Short press the MFB.




Previous song: Double-click the MFB on the left earphone.

Next song: Double-click the MFB on the right earphone.

### **Voice Control**

After connecting to the phone, triple-click the MFB quickly to activate the voice assistant.

### LED Indicator Guide

Mode	Description	Voice prompts
Power On	Indicator light stays on about 1 second.	"Power On"
Power Off	Indicator light stays on about 1 second.	"Power Off "
Pairing	Indicator light flashes quickly.	"Pairing"
Connected	After connected, Indicator light goes off.	"Connected"
Earphones charging	When left earphones is charging, the left indicator light is on. 	-
	When right earphones is charging, the right indicator light is on. 	
	When both earphones are charging, the left and right indicator lights are on respectively. 	
Charging case	Charging case indicator light flashes while charging. When charging case indicator light is off, it is fully charged.	-

**Note:**

- \* After removing the earpieces from the charging case, without pressing any buttons, the left and right earpieces will connect automatically. If there is no connection found, it enters to pairing mode automatically.
- \* Please put the earphones in the correct position to charge.
- \* It is not recommended to replace the battery privately.
- \* The battery (battery pack or combination battery) must not be exposed to excessive heat such

as sunlight or fire.

### **FCC Statement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.