

USB 插口: USB Socket

AUX 插口: AUX Socket

V+/音量+: Press for a longer time-Increase Volume


V-/音量-: Press for a longer time-Decrease Volume

暂停: Pause

短按音乐: Press for a shorter time- Music

喇叭: Press for a shorter time- SPK

电量/显示: Electricity/Display



电源+12V: Power +12V

喇叭: Speaker

外接触发点: Connection of Touch Spot

外接音乐: Connection of Music

外接喇叭: Connection of Loudspeaker

(通上电源 开机启动音时短按任何键都可能打断启动音)

(Connect with power, and pressing any button can disrupt auto startup engine sound.

开机启动音结束后 默认进入音乐模式提示音: 有音乐模式提示音 音乐是不会自动播放,
After the auto startup engine sound, it will get into music mode: there will be one voice
said"Music",the music will not be on automatically by itself.

一. 按键功能说明: Instructions of buttons

1. 电量/显示:可显示当前模式、当前电量、音乐第几首,
Electricity/Display:Show current mode/electricity/music
2. USB卡插口:最大支持 16G, 大于 16G 将识别不到,
USB Card Socket: Can support 16G maximum, otherwise can not work.
3. AUX 插口:可连接手机数据线
AUX Socket: Can connect with mobile phone lines.

5. 音乐键：短按播放音乐，再短按切换下一首，长按可调节加音量
Music Button: Press shorter---Music, Press Shorter again---next track;
6. 外接喇叭：短按播放喇叭
Loudspeaker: Press shorter---Loudspeaker on
7. 外接音乐：短按播放音乐
Music: Press shorter--- Music on

二. 功能说明：Function Instruction

(通上电源 开机启动音时短按任何键都可打断启动音)

Power on, and press any button can disrupt auto startup engine sound.

开机启动音结束后 默认进入音乐模式：有音乐模式提示音 音乐是不会自动播放的.

After the auto startup engine sound, it will get into music mode: there will be one voice said"Music",the music will not be on automatically by itself.

8. 本设备蓝牙名称显示为：Bumper Car自动到蓝牙模式后、打开手机蓝牙开始搜索 出现 Bumper Car蓝牙名称时点击连接 连接成功会有提示音

Bluetooth Display Name on this devise: Bumper Car

When auto switch to Bluetooth mode, turn on the bluetooth on mobile and start to search and connect with Bumper Car . There will be remind voice when connection successful.

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help important announcement

Important Note:

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Country Code selection feature to be disabled for products marketed to the US/Canada.

This device is intended only for OEM integrators under the following conditions:

1. The antenna must be installed such that 20 cm is maintained between the antenna and users, and
2. The transmitter module may not be co-located with any other transmitter or antenna,

As long as the conditions above are met, further transmitter testing will not be required. However, the OEM integrator is still responsible for testing their end-product for any additional compliance requirements required with this module installed.

Important Note:

In the event that these conditions cannot be met (for example certain laptop configurations or co-location with another transmitter), then the FCC authorization is no longer considered valid and the FCC ID cannot be used on the final product. In these circumstances, the OEM integrator will be responsible for re-evaluating the end product (including the transmitter) and obtaining a separate FCC authorization.

End Product Labeling

The final end product must be labeled in a visible area with the following" Contains FCC ID: **2AVDK-HY1898BT**"

Manual Information to the End User

The OEM integrator has to be aware not to provide information to the end user regarding how to install or remove this RF module in the user's manual of the end product which integrates this module.

The end user manual shall include all required regulatory information/warning as show in this manual.

Integration instructions for host product manufacturers according to KDB 996369 D03 OEM Manual v01

2.2 List of applicable FCC rules

CFR 47 FCC PART 15 SUBPART C has been investigated. It is applicable to the modular transmitter

2.3 Specific operational use conditions

This module is stand-alone modular. If the end product will involve the Multiple simultaneously transmitting condition or different operational conditions for a stand-alone modular transmitter in a host, host manufacturer have to consult with module manufacturer for the installation method in end system.

2.4 Limited module procedures

This module is Limited single modular without shielding, host manufacturer have to consult with module manufacturer for the module limiting conditions when integrate the module in the host. module manufacturer should reviews detailed test data or host designs prior to giving the host manufacturer approval.

2.5 Trace antenna designs

Not applicable

2.6 RF exposure considerations

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

2.7 Antennas

This radio transmitter **2AVDK-HY1898BT** has been approved by Federal Communications Commission to operate with the antenna types listed below, with the maximum permissible gain indicated. Antenna types not included in this list that have a gain greater than the maximum gain indicated for any type listed are strictly prohibited for use with this device.

Antenna No.	Model No. of antenna:	Type of antenna:	Gain of the antenna (Max.)	Frequency range:
Bluetooth	/	PCB Antenna	2.0dBi for 2402-2480MHz;	

2.8 Label and compliance information

The final end product must be labeled in a visible area with the following" Contains FCC ID: **2AVDK-HY1898BT** ".

2.9 Information on test modes and additional testing requirements

Host manufacturer which install this modular with single modular approval should perform the test of radiated emission and spurious emission according to FCC part 15C:15.247 and 15.209 requirement, only if the test result comply with FCC part 15.247and 15.209 requirement, then the host can be sold legally.

2.10 Additional testing, Part 15 Subpart B disclaimer

Host manufacturer is responsible for compliance of the host system with module installed with all other applicable requirements for the system such as Part 15 B.