

尺寸：70x95mm 四折五面 正反面单色印刷 风琴折页

## Instruction Manual



**3 in 1**  
MAGNETIC WIRELESS CHARGING STATION


### Product Description

Magnetic Induction Area

Non-Slip Silicone Tread

Induction Area

Led Indicator




Watch Induction Area

Heat Dissipation


Non-Slip Silicone Tread

Type C Port



### Technical Specification

Name: 3 In 1 Magnetic Wireless Charging Station  
executive standard: Qi conversion rate:  $\leq 80\%$   
Input: 5V  $\approx$  3A , 9V  $\approx$  3A Output2(Front): 15W/10W/7.5W/5W  
Output1(Top): 2.5W Output3(Back) : 5W  
Size: 82mm(L)\*111mm(W)\*110mm(H)



### Method of use

- 1 . Indicator starts flashing while connecting with power, then indicator off , charger enter into standby mode.
- 2 . Put closer to magnetic induction area, iPhone 12 and Magsafe case will be attracted and auto-aligned to the induction position. Middle Indicator on, charger enter into charging mode.
- 3 . Put Smart Watch close to the induction area, auto-aligned to the induction position. Right indicator on, charger enter into charging mode.
- 4 . Put Qi enable device onto the induction area, left indicator on, charger enter into charging mode.
- 5 . Remove devices from the charger, indicator off, charger enter into standby mode
- 6 . Indicator start flashing or Charger automatically turned off when exceptional occurs.

### Safety Notice

- 1 . Do not pull the power cord hard to avoid the power cord from breaking or falling off.
- 2 . Do not disassemble by yourself or throw it into fire or water to avoid short circuit and leakage.
- 3 . Do not use in severely high temperature, humidity or corrosive environments to avoid leakage of electricity due to damage to the circuit.

### Frequently Asked Questions

- 1 . Charging is slow. The mobile phone itself or the external receiving coil allows the wireless charging current to be different, or the application running consumes a lot of

- power when the mobile phone is charging. It is recommended to reduce or close the application.
- 2 . The phone is charging intermittently, and the indicator light flashes. If the charging current is not enough, please use a charging head (adapter) with sufficient power 9V/1.67A or above QC2.0.
  - 3 . Charging fever. It is normal for the receiving coil or transmitter board to generate heat during wireless charging. It is recommended to adjust the charging position.
  - 4 . The charger does not work. Do not put metal debris or magnetic cards on the charging area. If the product does not work due to overheating, please take off the phone and wait for it to cool down and try charging again.
  - 5 . The host indicator is normal, but the mobile phone cannot work. The mobile phone receiving coil is faulty or the charging position is not aligned. It is recommended to replace the receiving coil or repair the mobile phone.
  - 6 . The indicator light of the host is not bright. If the host fails, contact after-sales maintenance.

### FCC Warning statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) this device must accept any interference received, including interference that may cause undesired operation.  
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:- Reorient or relocate the receiving antenna.  
- Increase the separation between the equipment and receiver.  
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
- Consult the dealer or an experienced radio/TV technician for help. FCC RF exposure statement: This equipment complies with FCC Radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the product and your body.

