





1. Wireless charging function: Put the digital product that supports wireless charging function in the wireless charging gasket, and light the charging indicator, compatible with 10W/ 7.5w /5W specifications. Turn on/adjust brightness/turn off the light: After you touch the metal touch ring with your finger, it will turn on the light/brightness mid-grade brightness /

high-grade brightness /turn off the light and cycle accordingly.

3. Bluetooth Speaker: Turn on Bluetooth of mobile phone, connect the name of Bluetooth device of "XS-F11", and there will be prompt sound if it is connected successfully.

" ()": Hold it to turn on/off the machine; and there will be corresponding prompt sound at the same time.

" +/ \triangleright ":Hold it to play the next song; Click it to enter the volume+

"-/44" :Hold it to play the previous song; Click it to enter volume- till no voice.

" || • ": Music play/pause key.

Note: Power supply should be connected to each function of the product.)

Bluetooth name	XS-F11	Working voltage	DC12V/2A
Material	Aluminium + ABS + PVC +SIL	Max power	22W
Bluetooth output	Double track 5W	Bluetooth distortion rate	≼ 10%
Luminous flux	300 ± 10%lm	Temperature	3800-4200K
Net Weigh	500g	Product size	22*8.2*21cm
Output frequency of W.C.	FCC:115-205KHz CE:110-148KHz	Charging distance	<6mm
Output voltage of	10W:DC9V/1.1A 7.5W:DC7.5V/1A 5W:DC5V/1A		

FAQ				
Lamp not light	The power socket is not energized	Check the plug		
Light flashing	Loose connecyion between DC plug and DC socket	Check whether the DC plug is properly connected to the DC socket		
The phone's temperature is high during wireless charging	Mobile phone and wireless charging stand are offset	Adjust the position of the mobile phone and the wireless charging stand to the center		
Interrupted during wireless charging	Over-temperature protection	Take the phone away, recharge it after 2-3 minutes or larve it alone with out any action, the phone will automatically recharge after the temperature drops.		

uding the above reasons, the desk lamp still does not light up or flickers. Please do not open the shell to repair it by yourself. Professional maintenand onnel are required to repair i

FCC Warning This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

FCC RF exposure statement:

-Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance between 20cm the radiator your body.