


# onn.™

## Bluetooth® Boombox



### User Manual

#### DEAR CUSTOMER

Congratulations on your purchase!  
Please read this manual carefully and keep it for future reference

#### Specification:

- \*Frequency Response:85Hz-20KHz
- \*S/N Ratio:≥62dB
- \*Output Power:2.5W\*2(RMS)
- \*Speaker:3"\*2

#### Inside Package:

Speaker	1pc
Aux Cable	1pc
Charging line	1pc
User Manual	1pc

#### Caution:


1. Do not expose to dripping or splashing.
2. Do not place any objects filled with water over the apparatus.
3. Do not block the ventilation holes.
4. When using high output signal don't turn the volume to maximum to avoid distortion.

#### How to use the Bluetooth:

1. Select the audio input to Bluetooth status
2. Search Bluetooth device with name "ENKOR ET15"
3. Connect the Bluetooth
4. If your Bluetooth device below 2.0 version, input password "0000" when connecting.

NO.1


#### Front panel




- M**-----Short press will input function key, switch among AUX/FM/Bluetooth mode; Long press will power switch.
- ◀**----- Previous song when Bluetooth input; Short press will previous channel when radio input; Long press will search forward for the previous channel when radio input.
- ▶**----- Short press will Play/Pause song when AUX/Bluetooth input; Long press will disconnect connected devices and quickly pair when Bluetooth input; Long press will automatically search and save radio station when radio input.
- ▶▶**----- Short press will next song when Bluetooth input; Long press will TWS pairing when Bluetooth input; Short press will next channel when radio input; Long press will search backward for the next channel when radio input.
- ◀-**-----Volume down.
- ◀+**-----Volume up.

NO.2

#### What mean of the light




- \* Blue light means Bluetooth mode(The light flashing is in Bluetooth pairing status)
- \* Red light means AUX/FM mode(The light flashes during automatic channel search)
- \* Red light breathing means low power



- \* Red light means charging
- \* Green light means full charge

NO.3

#### System connection diagram



#### NOTE:

- \* Do not leave objects generating magnetism near the speakers.

NO.4

#### Timing alarm

##### How to use the alarm

- \*Enter the aux mode, long press this key(▶▶) to set the timing mode. ( the red light flashes)
  - \*In the timing mode, short press this key(▶▶) to select timed alarm. (1 hour, 2, 3... 4 hours)
  - \*Alarm setting confirmation: long press this key(▶▶) to confirm completion and exit.(The red light stops flashing and becomes normally on )
  - \*When the alarm clock rings, press any key to stop the alarm
- Note: the timing alarm is a one-time setting and does not repeat.  
If it is turned off, the timing alarm will be automatically cancelled

NO.5

**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.