
Wireless **Earbuds**



Included

- Wireless Earbuds
- · Micro USB Charging Cable

- Power ON using ON/OFF switch.
- Rapid flashing white light, followed by a chime
- Use Bluetooth settings on your phone to pair with HEYDAY EARBUD 01
- Slow flashing white light pairing successful

Indicators

- Red/White Alternating Bluetooth pairing
- Slow Flashing White Paired
- Slow Flashing Red Battery low
- Red Charging
- White Charging complete · Ascending Tones - Powering on
- · Descending Tones Powering off
- · Three Rapid Tones Ready to pair
- · Two Rapid High Tones Paired
- Two Rapid Low Tones Low battery · Two Ascending Tones - Max. Volume
- · Two Descending Tones Min. Volume

- Phone call function Press the ON/OFF switch to answer the incoming call, press the ON/OFF switch again to hang up after the call
- Press the + button to increase the volume

Press the - button to decrease the volume

The music will pause when a call comes in and will resume playing after the call has ended

4 in

Charging

- Full charge requires approximately 2-3 hours
 Charging is complete when solid white light turns on
 Plug micro end of charging cable into earbuds

Plug USB end of charging cable into a DC 5V USB power supply

- · If the earbuds are not working correctly, turn them on/off to reset
- · If the earbuds won't turn on, recharge the battery and try again
- \cdot If the earbuds won't charge, make sure the supply works, is 5V >1A, and not damaged
- · If the earbuds make no sound adjust the volume

Troubleshooting and tips

- · If the earbuds make no sound or do not show as an available device, make sure they are not paired to another device, if so, unpair the device and re-pair the desired device
- This device does not have a pairing code. If prompted for one make sure you are connecting to the correct device. If you are, "forget" the device and re-pair. If you are still prompted enter

The unit will power off after 2 minutes of no use.

Need some help?

Can't get it to pair? Have a guestion or comment?





call us at: 877-698-4883 or: 877-MyTgtTech

online at: TargetTechSupport.com

Safety

- · Do not use near any water source
- · Do not modify or repair this device
- Do not use in high temperatures or extreme weather
- Do not use chemical detergents to clean your device, use a soft dry cloth
 Keep 5-10 inches between microphone and mouth when using the phone call function

heyday @ 🕱

FCC ID: 2AVTM-TT2001 Model: TT2001 Input: 5V --- Max 1A Made in China

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment to an outlet on a circuit different from that to which the receiver is connected. . Consult the dealer or an experienced radio/TV technician for help. Target Corp.Mpls.MN,55403 Phone:1-612-304-6073

5.6 in