

Remote control manual

5 function keys of the remote control:

1. Main switch key: press short to switch the main switch on and off;
 - 1) Click on the light to turn on all lights
 - 2) Click turn off the lights and turn off all lights
2. Main lamp on key synthesis key:
 - 1) Main light: Click on/off the light
 - 2) Click when the light is on, and the light brightness is cyclically adjusted by 10%-30%-60%-80% to 100%
 - 3) Long press 1S to turn off the light
3. Main lamp color temperaturekey
 - 1) Power off (not on) state of main light: pressing is invalid
 - 2) State of main light on: press the cycle to switch the color temperature of 4 sections: 2700K-4000K-5000k-6200K
4. Comprehensive key of auxiliary light switch
 - 1) Auxiliary light: Click on/off the light
 - 2) Click when the light is on, and the light brightness is cyclically adjusted by 10%-30%-60%-80% to 100%
 - 3) Long press 1S to turn off the light
5. Color temperaturekey for the auxiliary lamp
 - 1) The auxiliary light is turned off (not on) : it is invalid to press
 - 2) Auxiliary light on: single press the cycle to switch 4 sections of color temperature value: 3000K-4000K-5000k-6200K

Remote indicator function

1. Charging status: the white light indicator light breathes and flashes (2 seconds/time), and the light is extinguished after being filled
2. Reminder of low power: When the battery is low, the red light flashes 10 times in a 1-second cycle for 2 seconds. After the operation, it enters the sleep state and the light goes out
3. After the remote control leaves the charging station, it will enter the sleep state and the indicator light will go out
4. When the remote control is pressed, the white light indicator lights up

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.