

# Microphone operating instructions

Start-up: Short press the transmitter intermediate power key and the receiver power key.

Shutdown: Press the transmitter intermediate power key and the receiver power key for 3 seconds.

This product has been paired by default when it leaves the factory. It can be used on boot. If multiple machines use serial frequency at the same time, just press the boot button of transmitter to change frequency.

One transmitter of this product can be used in pairs with up to 10 receivers at the same time.

In the case of replacement of transmitting or receiving equipment, it is necessary to re-pair. The operation instructions are as follows:

## 1Transmitter operation:

Press the boot button for 5 seconds, when the power indicator flashes once, then press the transmitter boot button once quickly, and when you see the power indicator flashing, you enter the matching mode.

## 2Receiver operation:

After the transmitter enters the matching mode, turn on the receiver, wait 2 seconds and press the transmitter's boot button 1 to complete the frequency matching. At this time, you can speak to the microphone to test the voice. If the matching is successful, the receiver will flash red light when speaking.

## Exit pairing:

The frequency can be automatically locked and matched by pressing the startup key of the transmitter.

USB cable: length 22 cm, Black

Frequency range: 560MHz-579MHz

Modulation mode: digital modulation

Signal to noise ratio: 96dB

Frequency response: 30Hz-18KHz

Antenna Type: Internal antenna

Antenna Gain:-3dBi

Distortion: <0.1%

Dynamic range: 96dB

Delay: 2.5ms

Frequency points: up to 48

Transmitter power: 10mW

Receiver sensitivity: -96dB

Use time of transmitter: 5 hours 3.7V 400mAh

Receiver service time: 5 hours 3.7V 400mAh

Charging time: 2 hours

Charging adapter: 5V 800mA

#### FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.