

## About the Guide

- This quick start guide is for reference only. Minor difference might be found in user interface.
- All the design and software here are subject to change without prior written notice.
- All trademarks and registered trademarks mentioned are the properties of their respective owners.
- Please visit our website or contact your local service engineer for more information.
- If there is any uncertainty or controversy, please refer to our final explanation.

### Step 4

Wait for booting to be finished, and then the camera indicator flashes with green light.

### Step 5


Do the following operations to finish adding camera.



- Note:**
- If you have more than one camera, do step 5 to add them one by one.
  - If the Wi-Fi network has changed or the indicator status goes wrong, reset the camera, and then do step 5 to add it again.

## Installing Camera

**Note:** Make sure that the mounting surface is strong enough to hold at least three times of the device weight.



- Step1** Drill screw holes on the mounting surface as the positioning map shows, and then put in the expansion bolts.
- Step2** Attach the pedestal to the mounting surface with the self-tapping screws.
- Step3** Power up the camera, and then adjust the lens to the ideal angle.

## FAQ

### ▶ Q: The device cannot work normally or start?

Check the LED indicator status. If the light is not in green, press and hold the reset button for 10 s to reset the camera.

### ▶ Q: How to connect the camera to a new Wi-Fi?

- If camera is online, select **Device > Network Config** to change the Wi-Fi connection.
- If camera is offline, reset the camera, and then configure the camera again.

### ▶ Q: Connection is overtime?

- Check the Wi-Fi configuration: Select the communication channel to auto, and the mode to 11bgn Mixed .
- Please put the camera and router, camera and smart phone within 5 m (16.4 ft) during the connecting period.

### ▶ Q: The device is offline?

Check the indicator status:

- If the green light is on, check whether the router can connect to the Internet. If Internet is working, restart the camera.
- If the red light flashes, reset the camera, and then configure the camera again.
- If the red light is on, it means the camera is faulty.

### ▶ Q: When the Micro SD card is full, how is the record video saved?

When the Micro SD card is full, the system will overwrite the previous recorded videos. Save the important information in time.

For more questions, please visit [www.imoulife.com/web/support/help](http://www.imoulife.com/web/support/help), or scan the QR code below.





# Quick Start Guide

Version 1.0.1

1.2.51.32.17044-000

## Packing List



Camera ×1



Positioning Map ×1



Power Adapter ×1



Screw Package ×1





QSG ×1



Waterproof Connector ×1

## Camera Introduction



The pattern of the LED indicator is included in the following table.

LED Indicator Status	Device Status
Off	<ul style="list-style-type: none"> <li>Powered off/LED turned off</li> <li>Rebooting after reset</li> </ul>
Red light on	<ul style="list-style-type: none"> <li>Booting</li> <li>Device malfunction</li> </ul>
Green light flashing	Waiting for network
Green light on	Operating properly
Red light flashing	Network connection failed
Green and red lights flashing alternately	Firmware updating

## Operating with Imou Life App

### Step 1

Scan the following QR code or search "Imou Life" in Google Play or App Store to download and install the app.

**Note:** If you have installed the app, update it to the latest version.



### Step 2

Run Imou Life App, and then register an account for the first use.

### Step 3

Connect the camera to power source with the power adapter.