




Restrict Band NVNT ac20 5500MHz Ant1 Peak




Restrict Band NVNT ac20 5500MHz Ant1 Average






Restrict Band NVNT ac20 5700MHz Ant1 Peak




Restrict Band NVNT ac20 5700MHz Ant1 Average






Restrict Band NVNT ac40 5510MHz Ant1 Peak



Restrict Band NVNT ac40 5510MHz Ant1 Average






Restrict Band NVNT ac40 5670MHz Ant1 Peak




Restrict Band NVNT ac40 5670MHz Ant1 Average






Restrict Band NVNT ax20 5500MHz Ant1 Peak




Restrict Band NVNT ax20 5500MHz Ant1 Average






Restrict Band NVNT ax20 5700MHz Ant1 Peak




Restrict Band NVNT ax20 5700MHz Ant1 Average






Restrict Band NVNT ax40 5510MHz Ant1 Peak




Restrict Band NVNT ax40 5510MHz Ant1 Average






Restrict Band NVNT ax40 5670MHz Ant1 Peak



Restrict Band NVNT ax40 5670MHz Ant1 Average





F.5 Frequency Stability

Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NVNT	a	5500	Ant1	5500	0	0	25	Pass
NVNT	a	5580	Ant1	5579.98	-20000	-3.58	25	Pass
NVNT	a	5700	Ant1	5699.98	-20000	-3.51	25	Pass
NVNT	n20	5500	Ant1	5499.98	-20000	-3.64	25	Pass
NVNT	n20	5580	Ant1	5579.98	-20000	-3.58	25	Pass
NVNT	n20	5700	Ant1	5700	0	0	25	Pass
NVNT	n40	5510	Ant1	5510	0	0	25	Pass
NVNT	n40	5550	Ant1	5549.96	-40000	-7.21	25	Pass
NVNT	n40	5670	Ant1	5670	0	0	25	Pass
NVNT	ac20	5500	Ant1	5499.98	-20000	-3.64	25	Pass
NVNT	ac20	5580	Ant1	5579.98	-20000	-3.58	25	Pass
NVNT	ac20	5700	Ant1	5699.98	-20000	-3.51	25	Pass
NVNT	ac40	5510	Ant1	5510	0	0	25	Pass
NVNT	ac40	5550	Ant1	5550	0	0	25	Pass
NVNT	ac40	5670	Ant1	5670	0	0	25	Pass
NVNT	ax20	5500	Ant1	5500	0	0	25	Pass
NVNT	ax20	5580	Ant1	5579.98	-20000	-3.58	25	Pass
NVNT	ax20	5700	Ant1	5699.98	-20000	-3.51	25	Pass
NVNT	ax40	5510	Ant1	5510	0	0	25	Pass
NVNT	ax40	5550	Ant1	5550	0	0	25	Pass
NVNT	ax40	5670	Ant1	5670	0	0	25	Pass




Shenzhen LCS Compliance Testing Laboratory Ltd.
 Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China
 Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com
 Scan code to check authenticity




Test Graphs

Freq. Stability NVNT a 5500MHz Ant1




Freq. Stability NVNT a 5580MHz Ant1






Freq. Stability NVNT a 5700MHz Ant1




Freq. Stability NVNT n20 5500MHz Ant1






Freq. Stability NVNT n20 5580MHz Ant1




Freq. Stability NVNT n20 5700MHz Ant1






Freq. Stability NVNT n40 5510MHz Ant1




Freq. Stability NVNT n40 5550MHz Ant1






Freq. Stability NVNT n40 5670MHz Ant1




Freq. Stability NVNT ac20 5500MHz Ant1






Freq. Stability NVNT ac20 5580MHz Ant1




Freq. Stability NVNT ac20 5700MHz Ant1






Freq. Stability NVNT ac40 5510MHz Ant1




Freq. Stability NVNT ac40 5550MHz Ant1






Freq. Stability NVNT ac40 5670MHz Ant1




Freq. Stability NVNT ax20 5500MHz Ant1






Freq. Stability NVNT ax20 5580MHz Ant1




Freq. Stability NVNT ax20 5700MHz Ant1






Freq. Stability NVNT ax40 5510MHz Ant1




Freq. Stability NVNT ax40 5550MHz Ant1





Freq. Stability NVNT ax40 5670MHz Ant1





F.6 Duty Cycle

Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5500	Ant1	94.56	0.24	0.91
NVNT	a	5580	Ant1	94.65	0.24	0.91
NVNT	a	5700	Ant1	94.56	0.24	0.91
NVNT	n20	5500	Ant1	93.77	0.28	1.07
NVNT	n20	5580	Ant1	93.67	0.28	1.07
NVNT	n20	5700	Ant1	93.77	0.28	1.07
NVNT	n40	5510	Ant1	97.23	0.12	0.46
NVNT	n40	5550	Ant1	97.23	0.12	0.46
NVNT	n40	5670	Ant1	97.18	0.12	0.46
NVNT	ac20	5500	Ant1	93.72	0.28	1.06
NVNT	ac20	5580	Ant1	93.82	0.28	1.06
NVNT	ac20	5700	Ant1	93.72	0.28	1.06
NVNT	ac40	5510	Ant1	97.24	0.12	0.46
NVNT	ac40	5550	Ant1	97.19	0.12	0.46
NVNT	ac40	5670	Ant1	97.19	0.12	0.46
NVNT	ax20	5500	Ant1	93.82	0.28	1.06
NVNT	ax20	5580	Ant1	93.82	0.28	1.06
NVNT	ax20	5700	Ant1	93.72	0.28	1.06
NVNT	ax40	5510	Ant1	97.24	0.12	0.46
NVNT	ax40	5550	Ant1	97.19	0.12	0.46
NVNT	ax40	5670	Ant1	97.24	0.12	0.46




Shenzhen LCS Compliance Testing Laboratory Ltd.
 Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China
 Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com
 Scan code to check authenticity




Test Graphs

Duty Cycle NVNT a 5500MHz Ant1




Duty Cycle NVNT a 5580MHz Ant1






Duty Cycle NVNT a 5700MHz Ant1




Duty Cycle NVNT n20 5500MHz Ant1






Duty Cycle NVNT n20 5580MHz Ant1




Duty Cycle NVNT n20 5700MHz Ant1






Duty Cycle NVNT n40 5510MHz Ant1




Duty Cycle NVNT n40 5550MHz Ant1






Duty Cycle NVNT n40 5670MHz Ant1




Duty Cycle NVNT ac20 5500MHz Ant1






Duty Cycle NVNT ac20 5580MHz Ant1




Duty Cycle NVNT ac20 5700MHz Ant1






Duty Cycle NVNT ac40 5510MHz Ant1




Duty Cycle NVNT ac40 5550MHz Ant1






Duty Cycle NVNT ac40 5670MHz Ant1




Duty Cycle NVNT ax20 5500MHz Ant1






Duty Cycle NVNT ax20 5580MHz Ant1




Duty Cycle NVNT ax20 5700MHz Ant1






Duty Cycle NVNT ax40 5510MHz Ant1



Duty Cycle NVNT ax40 5550MHz Ant1





Duty Cycle NVNT ax40 5670MHz Ant1

