

# wireless charger

## Security Information

To prevent personal injury or injury to other people or damage to your device, read the product's safety information. Do not use the machine for a while if the machine overheats.

- Do not store the device near or on heaters, microwaves, cooking appliances or high-pressure containers, as the device may overheat and cause a fire. Do not drop or hit the loader or device. If your device falls, it may be damaged.

If children use the appliance, make sure that they use it correctly.

The device should be dry.

Moisture and liquid can damage the parts or the electronic systems of the device.

If your device is wet, dry it with a towel and take it to a service center.

Do not disassemble, modify or repair the device.

Your device may not work properly, which increases the risk of electric shock.

- Any changes or modifications to the device may void the warranty producer's.

Do not place too close to a magnetic strip or chip card to avoid magnetic damage.

- Keep a minimum distance of 20 cm between implanted devices

medical devices and the wireless charger to avoid potential interference with the medical device.

Working ambient temperature: 0-50 °C.

If the device requires repair, take it to the Service Center.

To completely switch off the appliance, pull out the plug.

## FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## Connection to power supply

1. Connect the adapter to the socket.

2. Connect the adapter to the USB 2.0 interface and the other micro USB connector to the wireless charger.

Power on the green indicator light for 4 seconds, 4 seconds after the light is off

Put the wireless charger phone up, the green light is always on

Indicator light flashes during foreign object detection

Product packaging contains: wireless loader, charging cable, operating instructions.

\* The AC adapter is not included, please buy separately or Use an original mobile phone adapter if necessary.



## Technical data

Input: 5V/2.0A 9V/2.0A 12V/1.5A

Output: 5V/1.0A 9V/1.12A 9V/1.67A

Loading efficiency: over 75% Loading distance: <8mm Frequency: 110-205KHz

Wireless charging power: 15W

**FCC Warning Statement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.