



Quick Start Guide

Power On/Off


To start, turn on your Lume Pad (203) by pressing and holding the Power Button for a few seconds. Then follow the onscreen instructions.

Turn the Power On/Off


- **On:** press and hold the Power Button for a few seconds.
- **Off:** press and hold the Power Button for a few seconds. Then follow the onscreen instructions.

Turn the Screen On/Off

To turn the screen on and off while the tablet's turned on, press the Power Button once.



Bottom Navigation Bar



Overview - Front & Side


To start, turn on your Lume Pad (203) by pressing and holding the Power Button for a few seconds. Then follow the onscreen instructions.

User Manual

Read the user manual before using your Lume Pad. View it directly on your Lume Pad (Settings > About tablet > Learn more) or go to www.leiainc.com/manual

Intellectual Property

Leia Lume Pad and other Leia products are covered by patents, trademarks, design rights, and copyrights. More details at www.leiainc.com/legal/patents



Welcome to LUME PAD

To start, turn on your Lume Pad (203) by pressing and holding the Power Button for a few seconds. Then follow the onscreen instructions.

Leia Inc.

Leia Inc. is a registered trademark of Leia Inc. All rights reserved. Leia Inc. is a California company.

Leia Inc.

Leia Lume Pad and other Leia products are covered by patents, trademarks, design rights, and copyrights. More details at www.leiainc.com/legal/patents

Learn more about your Lume Pad at www.leiainc.com



FCC Statement

Changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to following two conditions (1) this device does not cause harmful interference. (2) this device must accept any interference received, including interference that may cause undesired operation.

SAR Information Statement

Your LUME PAD is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR.

The SAR limit set by the FCC is 1.6 W/kg. * Tests for SAR are conducted with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest

certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for safe exposure. These tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this LUME PAD when tested for use worn on the body, is 0.84 W/kg (Body-worn).

Measurements differ among LUME PAD models, depending upon available accessories and FCC requirements. While the FCC requires that the SAR level of a phone be determined at the highest power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for safe exposure. These tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this LUME PAD when tested for use worn on the body, is 0.84 W/kg (Body-worn).