

Wireless outdoor solar security camera

User Manual



V2.2

Table of Contents

| | |
|---|--------------|
| Part 1: Before Installation..... | 1-3 |
| Part 2: In-App Setup..... | 4-11 |
| Part 3: Physical Installation | 12-13 |
| Part 4: Technical Specifications | 14 |
| Part 5: Detailed App Instructions..... | 15-22 |
| Part 6: How to save and delete videos..... | 23 |
| Part 7: FAQs..... | 24 |




Before Installation

Warm tips before you go:

1. Solar camera can only be set up with 2.4g Wi-Fi network. (It's ok to use Cell phone 4G data to live viewing it after the camera was set up with 2.4g Wi-Fi network firstly.)
2. You may possibly need a Wi-Fi extender if your Wi-Fi signal is weak around the yard where you want to install it.
3. Please format the micro sd card to FAT32 format and install the card when camera powered off.(Micro sd card is not provided in the package)
4. Please connect the solar panel to camera and then charge the camera by connect the USB port in the solar panel or the camera. it usually takes up to 10-12 hours to fully charge it.
5. Make sure the distance between your phone,router and the camera is no more than 1.5 feet when you're ready to pair the camera. Ensure that the Wi-fi signal strength on your phone is good.
6. The PIR range is 16 feet around,the recommend camera install height is 8 feet around.To avoid too much false alarms, we suggest you do not install the camera with nearby bushes,shrubs, grasses and tree leaves coming into the PIR range.
7. If you install the camera on stucco,brick or concrete surface,please mark 4 holes matching the bracket and then use a drill driver to drill into the wall and insert the expansion screws to hold the camera tightly


Before Installation

Product Diagram




Before Installation

Package Content




1* Solar panel




1*Screw kit

- 1*Hexagon spanner
- 1*Screw driver
- 8*Screws
- 4*Tapping screw
- 1* USB charging cable



1* PTZ Camera



1*User manual



1*Position paper

In-App Setup

Make sure the distance between your phone,router and the camera is no more than 1.5 feet when you're ready to pair the camera.Ensure that the Wi-fi signal strength on your phone is good.

1. Download the App (works only with iOS & Android devices)

Please locate the “Ubox” in your Google Play store or App store to download the Ubox App.



IOS





Android

2. Register an account

Open the App, click “register” and then input your email, the app will send an email with verification code in a few minutes. Go to your email to get the code and input it to verification.

Set a password for your account.


Please note: Verify code mail may be classified as spam by the mailbox, Please check out the spam box.



In-App Setup

3. Set up the installed location

Input the installed location
Click "Add family" and then input the name of house, click "next step" and then input required information, and then click "finished" to save it.



4. Pairing the camera with the App

Turn on the camera: switch the power button to up to turn on the camera, Then you will hear the following voice " The camera is now ready to begin pairing".




In-App Setup

Please connect your phone to the 2.4Ghz wifi firstly before you pair the camera, make sure your router password in mind before you start the pairing process.

- 1) Click "Add a device" and then choose "Setup device", click "Yes", when you hear the following voice " The camera is now ready to begin pairing".



- 2) Input the CORRECT WiFi password of your router, if you input a wrong password you will not be able to connect successfully. Click the eye icon to double confirm the password you entered correct



In-App Setup


Method 1: QR code configuration

1.1 Click the "QR code configuration", hold the QR code in front of the Solar camera, and then you will hear the following: "Pairing Information Received".




Method 2: Sound wave configuration

2.1 Enter into the "search device" page, make sure to turn up you phone's volume to the Maximum, you will hear the following voice: "Pairing Information Received".



In-App Setup

- 3) You have connected the device to the App successfully. Choose a name of the devices from the drop-down choice, or you can modify one that you want. and then select the area where device is located.(you have to choose one or you cannot connect the camera to the app)



- 4) Congratulations! Now you can live view the camera on your phone anytime and anywhere.



If you're unable to pair the camera, Please check below suggestions:

1. Please reset the camera to reset the camera to default after you fully charged the camera.
2. Please turn up your phone volume to the maximum, since the camera pair through sound wave.
3. Please put the camera, phone as near as to your router (within 1.5 feet) to get a strong wifi signal strength.
4. Please click on the eye icon when you input your router wifi password to make sure your wifi password CORRECT.
5. Please make sure your router setting is DHCP enabled, otherwise your router will not send out WiFi signal for any wireless device for pairing up.

In-App Setup


➤ Push Mode

This icon indicate that the push mode is on, click it to turn off push mode and then you cannot receive any notifications.









➤ Cloud storage

The video clips will save in the Cloud. Cloud video length is 8 seconds defaulted and free for 30 days. And you have to pay for the service per month or other cloud service.



How to Share Your Camera with More Users

When you can use your camera properly..You can start to share your camera to your friends or family members.click “⚙️”and choose “share permissins”,input the account that you want to share with.Choose a permissions from Administor,family member, Vistor,Customize





You can Customize the permissions and turn on or off every permission as you wish by clicking the blue icon”permissions”

How to unbind your camera


Please do not forget to unbind your camera from your app when your plan to return the camera, to avoid any personal information disclosure risk.

And unbind your camera as following steps. click “” and then choose ‘delete’




Physical Installation

1 Check your camera signal strength




2 Recommended height to install the camera

We suggest installing the camera about 8ft. You may adjust the camera angle physically according to the live view in your mobile. to focus your motion area to get the more accurate motion triggered events.




If your camera get numerous motion alerts unexpected

- 1) Please adjust your camera installation angle a bit down to focus the motion area.
- 2) Please change your PIR sensitivity to Low to reduce the PIR sensitivity.
- 3) Do not install the camera with nearby bushes, shrubs, grasses and tree leaves coming into the PIR range.



Physical Installation

- 4 Adjust the bracket on the wall and then mark 3 holes for mounting. Fix the bracket to the wall by expansion screws.





Technical Specifications

| | | |
|-------------------------------|----------------------------------|------------------------------|
| Image Quality | Resolution | 1080P |
| Specifications Lens | Lens angle | FOV 160° |
| Video Specifications | Video format | H.264 |
| | Frames per second | 15fps |
| | SD card support | 8GB-Max 64GB |
| Audio | Output | Built-in speaker |
| | Input | Built-in microphone |
| Communications | WiFi | 2.4GHz |
| Battery | Battery capacity | 4000mAh |
| | Standby time | Max 6 months |
| | Power consumption | 2W(run)/ 0.012W (standby) |
| Applicable Environment | Temperature | -20°C~+60°C(-4°F-140°F) |
| | Humidity | 20%~85% (Non-condensing) |
| System Support | Android 2.3 above/ iOS 7.0 above | |
| PIR | PIR angle | 110° |
| | PIR range | 16ft |
| Night Vision | Range | Up to 32ft |

Detailed App Instructions

1.click ,you could live viewing videos.



Detailed App Instructions

Battery charging sign



When camera exposed to sunlight,the battery will keep charging in green.



During night or fully charged,the battery will stay white.

Tips : If your battery sign will not show correct status as above,please remove the solar panel and then re install it to the camera body.




Low power indicator,please recharge the camera manually using the provided USB cable

Wifi signal strength

Tips: Please make sure your camera has a full bar of wifi strength to ensure a smooth live view speed. (A wifi extender is recommended to install beside the camera if needed)

Click here to chose the resolution to HD(1080P) OR SD(720P)




Number of users

Tips: If you have invited a second users to visit your camera.Please pay attention to below points:

- 1.Your camera password can be seen by the invited users,but it can not be modified.
- 2.The invited users can change all the camera settings,so the camera will work as per the last change made on the settings among all users.
- 3.If your camera does not work as you set before,please check the settings from the invited users' device.

Detailed App Instructions



Setting: Click  to enter into device settings. (Check page 19 for more details)

Two-way Talk: Click  to speak to visitors and hear what they say.

Manual Recording: Click  to manually record and the videos will be saved to your phone's Album

Cloud storage: Click  to playback videos saved in cloud storage.

Screenshot: Click  to screen capture and pictures will be saved to your phone's album.

Voice: Click  to mute the sounds from the camera.

Detailed App Instructions

SD Card Setting

- 1) Please turn on the cloud storage so that you can sync the camera time with your phone.
- 2) Please format the micro sd card before you installed it. The camera doesn't support plug and play. So please make sure to power off the camera and then install your card.





Image flip


You can choose Normal Rotate, Mirror or Mirror and rotate depends on your hardware installation way. The default is Normal.



Detailed App Instructions

Scene mode

You can choose to set it as Normal, back light compensation, night IR, High light compensation or Dynamic according to your actual light environment of installation place.




PIR Detection

You can set the PIR sensitivity as Disabled, Low, Medium and High.


- 1) When you set the PIR as Disabled, you will not record and receive any motion triggered events.
- 2) It is recommended to set the PIR Detection to High so that you could capture as more as a motion triggered from the beginning part of the event.
- 3) Try to capture more the beginning of the triggered event, please adjust your camera angle a bit closer to your aimed spot (Check page 13 diagram).

Detailed App Instructions



Active time


- 1) This is the time you could set for the video length recorded to micro sd card.
- 2) Always: If you choose this option, you will not allow the camera enter into standby mode, the camera will keep recording all the time until battery drains out. (60 seconds per file)



Detailed App Instructions


LED indicator

When you choose Enable, the Blue LED will light up to indicate when you operate the camera as it should be. When you choose Disabled, the Blue LED will not light up to indicate the operations or trigger motions. It is recommended to set it as the default



Power frequency


Please choose 60 or 50HZ according to your local frequency, It's defaulted to 60HZ for united states users.



Detailed App Instructions

Device Name

You can set a desired name for your camera.



How to save and delete videos

1. Videos can be saved in Cloud Storage:

(1). The videos of PIR activity


You could save the videos of PIR activities in cloud storage, which can be used 30 days for free and then you have to pay for the services. and playback in the app.

2. Videos can be saved in the SD card:

(1). The videos of PIR activity

(2). The videos of live viewing

You could playback these videos on the timeline in the App and format the SD card in the App.



3. Videos can be saved on the mobile phone album:

(1). The videos of REC mode

(2). The screenshot

You need to delete the videos of REC mode and the screenshots from your phone's album.

FAQs

Q1: Why do I fail to connect the camera to the App by sound wave?

- A:
1. Please reset the camera by the pin included.
 2. Please make sure the camera is powered on and there will be voice prompts that indicates it.
 3. Make sure the distance between your mobile phone and the device is no more than 30cm. And your mobile, camera and router are in the same room.
 4. Adjust your phone volume to maximum.
 5. Double check your WiFi password and make sure it is correct.

Q2: When In-App setup is done, why I could not see the live streams on my mobile?

- A:
- First, check in App to confirm the wifi signal is strong enough. If not,we would suggest adding wifi extender in between.

Q3: Why I cannot receive any alarm after I finished connecting the camera with the App ?

- A:
1. Click the  in App to confirm you have turned on the push mode.
 2. Check your mobile settings to allow the notification.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.