


SIZE:159*100MM(折后79.5*100MM)

材质:70G 黑白书纸

front



Product overview :

- 1.Type-C input port
- 2.LED Battery power indicator light
- 3.Touch button of the left earbud
- 4.Left earbud indicator
- 5.Left earbud
- 6.Right earbud
- 7.Right earbud indicator
- 8.Touch button of the right earbud

Specifications:

- Touch Button
- Wireless V5.0
- Battery capacity: 25mAh*2 & 300mAh
- Type-C Input: 5V-0.2A
- Total Play Time(75% volume): 10h
- Size: 50*50*26(mm)
- Material: Recycled ABS & Recycled PU

Accessory:

- Manual
- 30CM USB-A to Type-C Recycled TPE Charging cable

Operating Instructions:

- Power On: long press the touch button (3) or (8) for 3 seconds or take out from the charging bin.
- Power Off: long press the touch button (3) or (8) for 5 seconds or put it back into the charging bin.
- Automatic pairing of earbuds: the left and right earbuds are automatically paired after being turned on.
- Pairing the earbuds with the mobile phone: the left and right earbuds is already paired and pick it up from the charging bin for normal use. For the first use, click "Pairing" once the pairing name in the wireless search interface of the phone or device setting. Subsequent times the product will automatically connect.
- Pause: Click the touch button of the left/right earbud (3) or (8)
- When calling: Answer/hang up: Click the touch button of the left/right earbud (3) or (8) ; Reject incoming call: long press the touch button of the left ear/right earphone for 2 seconds;
- Last track: Double click on the touch button of the left ear earbud (3)
- Next track: Double click on the touch button of the right earbud (8)
- Volume +: three clicks on the touch button of the right earbud (8)
- Volume -: three clicks on the touch button of the left earbud (3)
- Activate SIRI: long press the touch button (3) or (8) for 3 seconds
- Earbud charging: Put the earbud into the charging case. The light will turn red, indicating that it is charging.
- To charge the case: connect the DC5V adapter with the USB terminal of the cable and insert the other end into the Type-C input port (1). The LED Battery power indicator red flashing when charging.

Note:

- Do not drop, apply excessive force to the controls, or put heavy objects on top of the Charging case and earbuds.

back

- Do not attempt to repair, disassemble or modify the product. There are no user-serviceable parts inside this unit.
- If you do not use the earbuds for long periods of time, be sure to store it on the dry charging case, free from extreme temperature, humidity and duct.
- Keep speaker away from any heat source.
- This is not a toy, not suitable for children under the age of 7.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Origaudio
2024 FortyFour Group LLC; d/b/a Origaudio
Made in China
FCC ID:2AWVU-X9832001010
Lot #23331