

## **Transmitter**

1. Fix the transmitter.
2. Connect the power supply DC5V and the power indicator turns on.
3. Adjust the distance to display 100-990 feet in the screen.
4. Cut off power supply when it is not in use, turn on power supply for using it.
5. It won't cause electric shock to the dog if the power is cut off.

## **Transmitting function**

Set the distance you need.

1. If your dog exceeds the set distance, it vibrates for 3-5 seconds, and then electric shock for 3-5 seconds. It works for 2 cycles, and then vibrates to remind the dog to return to the set distance. It enables the cycle automatically to ensure that the dog does not run out.
2. It is equipped with 14 flags for marking the distance.

## **Cautions**

1. When the transmitter is installed outdoors, the above

parameters are unchanged.

2. When the transmitter is installed indoors, the distance is approximately half, and the flag is required for marking the distance.
3. At the turn with corner of 90 degrees, the distance shall be adjusted by you via the flag.

## **Receiver**

### **Use of the receiver**

1. Press once to start the device and the indicator turns on.
2. When it is not in use, press it once to shut down and the indicator turns off.
3. For charging the receiver, connect it with DC5V power supply and the indicator flashes quickly. After charging full, the indicator keeps on.
4. Under low power state, the indicator flashes slowly.

### **Use of test indicator**

When the test indicator is on, it indicates an electric shock.

When you need to change the electric shock rod, as shown in the figure, push the test indicator counterclockwise to remove the electric shock rod. When pushing clockwise, you can lock the electric shock rod.

A transmitter can match with multiple receiver.

The fence adopts 433MHz frequency with strong signal, long transmission distance, strong penetration and diffraction ability

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction