

# KAP70600

## Wireless Charger Quick starting guide



[www.kapsys.com](http://www.kapsys.com)

## Note

It is suggested to read the full user guide before using your K A P 7 0 6 0 0 Wireless Charger. An electronic version of this document is available on our website at [www.kapsys.com](http://www.kapsys.com) under the Support section.


## Box content

A Wireless Charger for SmartVision3 Smartphone

A USB cable (C type)

A Quick starting guide

## Overview



N°	Item	Description
1	Wireless charging cradle	Wireless Charging location
2	USB C type connector	Power supply

## Getting started

1. Connect one end of USB cable on the Wireless Charger (Type C) and connect the other end on a USB DC power supply (5 Volts).
2. The wireless charger works with most slim protective cases (less than 3mm thick). If the case is heavy duty, made of metal, or your case doubles as a wallet and holds metal cards, charging may not properly function and the case would need to be removed.
3. The SmartVision3 should have the screen facing up.
4. Place the SmartVision3 on Wireless Charger Cradle.
5. The smartphone should be lined up length-wise on top of the wireless charger as is illustrated below. If the orientation is perpendicular, or misaligned, charging will not occur.
6. The operating system on your SmartVision3 will provide audio confirmation, when charging has begun.

## Technical characteristics

External dimensions	180 X 88 X 15 MM
Weight	80 g
Input voltage	DC 5.0 V
Input Current	1.5 A ~ 2 A
Output Power	5 W
Connection	USB type C

## Legal notice and Warranty

### PRECAUTIONS FOR USE AND RECOMMENDATIONS

Read all information before using the device to ensure safe and proper use.

- Handle your product with care, do not drop or knock them
- Do not disassemble the product as this will void the warranty and may cause damage that may render the product unusable.
- Use manufacturer-approved chargers, data cables and other accessories to prevent potential electric shock, fire, explosion or other hazards.
- Do not dismantle the product as this will result in the warranty being voided. Back cover cannot be removed.
- Clean the product using only a soft, slightly damp cloth. Do not use chemicals, detergents or abrasive products.
- This product is not waterproof. Protect it from damp and splashes of liquids.
- Do not store your device in extremely hot or cold places. Storage temperature is -20°C to +45°.
- Do not expose your device to direct sunlight for long periods. Operating temperature range is -5°C to +40°C.
- When charging, please keep the product in well-ventilated area. Charge the mobile phone in an environment between 5°C and 35°C.
- Do not use the product near magnetic fields.
- Do not use the product in potentially explosive areas.
- During prolonged use of your product, it may heat up. If the device overheats and reaches a certain temperature, functions and performance may be limited.
- Do not use bare or damaged cables, and do not use a damaged or defective charger.
- Unplug the wireless charging stand when unused for long periods of time.
- Caution, if you experience problems with the wireless charging stand, please discontinue use, unplug the wall adapter of the wireless charger stand from the AC socket, and contact your reseller for assistance.

### SAFETY AND HEALTH

- Keep the product away from small children.
- Do not use the product in health care facilities and ask to authorized personnel before using your phone near medical equipment.
- Persons with electronic implants (pacemakers, insulin pumps, neurostimulators, etc.) are recommended to place the product 15 cm away from implant or on the opposite side of the implant.

### WARRANTY

Your warranty is only valid under normal use of the device. All man-made damages and any of the following conditions are not covered by the warranty:

- The warranty period has expired.
- Normal wear and tear of the product.
- Damage resulting from improper use, exposure to humidity or liquid, or proximity to a heat source.

- Cracked or broken devices, or devices with visible signs of shocks.
- Failure to respect the precautions for use, accidents, negligence, misuse or use inconsistent with the instructions provided with the device, or commercial use of the product.
- Use of accessories or connectors not recommended by the manufacturer.
- The customer disassembles, repairs or modifies the device without the KAPSYS' authorization or has it repaired at a repair shop that is not included in the KAPSYS' approved repair network.
- Damage caused by a force majeure such as floods, fires, earthquakes, and lightning.

In some out of warranty failure cases, a repair can be implemented at your own cost. In case of breakdown, please contact your dealer.

## **CUSTOMER SERVICE**

For more details, please contact your dealer Customer Service or send us a mail to:

Service Clients KAPSYS – 694 avenue du Docteur Maurice Donat 06250 MOUGINS SOPHIA ANTIPO利斯, France.

You can also visit our website: [www.kapsys.com](http://www.kapsys.com).

## **TRADEMARKS**

Company and product brands referred to in this document, are trademarks, either registered or not, and owned by the respective holder as follows:

KAPSYS words, brands and logos are registered trademarks of KAPSYS SAS.

## **ABOUT THIS DOCUMENT**

Information published in this document is liable to change without notice. KAPSYS reserves the right to amend the contents of this document with no obligation to notify any person or entity whatsoever thereof. KAPSYS cannot be held liable in the event of any technical or publishing errors or omissions contained herein, or in the event of accidental or indirect loss or damage resulting from the product operation or from using this document. KAPSYS endeavours to continuously improve our product and its features quality and performance. KAPSYS therefore invites you to visit their website ([www.kapsys.com](http://www.kapsys.com)) for the latest update on the use and operation of this product.

## **CE Compliance For Europe**

Hereby, Kapsys declares compliance of this equipment to the applicable Council Directives of the European Union.

FCC statement:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.

--Increase the separation between the equipment and receiver.

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.

FCC ID: 2AXFA-KAP70600