




/Quasadtech



@Quasad.tech

www.quasad.tech


Essential Pad QNC14



125 mm

90 mm

Device overview



Technical specification



Windows 10



64 GB ROM
+ 4 GB RAM



1TB HDD 5400RPM



Apollo Lake N3350



Micro SDHC/SDXC



329*217*23mm
(H*W*D)



Wi-Fi: 802.11b/g/n
Bluetooth 4.0



5000 mAh



1400 g



Front 0.3MP





14.1", 16: 9 ,1920*1080 IPS




Congratulations on your purchase and welcome to Uasad.
Enjoy your Uasad Notebook with the latest Windows 10.

Use your apps

Open apps

Press [] on the keyboard, or click [] on the bottom left corner of the screen to see all apps.

Open the recently used apps list

Click  you will see all the open recently used apps. Tap the app you want from the list.

Action Center

Click  Start Setting management.



Can Sleep/shut down.



Can let you search the files and application programs in the PC.



Can let you set up the PC.



Can scan more apps.

Connect to the Internet

1. Tap the wireless network icon[] bottom right corner screen.
2. Turn on Wi-Fi, tap the network you want to connect to, and then tap Connect.

Warnings and safety precautions



Warning

- To prevent fire or shock hazard, do not expose your device to rain or moisture.
- Do not allow the device to come in close contact with a flame.
- Do not put, store or leave your device in or near sources of heat, in direct strong sunlight, in a high temperature location, in a pressurized container or in a microwave oven.
- When using this device, obey all laws and respect local customs, privacy and legitimate rights of others, including copyrights.



Safety

Handle your device with care

- Keep your product away from any sources of humidity. Do not manipulate your device with wet hands. Any damage done to the device due to its contact with water voids your warranty.
- Do not use or store your device in dusty or dirty areas.
- Do not use or store your device in extreme temperatures.
Environmental requirements:
Operating temperature: 32° to 95° F (0° to 35° C)
Nonoperating temperature: -4° to 113° F (-20° to 45° C)
- Do not drop, knock, or shake the device. Rough handling can break it.
- Do not paint your device. Paint can prevent proper operation.

Driving and walking safely

- You are responsible for knowing and obeying the laws and regulations regarding the use of wireless devices in the areas where you drive.
- Ensure that your device and its accessories do not block any air bags or other security devices fitted in your car.
- Do not use your device while walking or engaging in any activity that requires your full attention.

Avoid interference with other electronic products

- Keep the device away from magnets or magnetic fields.
- Your device radiates radio frequency (RF) signals that could interfere with the functioning of other electronic devices, such as pacemakers, hearing aids, or medical devices. Contact the manufacturer of the equipment to resolve any possible interference problems.

Small children

- Keep your device and its accessories out of the reach of small children. Small parts may cause choking or serious injury if swallowed.



Caution

Only certified technicians are qualified to repair your device

In calling upon nonqualified persons to repair your product, you run the risk of damaging your device and voiding your warranty.

Use only accessories that are branded or certified by manufacturer

The use of incompatible accessories with the device, such as batteries and charger, can cause injury or damage your device.



Battery and charger caution

This device is equipped with a Lithium-ion or Lithium-ion polymer battery.

- Risk of explosion if battery is replaced by an incorrect type.
- Do not pierce, open, disassemble the battery, or use it in a humid and/

or corrosive environment. If a battery leaks, do not let liquid touch skin or eyes. If this happens, immediately flush the affected areas with water, or seek medical help.

- Do not expose the battery to temperatures over 45°C (113°F).
- Do not dispose of batteries in a fire as they may explode. Obey local regulations. Recycle when possible.
- Be careful to never crush or perforate the battery. Avoid exposing the battery to high external pressure which could provoke an internal short-circuit and overheating.

Avoiding hearing damage



To prevent possible hearing damage, do not listen at high volume levels for long periods.

Disposal and recycling



Correct disposal of the product

This product contains substances that are potentially dangerous to the environment and to human health. Therefore, you should hand it over to the applicable collection point for the recycling.



Correct disposal of the batteries

If your product contains a detachable battery pack, you should only dispose of it in a designated collection point for used batteries.

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- o Reorient or relocate the receiving antenna.
- o Increase the separation between the equipment and receiver.
- o Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- o Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.