


Instruction Manual

Product introduction

Thank you for using this product. This product is a high-capacity, high-quality use of lithium polymer battery and charge-discharge chip, in safety, efficiency, compatibility and other aspects have outstanding performance.



This product uses USB-A interface to charge the equipment. When discharging, the indicator lamp shows the information of the electric quantity as follows:

Indicator	LED1	LED2	LED3	LED4
Full Charge	OFF	OFF	OFF	OFF
0-25%	OFF	OFF	OFF	ON
25-50%	OFF	OFF	ON	ON
50-75%	OFF	ON	ON	ON
75-100%	ON	ON	ON	ON

Specification

Magnetic Wireless Power Bank
 Model:TYH-60042
 Battery Capacity:4000mAh
 Input:Micro USB:5V/2A
 Output:USB-A:5V/2A
 Wireless Output:3W
 Size:107x66x51x3.5MM
 Weight: 136±10g

Notice: The wireless charging function of this product only can be used when it is connected with the wall charger under electricity.

Warning

1. Before using this product, please read the product description carefully, and follow the instructions to operate correctly.
2. Please do not disassemble the device by yourself. This product is not equipped with any parts and accessories that can be disassembled / maintained by yourself.
3. Please do not choose to meet local safety standards (such as China 3C certification standard) charger for this product charging, in order to prevent electric shock or lead to broken battery.
4. Do not apply heavy pressure, tap the product and avoid using the product in case of serious drop or strong vibration, or if liquid penetrates / spills into the product, which may cause battery, circuit damage or short circuit, please stop using it immediately and dispose of it properly.
5. This product occurs expansion, deformation, leakage, capacity, such as obvious decline, please immediately stop using and properly deal with.
6. In hot weather, please do not put this product in the outdoor unattended car or other sunburnt places, so as to avoid danger.

Notice

1. For the first time use, please charge the product fully.
2. When charging this product or using this product to charge other equipment, please choose the reliable charger and data line.
3. When charging the product, make sure that someone is present. Please unplug the power when you go out or leave for a long time.
4. If there is no power indication after pressing the key, it may be in a protected state, and can be connected to the external charger to try to recover.
5. If you do not use this product for a long time, please keep the power in the range of 20-80% and store this in a cool and dry environment. Avoid the state of full or no power long-term storage of this product to extend battery life.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.