

dnick bower-on and power-off operations. 12. Instructions for shifting gears if the remote control is broken: If the remote control is broken, you can switch colors through

11. Power-Off Memory Function: Each time the power is plugged in, the brightness is the brightness before the shutdown;

моцкид шоде! uext time turned on, it will continue to work in the current 10. Memory Function: Live memory function, siter the current working state is turned off or scheduled to be turned off, the next time furned on it will continue to work in the current

. White light -- Warm White light -- Warm light: Mode switch

8. Small Sun — —-Medium Sun-- —-Big Sun — Big Sun — Sudjustneer, 100% brightness fast switching function;

rue color diadient will be released. ③ Three-Color Gradient Mode: white light-warm white light-warm light-automatic color switching. The cycle time is 20 seconds; the timing button can be selected, if you press other buttons, the color man be selected.


эрош биндеэлд ® Breathing Lépit Mode; 2005; 1009: 1008; 1008; 1008; 1008; 1009; 100

> Tuo skewie si atets lettiui au i T 7. MODE: Mode Button:





Remote Control Function Description





Waterproof interface Screw it lightly according to the arrow direction

Drill hole, insert light, connect wire to transformer, ----- uoileilelsui -----

fine if one or two of the deck lights fails.) ou Jone ueegeg() ue jeg geck jigur kirs zriji works connection, you can only install part of them based ◆ The LED dot lights are detachable and in paralle!

Included, Support Max16pcs in Series) copper2 pin connector(DC 12V Transformer voltage output, no flicker, durable and stable ◆ Super quality LED chips(0.8W/pcs), DC12V low

the LED are not working properly ♦ Disconnect the main adapter from power outlet if

adapter to poweroutlet. ◆ Checkall connections before connectthe main

♦ Make sure LED are not installed within the reach

before use! Read the instruction carefully

Instruction manual

LED Deck Light

LED Deck Light

Bedienungsanleitung Deutsch



Lesen Sie die Anleitung vor Gebrauch sorgfältig durch!

- ◆ Stellen Sie sicher, dass LEDs nicht in Reichweite
- ♦ Überprüfen Sie alle Verbindungen, bevor Sie den Hauptadapter an die Steckdose anschließen.
- ◆ Trennen Sie den Hauptadapter von der Steckdose, wenn die LEDs nicht richtig funktionieren
- ◆ Super-Qualität LED-Chips (0,8 W / Stück), DC12 Niederspannungsausgang, kein Flackern, langlebiger und stabiler Kupfer2-Pin-Anschluss (DC 12V Transformator im Lieferumfang enthalten, unterstützt Max16 Stück in Serie)
- ◆ Die LED-Punktlichter sind abnehmbar und in Parallelschaltung können Sie nur einen Teil davon installieren, je nach Bedarf (Die LED-Decklichter funktionieren immer noch einwandfrei, wenn ein oder zwei der Decklichter ausfallen.)

----- Installation -----

Loch bohren, Licht einsetzen, Draht an Transformator anschließen, erneut für jedes Licht wiederholen, das den Draht mit dem letzten Licht verbindet.

Die zeigende Pfeilspitze muss auf den Schlitz zielen.



LED Deckslicht

Stellen Sie sicher, dass die LED nicht in Reichweite von Kindem installie
Überprüfen Sie alle Verbindungen, bevor Sie den Hauptadapter an die
Sterkinge enerhäußen

Hauptadanter von der Steckdose, wenn die LED nicht richtig

D Treiber

----- Anwendung -----

Beschreibung der Fernsteuerung

Lesen Sie die Anleitung vor dem Gebrauch sorgfältig durch!

----- Installation -----

1. ON/OFF: Das ist die Ein-/Aus-Taste

TIMER-RESET: Zum Deaktivieren der Timer-Taste/Matchcode-Taste;
Drücken Sie diese Taste im Timer-Modus zweimal das Lidit Minit zweimal schielt. um die
Timer-Modus Jahren Modus Jahren im Heine Modus Jahren in Heine Heine Heine Hein

000

3, 4H ist eine Timer-Taste seinnel drücken au

4. 8H ist eine Timer-Taste (einmaldrücken, auch einmalblinken

5. 12H ist eine Timer-Taste (einmal drücken, auch

7. MODE: Modus-Taste

Im Ausgangszustand leuchtet das Licht ständig

2) Atemlichtmodus: 100%-10%/10%-100% Helligkeit ändert sichim Zyklus, die Zykluszeit beträgt 20 Sekunden; im Atemlichtmodus können Sie die Farbtaste und die Timer-Taste auswählen, wenn Sie andere Tasten drücken, wird der Atemlichtmodus abgebroche

3) Dreifarhiger Farhverlaufsmodus: Weißes Light -- Warmweißes Licht -- Warmes Licht -- automatischer Farbwechsel Die Zykluszeit beträgt 20 Sekunden; die Timer-Taste kann gewählt werden, wenn Sie andere Tasten drücken, wird der Farbverlaufsmodus abgebrochen.

9. Weißes Licht---Warmweißes Licht---Warmes Licht:

10. Memory-Funktion: Memory-Funktion mit Strom, nach dem Ausschalten im aktuellen Arbeitszustand oder dem zeitgesteuerten Ausschalten wird es beim nächsten Einschalten automatisch in den aktuellen Arbeitsmodus gewechselt;

11. Memory-Funktion nach Ausschaften: Jedes Mal, wenn die Stromversorgung angeschlossen wird, wird die Helligkeitseinstellung vor dem Ausschalten aktiviert;

L2. Anleitung zum Umschalten im Fall einer Fehlfunktion: Wenn die Fernbedienung kaputt gegangen ist, können Sie die Farben durch schnelles Ein- und Ausschalten wechseln.

Maximale Ausgangsleistung (Weißlicht): 12W (Lampenleistung) Maximale Ausgangsleistung (Warmweißlicht): 12W (Lampenleistung) Maximale Ausgangsleistung (Warmlicht): 12W (Lampenleistung)

Achtung: Unterstützt Verbindung mit bis zu 20 Lampen

any interference received, including interference that may cause undesired operation. conditions: (1) this device may not cause harmful interference, and (2) this device must accept Any changes or modifications not expressly approved by the party responsible for This device complies with part 15 of the FCC Rules. Operation is subject to the following two

correct the interference by one or more of the following measures: generates, uses and can radiate radio frequency energy and, if not installed and used in reasonable protection against harmful interference in a residential installation. This equipment digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide which can be determined by turning the equipment off and on, the user is encouraged to try to If this equipment does cause harmful interference to radio or television reception, However, there is no guarantee that interference will not occur in a particular installation. accordance with the instructions, may cause harmful interference to radio communications. NOTE: This equipment has been tested and found to comply with the limits for a Class B compliance could void the user's authority to operate the equipment.

- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different

from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be u sed in portable exposure condition without restriction