DESK LAMP



MANUAL

Page 2

PRODUCT DESIGN:



BRIEF FUNCTION:

Wireless charger desk lamp includes 3 grades brightness adjustable function and supports wireless charger device use.

page 3

SPECIFICATION:

*Model:WD101

*Input:5V/2.0A

*LED:27pcsx2835LED

*Center Luminance: 788lux

*Color temperature:6500K MAX

*Wireless charger output:5V/1A, 5W

*Transferring distance:≤8mm

ATTENTIONS:

- 1. Power off the item before it is cleaned.
- 2.Keep the working temperature at 0^{45} °C.
- 3.Do not use it in humid environment.
- 4.Do not disassemble or modify it by yourself.
- 5.To make sure using effect, please use a 5V/2A adaptor and good quality cable.

Page 4

ABOUT WIRELESS CHARGER ATTENTIONS:

- 1.Please make sure your charging device support wireless charger while you use wireless charger function.
- 2. Please keep the charging device with wireless charger socket distance less than 8mm.
- 3. Please put the charging device to the central charging area for better charging effect.
- 4. Please remove charging device protection cover for better charging result.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.