


英文

<p>X7 Magnetic Wireless Car Charging Mount Instruction Manual</p> <p>Product Description</p> <p>Thank you for purchasing our wireless car charger holder, which is specially designed for iPhone12 series. It can be installed easily at the air vent of the car, and the unique magnet adsorption function allows you to enjoy the convenience of wireless charging. Please read this manual carefully before use and keep it properly.</p> <p>Packing List</p>  <ol style="list-style-type: none"> 1. Wireless Car Charger 2. Pivot Ball Fixing Nut 3. Air Vent Fixing Button 4. Ball Joint 5. Type-C Charging Cable <p>Installation Method</p> <ol style="list-style-type: none"> 1. Place the pivot ball fixing nut into the ball joint. 2. Insert the ball joint fixture into the wireless car charger. 3. Tighten the nut according to the requirements. 4. Fix it on the air vent, and tighten the air vent fixing button. 	<p>Function Parameters</p> <p>Input voltage: 5V/2A-9V/2.0A-12V/1.5A (compatible with QC/AFC/PD protocol)</p> <p>Output power (automatically adapted to mobile phones): 5W-7.5W-10W-15W</p> <p>Output current: 1A-1.67A</p> <p>Output voltage: 5-9V</p> <p>7.5W maximum efficiency: 76%</p> <p>Charging distance: 3mm</p> <p>Charging method: Magnet adsorption and auto alignment, wireless induction charging</p> <p>Working frequency: 110-205KHZ</p> <p>Product weight: 130 g</p> <p>Attentions</p> <ol style="list-style-type: none"> 1. The product is only suitable for iPhone 12 series. If the phone needs a protective case, please choose the case with magnet adsorption function. 2. Make sure your magnetic phone case is not thicker than 3mm. 3. Do not place metal objects or magnetic cards on the charging panel, which may cause abnormality and damage to the metal, magnetic cards or the product. 4. A formally certified QC2.0/3.0 car charger is required as the power source. 5. Do not disassemble the product by yourself or put into fire or water to avoid short circuit and electric leakage. 6. Do not use it in severe high or low temperature, humidity or corrosive environment to avoid damage to the product. 7. Any questions or problems, please contact us freely with your Order Number. 8. NANAMI Customer Support: support@nanami.cc 	<p>FCC STATEMENT:</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:</p> <p>This device may not cause harmful interference. This device must accept any interference received, including interference that may cause undesired operation.</p> <p>Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following.</p> <p>measures:</p> <p>Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.</p>	<p>FCC Radiation Exposure Statement:</p> <p>This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.</p> <p>English:</p> <p>This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:</p> <ol style="list-style-type: none"> (1) this device may not cause interference. (2) this device must accept any interference, including interference that may cause undesired operation of the device. <p>French:</p> <p>Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée.</p> <p>aux deux conditions suivantes:</p> <ol style="list-style-type: none"> (1) l'appareil ne doit pas produire de brouillage. (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. 	<p>Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to IC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <p>Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Consult the dealer or an experienced radio/TV technician for help.</p> <p>IC Radiation Exposure Statement:</p> <p>This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.</p>
---	--	---	---	---