










456mm

117mm

OUTSIDE PRINTING

MITAG MULTI-SENSOR STARTER KIT CONTAINS:

- 1 - MIGATEWAY 
- 2 - MITAG MULTI-SENSORS 
- 2 - MITAG MOUNTING BRACKETS 
- 1 - ETHERNET CABLE 
- 1 - USB POWER CABLE 
- 1 - USB POWER ADAPTER 
- 2 - PROXIMITY MAGNETS 
- 8 - #6 X 1.0" SCREWS 
- 8 - M5 WALL ANCHORS 

REMOTE MONITORING MADE EASY

www.MiSensors.com

FOR ADDITIONAL INFORMATION & SUPPORT:

-  MiSensors.com
-  support@MiSensors.com
-  866.MiSensors

MiSensors

WELCOME TO THE MISENSOR FAMILY



ACTIVATION CODE

456mm

117mm

INSIDE PRINTING


STEP 1 ACCOUNT SETUP

Create your MiSensors administration account.

- 1 CREATE ACCOUNT**
Visit signup.misensors.com and click "Sign Up" to create your Admin account.
- 2 CONFIRM EMAIL**
After creating your account you will receive an email to confirm your account.
- 3 BEGIN SETUP**
Once your account is confirmed you will need to select the "Begin Setup" button.
- 4 ACTIVATION CODE**
Enter the activation code found on the front of this card when requested during the onboarding process.
- 5 COMPLETE THE ONBOARDING STEPS**
Follow the steps to complete your account setup.

STEP 2 MIGATEWAY SETUP


Plug in USB cable to USB power adapter, then USB cable into MiGateway. Connect MiGateway using the ethernet cable into a RJ45 Ethernet port on your router/switch or cellular gateway.



Note: A QR code and MAC Address are located on the MiGateway Label. It will be used to add your Gateway in the MiSensors software application.

STEP 3 MITAG SENSOR SETUP

Before you install your MiTag Sensors be sure to add them to your account in the MiSensors software application. Use the MiTag Mounting Bracket for a secure installation. Hold the Alarm button for 3-5 seconds to activate transmitting mode. All lights will begin to blink and then a blue light will blink once it is transmitting.



Note: A QR code and MAC Address are located on the MiTag Labels. It will be used to add your Sensor in the MiSensors software application.

CUT LINE 
FOLD LINE 

 PANTONE 299C

 PANTONE 7546C

 PANTONE WHITE

FCC Compliance Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with the FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and all persons. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Canadian Compliance Statement

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada license-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1) L'appareil ne doit pas produire de brouillage;
- 2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

NOTE: This equipment complies with RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

REMARQUE: Cet équipement est conforme aux limites d'exposition aux radiations RSS-102 établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.