


Mifa

FREE WALKER



F10

Bluetooth Speaker

USER MANUAL >

LISTEN.MIFA
THE MUSIC POWER TO
YOUR DEEP HEART!



JUST ENJOY

Mifa MIFA INNOVATIONS LLC
www.mifa.net Designed in US
Made in China

Copyright © MIFA. All rights reserved.
MIFA, the MIFA logo and other MIFA marks
are all owned and registered by MIFA
INNOVATIONS LLC. All other trademarks are
the property of their respective owners.
The information contained here is subject
to change without prior notice.



EUBRIDGE ADVISORY GMBH
Virginia Str. 2, 35510 Butzbach,
Germany
eubridge@outlook.com



TANMET INT'L BUSINESS LTD
9 Pantygraigwen Road, Pontypridd,
Mid Glamorgan, CF37 2RR, UK
tanmetbiz@outlook.com

01 Warnings

English



- ◆ Please use and store this product at room temperature
- ◆ Do not throw and drop this product to avoid product damage
- ◆ Do not self-dismantling, repair and transform the product
- ◆ Do not use chemical solvent cleaning the product
- ◆ Please don't arbitrarily discarded or placed the lithium battery in the fire in order to avoid the risk of explosion


02 Product Features

English

- IP56 Water resistant & Dust proof
- Class-G NCN digital AMP
- Bluetooth 4.0 music playing
- Hands-free function
- USB sound card
- Supports iOS system ringtone playback
- Micro SD card APE,FLAC format music playing
- Micro SD card MP3,WMA,WAV format music playing
- Micro SD card reader data storage

03 Packing Content

English



Bluetooth speaker 1pc




USB cable 1pc



Hook 1pc



User manual 1pc




Warranty Card 1pc

04 Key Functions

English

Power :
Press and hold for 3 seconds to power on/off
Play/Pause: Short press to play/pause the music




- Press and hold:** Next song
- Short press:** Volume up/down. LED light will fast flash while reaches the minimum.
- Press and hold:** Previous song
- Short press:** Volume up/down. LED light will fast flash while reaches the maximum.
- Call answer key:** When an incoming call is received, a short press will answer or hang up the call, press and hold to reject the call.
- Mode switching by 2 times fast pressing:** Bluetooth mode/Micro SD card mode (A micro SD card must be inserted)/USB sound card mode (connect to the USB cable) switch in order

Bluetooth disconnect: Short press (+) (-) at the same time, disconnect with the current Bluetooth device and waiting for a new device to pair.

05 Interface function

English

USB sound card playing
When the speaker powers off, connect the speaker, quick press Power key 2 times, you will hear the voice prompt, then it comes to USB sound card playing mode and can play the music in our computer.




Micro SD card playing
When the speaker powers off, insert micro SD card, connect the speaker, Press and hold (Power) key, you will hear "Ding", then you can copy or delete files from the Micro SD card.

Notes
When low battery, the red LED fast flickering with "Du Du", then power off automatically.

06 Bluetooth Connection

English

Pairing with the devices that with Bluetooth function.




Bluetooth pairing:
Power on the speaker after the tone sound, a blue light will flicker, allowing pairing with a Bluetooth device "Mifa_F10".

Notes:
1, The default password is "0000"
2, The speaker will auto-connect to the last paired device when it powers on.
3, If you need to connect other devices, press (+) (-) at the same time to disconnect first, you will hear a sound then the speaker is re-discoverable and ready to pair with a new device.

07 Technique Parameters

English

Basic parameters	
Speaker type	Portable Bluetooth Speaker
Speaker system	Mono
Active/Passive	Active
Operate mode	Button
Main Features	Bluetooth 4.0, Hands-free, NCN digital AMP, USB sound card, Micro SD card music playing, Card reader
Power supply	DC5V-500mA USB adaptor
Technique Parameters	
Loudspeaker	1.5 inch + passive radiators
Output power	4Q 3W
Frequency Response	80Hz~18KHz
USB specification	USB2.0 compatible with USB1.1
Playing function	
File format	APE, FLAC, WAV, WMA, MP3



Product size: W86xD97xH38mm
Product weight: 166g (including the lithium battery)

08 FAQ

English

Problems	What to do
Paired Bluetooth device will not connect	1. Restart the speaker 2. If need password, please input "0000"
Music cuts out/stops playing	Please check if the Bluetooth connection is valid and in range. Check for outside interference from other electronic devices.
The speaker indicates a connection, but is not playing music	1. Check the volume of speaker 2. Check if the speaker is muted or paused
Speaker will not turn on	Check if the battery is low
System halted	Reset the speaker
Micro SD card format error	1. Check if the format of files in SD card is correct (supported file format is FAT32) 2. Check if the files is APE,FLAC, WAV, WMA, MP3

Mifa MIFA INNOVATIONS LLC Hotline : 4007-881-899
www.mifa.net Designed in US Made in China

© MIFA all rights reserved. The product and the packaging trademarks or registered trademarks of MIFA INNOVATIONS LLC in the united states or other countries. All rights reserved. Other trademarks and trade names are registered mark of their respective owners. MIFA INNOVATIONS LLC for any errors that may occur in this manual does not undertake any responsibility. The information contained in this manual are subject to change no prior notice.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction
FCC ID: 2AXOX-F10

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.