

TRIBUTE TO INNOVATION

GMKtec

Geek/Modern/(K)Creativity

GMKtec NUCBOX G1 USER MANUAL

Friendly Reminder

Thank you for choosing GMKtec, please read this user manual carefully and save it for future reference. Certificate/Inspected

The information contained in this document is subject to change without further notice; nothing in this document should be construed as creating any additional warranty; GMKtec shall not be liable for technical or editorial errors or omissions that may appear in this document;

If there are any problems or needs in the use process, you are welcome to use the email in this manual. Contact us at the address, we have been here to provide support!

Safety warnings and precautions

Before using and operating this equipment, please read and observe the following precautions carefully to avoid dangerous or illegal operations.

Use environment

Do not use the device in dusty and humid places to avoid causing internal circuit failures; Do not place this equipment near heating objects such as electric heaters; The working temperature of this equipment is 0-40 degrees, and the normal working temperature is 10-90% RH.

Power

Please use the special charger that comes standard with this product;

Waterproof


This device is not waterproof, please keep it dry;

Maintenance

For all maintenance services, please contact the dealer's maintenance personnel; Do not insert any sharp objects into the device; Do not drop or bump the device to avoid damage to the device.


About the Device

Please familiarize yourself with the interface and buttons of the device before use.



About the Device

Please familiarize yourself with the interface and buttons of the device before use.



Technical specifications


CPU	Intel 12th Alder Lake- N95, 4C/4T, 7nm, MAX3.4G, 6 MB Cache, TDP 15W	
GPU	Intel UHD Graphics (Up to 1.2Ghz)	
RAM	8GB, DDR4 3200 MT/s, SO-DIMM*1 (Up to 32GB, storage capacity is subject to actual purchase)	
Storage	M.2 2280 NVMe (PCIe3.0) 256GB/512GB (Product capacity is subject to actual purchase)	
Network	Ethernet	Giga LAN(RJ45)*1 2500M/1000M/100M/10M
	WiFi	Realtek 8852BE 802.11a/b/g/n/ac
	BT	Support
Charger	DC IN (5.5/2.5mm) , 12V/4A	
Packing list	Mini pc *1+VESA bracket*1+adapter *1+user manual *1+warranty card*1+HDMI Cable*1	

Note: The pictures listed in this manual are for reference only. Product specifications/button definitions and appearance are subject to change without further notice.


Connection Steps



1. Please use the power adapter that comes with this product;



2. Connect the monitor with the HDMI cable, please make sure that the HDMI cable is qualified;



3. Connect the keyboard and mouse;

4. During the first system startup, please follow the Windows startup guide. During this process, remember not to disconnect the power supply. It will take about ten minutes for the first startup to enter the user desktop, please wait patiently;

5. During the system startup process, if you cannot log in to your personal account, please turn off the Wi-Fi and local area network, select "skip option", and then log in to your personal account in the system;

Picture for reference only

Warranty commitment

Entitled 12-month warranty for the product quality problems caused by non-human factors.

Certificate/Inspected

After Service

Email: support@gmktc.com

Sales: gmktc@gmktc.com

Company: Shenzhen GMK Technology Co., Ltd.
Address: 4/F, #9 Bldg, Yifenghua Industrial Park, Huaning Rd, Longhua Dist, 518109, Shenzhen, China



FCC Compliance Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:-- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver.-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.-- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

USER MANUAL

GMKtec

Geek/Modern/(K)Creativity

www.gmktc.com