
Front





Charge

The headphone with a rechargeable battery , the first use of the headset must be fully charged to the battery. In use, if the voice Battery Low * prompting low power , that the battery is low , then you need to charge the headset.

The charging cable should be connected to the headset's magnetic charging port, about 2 hours to fill. Charging status indicator is red light, full charge often blue light.

Note There are positive and negative poles corresponding the magnetic charge, which can be charged normally the mutual adsorption. Mutual exclusion cannot charge or even cause short circuit.



Power On/Off Function Operation Indicator Light is on Press ' 🖒 'for 3-5s

Light is off

Music Play

Function	Earphone status	Operation
Increase volume	Play music	Short press ' +
Reduce volume		Short press ' -
Next song		Long press ' +
Previous song		Long press ' - '
Pause	1 1	
Resume	Pause	Short press ' 🖒 '

Answer the phone

Function	Earphone status	Operation
Answer the call / Hang up	Phone calls in	Short press ' 🖒 '
Decline the call		Press ' 🖒 ' for 2s
Volume control	Calling	Short press '+/-
Phone / Bluetooth earphone switch		Press ' 🖒 ' for 2s

Operating instruction

How to pair with Bluetooth How to palr with Bluetooth Bluetooth Bluetooth pairing: the off state, press and hold '\$\mathcal{O}\$' for 3 to 5 seconds, the indicator light will enter the red and blue light flashing state, and then enter the pairing state. Turn on the Bluetooth (mobile phone / computer) on the device and search for the device name "X7". Click the device "X7" to pair and connect.

Bluetooth / MP3 mode switching: Double click ' 🖒 ' free Switch bluetooth and memory mode.

Note: Bluetooth mode is default for boot.

Song download: Connect the magnetic charging cable to the computer and headphones, you can read the USB built-in memory card, and copy the songs from the computer to the USB.

TF card playback mode switch: When playing audio in rd mode, triple-click ' 🖰 ' to switch between shuffle and ential playback modes (with memory function)

Back

Al intelligent voice control		(Phone needs to suppo voice wake-up function	
Function	Earphone status	Operation	
Voice control	Bluetooth is connected	Press the ' 🖒 ' for 1s	

Note: In the Bluetooth connection status, Press the power but for 1 second and release it. After hearing the prompt, you can voice control the phone, saving time to operate the phone, fast and amert.

For example: You can directly control the earphone and ask: What time is it now......Today's weather.....
Navigate to Taipei 101......Call someone

Smart exercise, easy and full of fun

Indicator

Charging	Normally on red light
Finished charging	Normally on blue light
Search for a match	Red and blue lights flash alternately
Bluetooth music player	Blue light flashes once every 5 sec.

Product parameter

Model: X7 Charging time: ≈2h Input: 5V/180mA

Battery: 200mAh Distance: Bluetooth 10m Operating time : >5h@65% Volume

Version: 5.4

Profile: HFP, A2DP, AVRCP

Music format support: MP3, WMA, WAV, APE, FLAC Vaterproof grade: IPX8

Care and cleaning

- Cert et al la Cledaling

 The headshores should not soak in seawalenthine for a long time. The magnetic change part tends to deceyfrosion, such as going to the beach to recommend the magnetic absorption point shielding)

 If not used for a long time, please fully charge it at least once a month.

 If you find that the earphone is defective, please stop using it. A keep the product well well well to the comment of the product will not premission. If you find that the earphone is defective, please stop using it. A keep the product well you for the not recommend to the product will not stop the product will not stop the product will not stop the product to direct surflight for a long time.

 Please use a USB power adapter with an output of 5V less than 1A.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection Nues. Inese limits are designed to provide reasonation protects against harmful interference in a rediscinedial installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to redio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of

- Regrient or relocate the receiving antenna
- Renorment or muccaus me receiving anianna
 Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 Consult the dealer or an experienced radio/TV technician for

FCC Statement

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is

- uniputes uniputes with part 15 or the PCC Rules. Operation is subject to the following two conditions:

 1. This device may not cause harmful interference.—

 2. This device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without



Product warranty card

Product model:
Clients name:

Product maintenance records

Date	Bad phenomenon	Solution
\rightarrow		

_ 55mm _

75mm