


[HONIGAN]

1:32 SCALE RC AUDI S1 HONITRON

OPERATING INSTRUCTIONS

MODEL# H225479AH32
FCC ID: 2AXWV-FB02AD32



©2023 Flybar, Inc., Piscataway, NJ, USA

CONSUMER INFORMATION

CONTENTS:

- 1 Vehicle with Rechargeable Battery
- 1 Remote Controller

FEATURES:

- 6 MPH Top Speed with up to 150 FT Range
- Battery Charges with Included USB Cable
- Up to 20 Minutes Playtime
- 2.4GHz Full Function Pistol Grip Controller
- Forward/Reverse Driving
- Left/Right Steering
- Detailed Replica Design

WARNING

- Never play with this vehicle on streets.
- Do not pick up vehicle while in motion.
- Motor and battery can get very hot after running. Take care when handling them.
- Vehicle may become hot if the electronics get wet. DO NOT OPERATE this vehicle near in water, snow, sand, grass or any wet or muddy surfaces.
- To prevent property damage and/or personal injury. Never run the car near or toward people or animals or in crowded areas.
- Always place the car gently on the floor by hand. Never throw the car onto the floor.
- Avoid collisions with walls, hard objects, or human/animal bodies. Keep fingers, hair and loose clothing away from tires and wheel hubs. To avoid accidental operation, remove all batteries from controller when not in use.
- Do not connect this toy with other power supplies. Do not insert any wire into electrical outlets.
- Be sure to rest your vehicle for at least 5 minutes after every 20 minutes of operations.
- Make sure that no one else is using the same frequency in your running area. Using the same frequency at the same time, can cause loss of control with RC car, resulting in serious accidents.
- Remove the batteries from transmitter when not in use for extended periods of time.
- This toy is not intended for children under 6 years old.

CAUTION: CONTROLLER BATTERY SAFETY INFORMATION

- Ensure that battery polarity is correct.
- It is recommended to use only Alkaline type batteries. Do not mix used and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove controller batteries if R/C will not be used for a long period of time to prevent possible battery leakage.
- Do not recharge non-rechargeable batteries. Do not short-circuit terminals.
- Dispose of batteries safely. Do not dispose of batteries (or products containing non-replaceable batteries) in fire, as batteries may explode or leak.

CAUTION: CAR BUILT-IN BATTERY SAFETY INFORMATION

- Carefully read the instruction guide and use the batteries correctly.
- Rechargeable batteries are only to be charged under adult supervision. Routine examination for damage to the plug, enclosure and other parts. In the event of any damage, the toy must not be used with USB port until the damage has been repaired.
- Do not open, disassemble or alter the vehicle in any way. Do not dismantle the battery or charger and do not cut and battery cables. Altering the battery may cause short-circuit and/or damage to the product.
- To protect your vehicle, only connect to USB 2.0 charging port.
- Charge battery in isolated area. Keep away from flammable materials. Do not expose to direct sunlight. Do not recharge battery if it is still warm from use as it may damage the battery. Allow the battery to cool off prior to recharging.
- Never charge or store the vehicle in extremely hot or cold temperatures (about 104°F/40°C or below 14°F/-10°C) or beyond 60±25% related humidity. Don't charge or store the vehicle toy inside a parked car under the sun.
- Do not allow the batteries to get wet.
- Never incinerate used batteries, as they can explode causing serious accidents. In the unlikely event of leakage or explosion use sand or a chemical fire extinguisher for the battery.
- Make sure to disconnect charger from RC car and electrical outlet when not in use.

INSTALLING 2 BATTERIES INTO CONTROLLER

Requires 2 (two) "AA/LR6" alkaline batteries (not included)

1. Using a screwdriver (not included), remove the battery compartment door.
2. Remove and properly dispose of the used batteries (if any).
3. Insert the 2 "AA/LR6" batteries with polarity (+/-) as shown inside battery compartment.
4. Replace the battery compartment door and use a screwdriver to lock the compartment door.

CHARGING THE CAR


1. Make sure the switch is in the OFF position
2. Using a screwdriver (not included), remove the battery compartment door.
3. Remove the battery
4. Connect battery to the USB charger
5. Plug one end of the USB 2.0 cable into the battery and the other into any standard USB 2.0 port
6. The LED light will turn on to show it is charging
7. Once the LED light turns off, the RC vehicle is fully charged
8. Replace the battery compartment door and use a screwdriver to lock the compartment door.

OPERATING THE CAR

1. Switch the transmitter on.
2. Switch on the car.
3. Turn the steering wheel left, and the car will turn left.
4. Turn the steering wheel right, and the car will turn right.
5. Pull the throttle trigger backward to drive the car forward. To stop the car, quickly push the throttle trigger forward. To coast the car to a stop, let go of the throttle trigger.
6. Push the throttle trigger forward to reverse the car.

TO ADJUST STEERING ALIGNMENT:

Adjust the steering alignment lever on the underside of the vehicle when the vehicle doesn't run straight forward.



RC DRIVING INSTRUCTIONS


1 Turn the steering wheel left, the car will turn left.




2 Turn the steering wheel right, the car will turn right.



3 Pull the throttle trigger backward, the car will drive forward.



4 Loosen the trigger to allow it return the neutral position.



QUICK TIPS:

- The included rechargeable battery is not charged prior to shipment and must be charged before the first use.
- When your vehicle starts to lose power, it may lose function or performance. It's time to recharge the batteries. Your vehicle's running time may change depending on your driving style.
- Radio interference can make your vehicle run abnormally. Interference can be caused by other RC vehicles running on the same frequency; electrical wires, large buildings; or CB radios. Try to stay away from these!
- Point your transmitter controller antenna up - not down toward your vehicle. If your vehicle gets too far away, it won't work properly.
- Don't store your vehicle near heat or in direct sunlight. Always turn the switch to the off position when not in play.

INSTRUCTIONS FOR DISPOSAL OF WASTE:

- Your batteries and electronic toys should be recycled or disposed per your local waste management guidelines.
- Contact your local waste management officials for information regarding the environmentally sound recycling and disposal of batteries and electronic toys.

COMPLIANCE

Industry Canada Warning:

Operation is subject to the following two conditions:

(1) This device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. This radio communication device complies with Industry Canada Standard RSS-210.

COMPLIANCE WITH FCC REGULATIONS (VALID IN U.S. ONLY) THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

1. THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
2. THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION.

This device generates and uses radio waves and if not used properly may cause interference to radio and television reception. It has been tested and found to comply with the limits set by the FCC which are designed to provide reasonable protection against such interference.

FCC WARNING:

CAUTION:

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult an experienced radio/TV technician for help.

CLEANING INSTRUCTIONS:

To clean, wipe excess dirt from toy. Wipe toy clean with damp cloth. Wipe dry. **DO NOT IMMERSE IN WATER** and **DO NOT CLEAN VEHICLE WITH ANY CHEMICALS**. Let the toy completely dry before playing.

TROUBLESHOOT

Vehicle will not START	<ol style="list-style-type: none"> 1. Power switch is off. Make sure to turn it on. 2. Batteries are drained. Charge batteries.
Vehicle does not respond to controls	<ol style="list-style-type: none"> 1. Transmitter controller battery is drained. Replace the controller battery. 2. Vehicle is out of range. Bring controller closer to the vehicle. 3. Interference from surrounding electrical machinery. Bring to a wide open space
Vehicle does not drive straight	<ol style="list-style-type: none"> 1. Adjust the steering dial underneath the front axle, left or right, until the wheels point straightforward.
Vehicle does not move	<ol style="list-style-type: none"> 1. Stop operation, switch off the power and rest your vehicle a few minutes.
Why does one remote control both vehicles when trying to play 2 RC vehicles at the same time?	<ol style="list-style-type: none"> 1. Turn off both cars and remotes. 2. Turn on one car and remote to power up and sync controller to first car. 3. Turn on second car and remote to sync controller to second car.

WARRANTY

CONTACT OUR CUSTOMER SERVICE WITH ANY ISSUES

BEFORE RETURNING,

Give our friendly technicians a call from 9AM to 5PM Eastern Time; Monday - Friday at:

1-845-647-8400

or email us at:

INFO@FLYBAR.COM

U.S.A & CANADA 90-DAY LIMITED WARRANTY

Flybar, Inc.-warrants to the original consumer purchaser that this product will be free of defects in material and workmanship for ninety (90) days from the date of purchase. Flybar will repair or replace the product, at our discretion, in the event of such a defect within the warranty period.

In the event of a defect covered under this warranty, first call the phone numbers listed above. Many problems can be solved in this manner. If necessary, you will be instructed to return the product to the address below. Include your name, address, telephone number, copy of dated sales receipt, and a brief explanation of the defect. Please return the defective part or unit, packed securely. This warranty does not cover damage resulting from unauthorized modification, accident, misuse or abuse. If the product is returned without a dated sales receipt, the product may be excluded from coverage under this warranty. Flybar's liability for defects in material and workmanship under this warranty shall be limited to repair or replacement, at our sole discretion, and in no event shall we be responsible for incidental, consequential, or contingent damages (except in those states that do not allow this exclusion or limitation). This warranty is exclusive, and is made in lieu of any express or implied warranty. Valid only in U.S.A. and Canada. This warranty gives you specific legal rights and you may have other rights, which may vary from state to state. Some states do not allow the exclusion of incidental or consequential damages, so the above exclusions or limitations may not apply to you.

ADDRESS FOR RETURNS:

Flybar, Inc.
ATTN: Hoonigan RC Warranty Return
795 West Alexander Road
Greenwood, SC 29646
©2023 Flybar, Inc., Piscataway, NJ, USA