



**3 in 1 Wireless Charger Station**  
User Manual

**Preface:**  
Dear customers, thank you for purchasing our products. In order to understand the product further. Please read this manual carefully before use. We wish you a pleasant experience!




- ① Phone charging area
- ② Earphone charging area
- ③ Watch charging area
- ④ Charging indicator
- ⑤ USB-C interface



It is suggested to use 18W 9V=2A adapter.

There is a distinction between Apple system and Samsung system. Please check whether the received product is apple system or Samsung system. If you purchase Apple system product, you can charge Apple watch, but not Samsung watch. If you buy Samsung system product, you cannot charge Apple watch.



**Specifications**

- 3 in 1 Wireless Charger Station
- Phone output: 15W Max
- Watch output: 3W Max
- Input: 9V=2A
- Earphone output: 5W Max
- Input interface: USB-C

**Compatible Devices**

**Mobile Phone**

For iPhone

- 14 Pro Max/14 Pro/14 Plus/14/13 Pro Max/13 Pro/13/13 mini/12 Pro Max/12 Pro/12/12 mini/X/XR/XS Max/X/8 PLUS/8/SE 2/SE

For Samsung

- Samsung Galaxy 23 Ultra/S23+/23/S22 Ultra/S22+/S22/S21 FE/S21 Ultra/S21/S21+/S20 FE/S20/S20+/S20 Ultra/S10E/S10/S10+/S9/S9+/S8/S8+/S7/S7+/S7 Edge/S7 Active/S6/6 Edge+/S6 Active/Z Flip4/Z Flip3/Z Flip/Z Fold4/Z Fold3/Z Fold2/ Note 20 Ultra/Note 20/Note10 (5G)/Note10+ (5G)/Note9/Note 8/Note7/Note 6/Note 5

- Other mobile phones that support the Qi standard

**Earphone**


- AirPods Pro 2nd Generation/AirPods 3/AirPods Pro/AirPods 2/AirPods(wireless charging case)
- Samsung Galaxy Buds live/Buds plus/Buds 2/Buds Pro

**Smart Watch**

- T7A•Apple Watch Series Ultra/8/SE 2nd Generation/7/6/SE/5/4/3/2
- T7S•Samsung Galaxy Watch 5 Pro/Watch 5/Watch 4/Watch 4 Classic/Watch 3/Active 2/Active

**Indicator Light Description**

Charging instructions	Earphone		20 seconds to go off
	Phone		20 seconds to go off
	Watch		20 seconds to go off
	When the product is fully charged for your device		Indicator light remains off
	When the power supply to the adapter is insufficient		All lights will flash continuously
	When there is a foreign object on the product		The corresponding light flashes when the position is abnormal!



**How to solve abnormal charging:**

- Please confirm whether your mobile phone has wireless charging function before use;
- Check whether the phone deviates from the wireless inductive charging area of the charger;
- Whether a non-metallic protective case is used for charging mobile phones, and the thickness of the protective case is recommended not to exceed 4mm;
- When metal objects touch the charging area, the charger will automatically identify and provide power off protection.
- When the temperature of the charger is too high, it will automatically start the protection. Please unplug the power supply first and use it after the charger recovers the temperature.

**Safety Notes**

- Use indoor or under dry environment, avoid placing or using in the environment of high temperature, humidity, strong static electricity and strong magnetic field;
- For your safety, please do not use wet hand plug and unplug electrical appliances;
- Avoid putting it in a place easily accessible to infants and children;
- Do not use the product if it is contaminated with water or dirt;
- Non-professional personnel are not allowed to open and repair without authorization.

**Q&A:**

Q: Why is there heating in the charging of wireless charging inductive products?

A: During the charging process, there will be a certain loss of magnetoelectric conversion, which will be converted into heat, causing the mobile phone and charger to generate heat, which is a normal phenomenon.

**Suggestions:**

- When the device is fully charged, disconnect it from charging time to avoid a long cycle of charging, which may lead to continuous heating of the device and charger;
- It is recommended to stop running the background software when charging the phone.
- 3 devices charging at the same time or you want a faster charging speed, you need to use the PD30W adapter to charge.
- Please charge after the temperature cools. Our chargers have temperature control to ensure your device is safe while charging.
- If your iPhone is not charging, it may be a version issue. Please upgrade your phone to the latest system, or restart your phone to resolve the issue.
- If the device does not charge your watch, please check if your watch is up to date, if not, please upgrade to the latest system to solve the problem.

**FCC Warning**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and (2) this device must accept any interference

received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could

void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause

harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to

correct the interference by one or more of the following measures:  
-Reorient or relocate the receiving antenna.  
-Increase the separation between the equipment and receiver.  
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.

