

<div>DL-TWS-001</div> <div>User Manual</div>	<div>Package list</div> <div>(The pictures are for reference only, please refer to the actual products.)</div> <div>Charging case *1</div> <div>Earbuds *2pair</div> <div>Charging cable *1</div> <div>Earbuds *2pairs</div> <div>Manual</div>	<div>Introduction</div> <div>Indicator</div> <div>Charging port</div> <div>Charging Contact</div> <div>Microphone</div> <div>Touch</div> <div>Charging contact</div>	<div>Manual</div> <div>Turn on</div> <div>Automatically turn on after taking the earbuds out, coming with Power On prompt</div> <div>Turn off</div> <div>1.Back to the case: It will turn off after putting the earbuds back into the charging case</div> <div>2.Shorttime turn-off: It will turn off if there is no paired device within 3 minutes</div> <div>3.Low-battery turn-off: It will turn off if the battery is low.You'll hear the prompt of Power Off</div>	<div>Manual</div> <div>Restore factory setting</div> <div>Be sure the earbuds is unconnected and is searching Bluetooth, simultaneously long press the right/left earbuds for 8s to clean paired information and restore the factory settings.</div>	<div>Manual</div> <div>Charging</div> <div>Put the earbuds in the charging case to feed</div> <div>The device may not charge properly or may overheat.</div> <div>The earbuds state of charging</div> <div>When charging, The white indicator is always on Fully charging, LED indicator goes out</div> <div>The case state of charging</div> <div>When charging, The orange indicator is always on Fully charging, LED indicator goes out</div> <div>Top: The charging case state is given priority when charging both earbuds and the case.</div>	<div>Connection</div> <div>Bluetooth pairing</div> <div>Entering the Bluetooth interface to find DL-TWS-001, click Enter to pair.</div> <div>There is warning of "Du Du Du" under pairing mode.You'll hear the prompt of Connected</div> <div>Disconnection</div> <div>1.Over-distance disconnection: The earbuds will be automatically disconnected if beyond the effective working distance, you'll hear the prompt of Disconnect</div> <div>2.Manually disconnection: Under the connected state (non-working state), simultaneously long-press the Touch of</div>	<div>Connection</div> <div>Right and Left for 3s, disconnect the current device. Or manually turn off the Bluetooth device to disconnect.</div> <div>The earbuds will enter into the pairing mode after disconnected. DL-TWS-001 allows pairing with other devices.</div> <div>Reconnection</div> <div>1.Over-distance disconnection automatic reconnection: The earbuds will be automatically reconnected when it enters the effective working distance within 3 minutes, you'll hear the prompt of Connected</div> <div>2.Manually disconnection: The earbuds will automatically reconnect</div>	<div>Connection</div> <div>The last paired device when taken it out from the charging case.</div> <div>Please put the earbuds back in the charging port if there is one earbud quiet and disconnecting, and try to reconnect</div>	<div>Function</div> <div>Operation</div> <div>Click Assistant</div> <div>Click the left/right earbud 3 times to start, and click to exit</div> <div>Press of robot's interruptions require opening the "Intelligent voice assistant"</div> <div>Music</div> <div>Play/pause: click the left/right earbud</div> <div>Previous/Next: double click the left earbud for the previous song, and the right earbud for the next song.</div> <div>Call</div> <div>Answer: Click the left/right earbud</div> <div>Endline: Long press left/right earbud for 1.5s</div> <div>Hang up: Click the left/right earbud</div> <div>Third-party call: Click the left/right earbud, keep the original call and answer the new call</div> <div>Switch the call: Double-click the left/right earbud</div>	<div>Function</div> <div>Noise-cancelling Mode</div> <div>In the turn-on state, Long-press right/left for 1s to switch the mode</div> <div>The prompt of noise-cancelling is Sh</div> <div>The prompt of regular mode is Eh</div> <div>The prompt of transparency mode is Hh</div> <div>Low-latency Mode</div> <div>In the turn-on state, Click the right/left earbud for 4 times to switch mode</div> <div>The prompt of game: Game Mode</div> <div>Existing game mode is Music Mode</div>	<div>product Specifications</div> <div>Product Model: DL-TWS-001</div> <div>Bluetooth Version: 5.3</div> <div>Codec: AAC / SBC</div> <div>Audio Distribution Profile: A2DP/AVRCP/HFP/HSP/SBC/AAC</div> <div>Bluetooth Range: ±10 meters (Open environment)</div> <div>Battery Life: 40(earphone)+12(cas)Hours</div>
<div>Security Instructions</div> <div>Please read this important safety instructions before using the equipment. This information contains general safety information applicable to this device and may include content not applicable to this device. Please follow the warnings and cautions to avoid injury to yourself or others or damage to your equipment.</div> <div>Warning</div> <div>Failure to comply with safety warnings and regulations would result in serious injury or death.</div> <div>Do not use damaged power cord or plug or loose power socket</div> <div>Unsafe connections can cause electric leakage or fire.</div> <div>Do not use wet hands or other wet body parts to touch.</div>	<div>Security Instructions</div> <div>Touch the device, power cord, plug or power socket, otherwise it may cause electric shock.</div> <div>When unplugging the power cord, do not use too much force, otherwise it may cause electric shock or fire.</div> <div>Do not bend or damage the power cord, otherwise it may cause electric leakage or fire.</div> <div>Do not operate the device with wet hands while it is charging, otherwise it may cause electric shock.</div> <div>Do not directly connect the positive and negative terminals of the charger together, otherwise it may cause a fire or cause serious injury.</div> <div>Do not use the device outdoors during a thunderstorm, otherwise it may cause electric shock or equipment failure.</div> <div>Use batteries, chargers, accessories and supplies approved</div>	<div>Security Instructions</div> <div>by the manufacturer:</div> <div>•Using universal batteries or chargers may shorten the life of the battery or cause the device to malfunction. They may also cause a fire or cause the battery to explode.</div> <div>•Only use chargers and data cables specially designed for equipment and approved by MOONDRÖP. Incompatible chargers and data cables may cause damage or damage the equipment.</div> <div>•When customers use accessories or supplies not approved by MOONDRÖP, MOONDRÖP is not responsible for the customers' safety.</div> <div>Do not put the device in the back-pocket or hang it on the waist</div> <div>Excessive force may damage the device, might cause explode</div>	<div>Security Instructions</div> <div>or fire.</div> <div>•If you hit or fall, you may be injured.</div> <div>Do not stop the device or subject it to strong impact.</div> <div>•Otherwise, it may damage the device or battery, cause the device to fail to work normally, or shorten the device life.</div> <div>•It may also cause overheating, burning or other dangers.</div> <div>Handle and dispose of equipment and chargers carefully</div> <div>•Do not throw battery or device into fire.</div> <div>Do not directly connect the positive and negative terminals of the charge batteries or devices in or on heating devices (such as microwave ovens, ovens, or radiators). The device may explode if overheated.</div> <div>When exposed to used battery or device, please comply with local regulations.</div>	<div>Security Instructions</div> <div>• Do not squeeze or pierce the device.</div> <div>• Do not subject the device to external high voltage, otherwise it may cause internal short circuit and overheating.</div> <div>Protect equipment, batteries and chargers from damage.</div> <div>• Avoid exposing the device and battery to extremely cold or extremely hot temperatures.</div> <div>• Extreme temperatures can damage the device, reduce the charging capacity of the device, and shorten the service life of the device.</div> <div>Do not touch the device with the skin peeled off or damaged, and the charger with damaged or not working properly.</div> <div>Do not store device near or in water heaters, microwave ovens, hot cooking equipment, or high-pressure containers</div>	<div>Security Instructions</div> <div>•The battery may leak.</div> <div>•The equipment may overheat and cause a fire.</div> <div>Do not put or store the device in areas where dust or aeolian materials are concentrated</div> <div>Dust or foreign objects may cause device damaged, fire or electric shock</div> <div>Prevent the charger from damage and the smaller end of the charger from contacting conductive materials such as liquid, dust, metal powder, or pencil lead.</div> <div>Do not touch with sharp tools.Charger socket; do not bump the charger socket.</div> <div>Do not put the device in the back-pocket or hang it on the waist</div> <div>Conductive materials may short-circuit or corrode the contacts, which may cause explosion or fire.</div> <div>When using a wireless charger, do not place metal objects,</div>	<div>Security Instructions</div> <div>magnets, and magnetic strips/cards between the device and the wireless charger.</div> <div>The device may not charge properly or may overheat.</div> <div>Do not bite or suck the device or battery</div> <div>Equipment with speakers is particularly susceptible to interference.</div> <div>Do not use your device in places that may be interfered by radio frequency such as hospitals, airplanes or cars</div> <div>In order to minimize the interference of the device to the pacemaker, please use the device on the side of opposite to the pacemaker</div> <div>Do not use damaged or leaking batteries. For safe disposal of batteries, please contact the nearest authorized service</div>	<div>Security Instructions</div> <div>center.</div> <div>The device and some accessories (sold separately) contain magnets. The American Heart Association and the British Medicines and Health Products Administration also warned that magnets will affect implantable pacemakers, heart rhythm converters, defibrillators, insulin pumps or other electronic medical devices (collectively referred to as "medical devices") within 15 cm, operating. If you are a user of any of these medical devices, please do not use this device and some accessories (sold separately) before consulting a doctor.</div> <div>Note</div> <div>Failure to comply with safety precautions and regulations can lead to personal injury or property damage</div>	<div>Security Instructions</div> <div>Do not use the device near other electronic devices</div> <div>Most electronic devices use radio frequency signals. Your device may interfere with other electronic devices.</div> <div>Equipment with speakers is particularly susceptible to interference.</div> <div>Do not use your device in places that may be interfered by radio frequency such as hospitals, airplanes or cars</div> <div>In order to minimize the interference of the device to the pacemaker, please use the device on the side of opposite to the pacemaker</div> <div>Do not use damaged or leaking batteries. For safe disposal of batteries, please contact the nearest authorized service</div>	<div>Security Instructions</div> <div>whether it will be affected by the radio frequency emitted by this device.</div> <div>•During air flight, the use of electronic equipment will interfere with the airplane's electronic navigator. Follow the airline's regulations and instructions. Please always use the flight mode.</div> <div>•The use of electronic equipment of the car may malfunction due to radio interference from the equipment. For details, please contact the manufacturer.</div> <div>Do not place the device in a place with dense smoke or fog</div> <div>Otherwise, the surface of the device may be damaged or the device may malfunction.</div> <div>Do not use the device near or in explosive areas, explosive materials, chemical agents and explosive areas.</div> <div>Do not store or carry flammable liquids, gases or explosive materials in boxes containing device or accessories.</div>	<div>Security Instructions</div> <div>certain hearing aids and cochlear implants. Before using this equipment, please contact the manufacturer to determine whether the equipment will be affected by the radio frequencies emitted by this equipment.</div> <div>Do not use the device near radio frequency devices or instruments (such as audio systems or radio antenna towers)</div> <div>Radio frequency may cause device malfunction.</div> <div>•If you use the device in a potentially explosive environment, always operate in accordance with regulations, instructions and signs in an explosive environment.</div> <div>Do not use the equipment in gas stations or near flammable materials, chemical agents and explosive areas.</div> <div>Do not store or carry flammable liquids, gases or explosive materials in boxes containing device or accessories.</div>	<div>Security Instructions</div> <div>If any part of the device is damaged, smokes, or smells of burning things, please stop using the device immediately. The equipment can not be reused until being repaired by the MOONDRÖP Service Center.</div> <div>•Broken glass may hurt your hands and face.</div> <div>•If the device emits smoke or the smell of burning things, it may cause the battery to explode or burn.</div> <div>Do not use the device in a potentially explosive environment</div> <div>Always operate in accordance with regulations regarding the use of equipment while driving.</div> <div>Do not use the equipment in gas stations or near flammable materials, chemical agents and explosive areas.</div> <div>For the safety of you and others, please follow the safety warnings and relevant regulations and remember the following tips:</div>
<div>Security Instructions</div> <div>Place the equipment in an easy-to-access location. No need to look away from the road to get the wireless device.</div> <div>On order to avoid danger, please the cell in traffic jams or bad weather conditions (rain, sleet, snow, ice). Rain and sleet, snow, ice and heavy traffic can cause danger.</div> <div>Do not record voice memo.</div> <div>Recording a language memo while driving may distract your focus on the primary responsibility of driving safely.</div> <div>According to the traffic situation, decide whether to answer the call reasonably. Answer calls when not moving forward or in traffic jams. Try to call after parking.</div> <div>Do not engage in strenuous or excited conversations to avoid distraction. Please let the caller know that you are driving.</div> <div>Properly maintain and use equipment</div>	<div>Security Instructions</div> <div>Keep the equipment dry</div> <div>Moisture and liquid can damage equipment parts or circuits.</div> <div>Do not turn on the device when it is wet. If the device is turned on, turn it off (if the device cannot be turned off, please maintain the status quo). Then dry the equipment with a towel and use it after it is completely dry.</div> <div>Do not expose the device to direct sunlight for a long time, such as on the dashboard of a car. Do not store the device with metal objects such as coins, keys and necklaces.</div> <div>•The equipment is equipped with a built-in liquid indicator.</div> <div>Water damage to the equipment will invalidate the manufacturer's warranty.</div> <div>The device should be stored on a flat ground if the device falls, it will be damaged.</div> <div>The device can be used where the atmosphere temperature is between 0°C and 35°C. You can store the device where the ambient temperature is between -20 °C and 50 °C. Using or</div>	<div>Security Instructions</div> <div>storing the device outside the recommended temperature range may cause damage to the device or shorten battery life</div> <div>•Do not store the device in extremely hot areas, such as in a car in summer, otherwise, the equipment may be damaged or the battery may explode.</div> <div>•Do not expose the device to direct sunlight for a long time, such as on the dashboard of a car. Do not store the device with metal objects such as coins, keys and necklaces.</div> <div>•The equipment may be scorched or malfunction.</div> <div>•If the battery contacts come in contact with metal objects, it may cause a fire.</div> <div>Do not store the device near magnetic fields</div> <div>When exposed to a magnetic field, the device may malfunction or the battery may discharge.</div>	<div>Security Instructions</div> <div>Magnetic strips/cards (including credit cards, phone cards, bank books and boarding cards) may be damaged by magnetic fields emitted by the device when the device is overheated. Otherwise, it may cause low temperature burns, redness and skin pigmentation.</div> <div>After using the device for a long time, pay attention to the heating of the device and avoid contact with the skin for too long.</div> <div>•Do not sit on the device, or keep it direct sunlight with your skin for a long time while the device is charging or connected to the power source.</div> <div>High temperature resistance varies from person to person.</div> <div>Please pay special attention when using it by children, the elderly,Protect hearing and ears when using earplugs</div> <div>Excessive exposure to strong sounds can cause hearing loss.</div>	<div>Security Instructions</div> <div>•Contact with strong sounds while walking may distract you and cause accidents.</div> <div>Always turn down the volume before using earplugs, and use only the lowest volume required to listen to conversations or music.</div> <div>There are foreign objects on the earplugs, and you wear the earplugs for a long time, it may cause ear infections. Please keep the earplugs dry and clean.</div> <div>•In a dry environment, static electricity may accumulate in the earplugs. Avoid using this earplug in a dry environment, or touch metal objects to discharge static electricity before using the earplugs.</div> <div>Do not place equipment and accessories in or near the airbag deployment area. If the equipment is improperly placed, the airbag inflates rapidly, which can cause serious injury.</div> <div>Do not drop the device or cause collision</div>	<div>Security Instructions</div> <div>Precautions for using the device during walking or moving.</div> <div>Always pay attention to your surroundings to avoid harming yourself or others.</div> <div>Do not paint or paste paper on the equipment</div> <div>If you are allergic to the paint or metal parts of the device, it may cause itching, eczema or swelling of the skin. When the above situation occurs, please stop using the device and consult a doctor.</div> <div>Install the device cautiously</div> <div>The device should be placed in a safe location, such as the deployment area. If the equipment is improperly placed, the airbag inflates rapidly, which can cause serious injury.</div> <div>Do not drop the device or cause collision</div>	<div>Security Instructions</div> <div>•The device may be damaged or malfunction.</div> <div>•If the device is bent or deformed, it may damage the equipment or cause personal injury.</div> <div>Ensure the longest service life of the battery and charger</div> <div>•If the battery is used for a long time, the battery may malfunction.</div> <div>•The equipment will discharge if left unused for a long time, and must be recharged before use.</div> <div>When the equipment is not in use, disconnect the power supply.</div> <div>•The battery can only be used for the designated purpose.</div> <div>Follow all the instructions in this manual to ensure the longest service life of the device and battery. The manufacturer will not provide warranty for damage or poor performance caused</div>	<div>Security Instructions</div> <div>by failure to follow the warnings and instructions.</div> <div>The equipment may wear out over time. Although some parts are guaranteed during the validity period, damage or deformation caused by the use of unapproved accessories is not covered by the warranty.</div> <div>Do not disassemble, modify or repair the equipment</div> <div>Any changes or modifications to the equipment will cause the manufacturer to not guarantee the equipment. For repairing, please contact your local MOONDRÖP authorized dealer.</div> <div>Do not disassemble or piece the equipment, as this may cause an explosion or fire.</div> <div>Do not disassemble or reuse the battery.</div> <div>When cleaning the equipment, please follow the following advice</div>	<div>Security Instructions</div> <div>Use a soft and dry cloth to wipe the device, use a brush or other tools to remove the wax/oil or dirt on the earplugs.</div> <div>Clean the battery contacts with a dry cloth.</div> <div>Do not use chemicals or cleaning agents. Otherwise, the surface of the equipment may be discolored or corroded, and it may also cause electric shock or fire.</div> <div>Prevent the equipment from contact with dust, sweat, ink, oil, and chemical products (such as cosmetics, antibacterial sprays, hand sanitizers, detergents and insecticides).Chemicals, the internal and external parts of the device may be damaged, or the performance may deteriorate. If the device comes into contact with any of the above-mentioned substances, please wipe it with a soft, lint-free cloth.</div> <div>Do not use the device for any purpose other than the</div>	<div>Security Instructions</div> <div>designated purpose</div> <div>The device may malfunction.</div> <div>Avoid disturbing others when using the device in public places</div> <div>Only qualified personnel are allowed to repair the device</div> <div>If the equipment is repaired by unqualified personnel, the manufacturer is not responsible for any problems provided through this service.</div> <div>Do not distribute copyrighted content</div> <div>Do not distribute copyrighted material without the permission of the content owner. This behavior violates copyright law. The manufacturer is not responsible for any legal problems caused by any illegal actions by users against copyrighted content.</div>	<div>Security Instructions</div> <div>Disclaimer</div> <div>All content and services available through this device belong to the copyright owner. All rights are reserved. The content, trademarks and other intellectual property laws. Such content and services are only for personal non-commercial use. Without the permission of the content owner or service provider, you may not be able to use any content or service.</div> <div>Explicit permission of the application content or service provider, you may be able to modify,copy,republish, update, print, transmit, translate, or repost any content or service displayed through this device. sell, create new derivative works, develop or distribute in any way.</div> <div>Third-party content and services are provided. For any purpose, MOONDRÖP Company does not provide any express</div>	<div>Security Instructions</div> <div>or implied guarantees for the content or services provided. MOONDRÖP Co. expressly declares that it does not assume any implicit guarantees, or through regulations, common law, or other means (including but not limited to trademarks and other intellectual property laws. Such content and services are only for personal non-commercial use. Without the permission of the content owner or service provider, you may not be able to use any content or service.</div> <div>Explicit permission of the application content or service provider, you may be able to modify,copy,republish, update, print, transmit, translate, or repost any content or service displayed through this device. sell, create new derivative works, develop or distribute in any way.</div> <div>Third-party content and services are provided. For any purpose, MOONDRÖP Co. does not guarantee for and use copyright, liability,</div>
<div>Security Instructions</div> <div>timeliness, legally or completeness."</div> <div>Third-party services may be stopped or interrupted at any time, and MOONDRÖP Co. is not responsible or guarantee for any content or the time period during which the service is available. The content and services are provided by third parties through networks and transmission equipment</div> <div>any, and heavy traffic can cause danger.</div> <div>Do not record voice memo.</div> <div>Recording a language memo while driving may distract your focus on the primary responsibility of driving safely.</div> <div>According to the traffic situation, decide whether to answer the call reasonably. Answer calls when not moving forward or in traffic jams. Try to call after parking.</div> <div>Do not engage in strenuous or excited conversations to avoid distraction. Please let the caller know that you are driving.</div> <div>Properly maintain and use equipment</div>	<div>Security Instructions</div> <div>Keep the equipment dry</div> <div>Moisture and liquid can damage equipment parts or circuits.</div> <div>Do not turn on the device when it is wet. If the device is turned on, turn it off (if the device cannot be turned off, please maintain the status quo). Then dry the equipment with a towel and use it after it is completely dry.</div> <div>Do not expose the device to direct sunlight for a long time, such as on the dashboard of a car. Do not store the device with metal objects such as coins, keys and necklaces.</div> <div>•The equipment is equipped with a built-in liquid indicator.</div> <div>Water damage to the equipment will invalidate the manufacturer's warranty.</div> <div>The device should be stored on a flat ground if the device falls, it will be damaged.</div> <div>The device can be used where the atmosphere temperature is between 0°C and 35°C. You can store the device where the ambient temperature is between -20 °C and 50 °C. Using or</div>	<div>Security Instructions</div> <div>storing the device outside the recommended temperature range may cause damage to the device or shorten battery life</div> <div>•Do not store the device in extremely hot areas, such as in a car in summer, otherwise, the equipment may be damaged or the battery may explode.</div> <div>•Do not expose the device to direct sunlight for a long time, such as on the dashboard of a car. Do not store the device with metal objects such as coins, keys and necklaces.</div> <div>•The equipment may be scorched or malfunction.</div> <div>•If the battery contacts come in contact with metal objects, it may cause a fire.</div> <div>Do not store the device near magnetic fields</div> <div>When exposed to a magnetic field, the device may malfunction or the battery may discharge.</div>	<div>Security Instructions</div> <div>Magnetic strips/cards (including credit cards, phone cards, bank books and boarding cards) may be damaged by magnetic fields emitted by the device when the device is overheated. Otherwise, it may cause low temperature burns, redness and skin pigmentation.</div> <div>After using the device for a long time, pay attention to the heating of the device and avoid contact with the skin for too long.</div> <div>•Do not sit on the device, or keep it direct sunlight with your skin for a long time while the device is charging or connected to the power source.</div> <div>High temperature resistance varies from person to person.</div> <div>Please pay special attention when using it by children, the elderly,Protect hearing and ears when using earplugs</div> <div>Excessive exposure to strong sounds can cause hearing loss.</div>	<div>Security Instructions</div> <div>•Contact with strong sounds while walking may distract you and cause accidents.</div> <div>Always turn down the volume before using earplugs, and use only the lowest volume required to listen to conversations or music.</div> <div>There are foreign objects on the earplugs, and you wear the earplugs for a long time, it may cause ear infections. Please keep the earplugs dry and clean.</div> <div>•In a dry environment, static electricity may accumulate in the earplugs. Avoid using this earplug in a dry environment, or touch metal objects to discharge static electricity before using the earplugs.</div> <div>Do not place equipment and accessories in or near the airbag deployment area. If the equipment is improperly placed, the airbag inflates rapidly, which can cause serious injury.</div> <div>Do not drop the device or cause collision</div>	<div>Security Instructions</div> <div>Precautions for using the device during walking or moving.</div> <div>Always pay attention to your surroundings to avoid harming yourself or others.</div> <div>Do not paint or paste paper on the equipment</div> <div>If you are allergic to the paint or metal parts of the device, it may cause itching, eczema or swelling of the skin. When the above situation occurs, please stop using the device and consult a doctor.</div> <div>Install the device cautiously</div> <div>The device should be placed in a safe location, such as the deployment area. If the equipment is improperly placed, the airbag inflates rapidly, which can cause serious injury.</div> <div>Do not drop the device or cause collision</div>	<div>Security Instructions</div> <div>•The device may be damaged or malfunction.</div> <div>•If the device is bent or deformed, it may damage the equipment or cause personal injury.</div> <div>Ensure the longest service life of the battery and charger</div> <div>•If the battery is used for a long time, the battery may malfunction.</div> <div>•The equipment will discharge if left unused for a long time, and must be recharged before use.</div> <div>When the equipment is not in use, disconnect the power supply.</div> <div>•The battery can only be used for the designated purpose.</div> <div>Follow all the instructions in this manual to ensure the longest service life of the device and battery. The manufacturer will not provide warranty for damage or poor performance caused</div>	<div>Security Instructions</div> <div>by failure to follow the warnings and instructions.</div> <div>The equipment may wear out over time. Although some parts are guaranteed during the validity period, damage or deformation caused by the use of unapproved accessories is not covered by the warranty.</div> <div>Do not disassemble, modify or repair the equipment</div> <div>Any changes or modifications to the equipment will cause the manufacturer to not guarantee the equipment. For repairing, please contact your local MOONDRÖP authorized dealer.</div> <div>Do not disassemble or piece the equipment, as this may cause an explosion or fire.</div> <div>Do not disassemble or reuse the battery.</div> <div>When cleaning the equipment, please follow the following advice</div>	<div>Security Instructions</div> <div>Use a soft and dry cloth to wipe the device, use a brush or other tools to remove the wax/oil or dirt on the earplugs.</div> <div>Clean the battery contacts with a dry cloth.</div> <div>Do not use chemicals or cleaning agents. Otherwise, the surface of the equipment may be discolored or corroded, and it may also cause electric shock or fire.</div> <div>Prevent the equipment from contact with dust, sweat, ink, oil, and chemical products (such as cosmetics, antibacterial sprays, hand sanitizers, detergents and insecticides).Chemicals, the internal and external parts of the device may be damaged, or the performance may deteriorate. If the device comes into contact with any of the above-mentioned substances, please wipe it with a soft, lint-free cloth.</div> <div>Do not use the device for any purpose other than the</div>	<div>Security Instructions</div> <div>designated purpose</div> <div>The device may malfunction.</div> <div>Avoid disturbing others when using the device in public places</div> <div>Only qualified personnel are allowed to repair the device</div> <div>If the equipment is repaired by unqualified personnel, the manufacturer is not responsible for any problems provided through this service.</div> <div>Do not distribute copyrighted content</div> <div>Do not distribute copyrighted material without the permission of the content owner. This behavior violates copyright law. The manufacturer is not responsible for any legal problems caused by any illegal actions by users against copyrighted content.</div>	<div>Security Instructions</div> <div>Disclaimer</div> <div>All content and services available through this device belong to the copyright owner. All rights are reserved. The content, trademarks and other intellectual property laws. Such content and services are only for personal non-commercial use. Without the permission of the content owner or service provider, you may not be able to use any content or service.</div> <div>Explicit permission of the application content or service provider, you may be able to modify,copy,republish, update, print, transmit, translate, or repost any content or service displayed through this device. sell, create new derivative works, develop or distribute in any way.</div> <div>Third-party content and services are provided. For any purpose, MOONDRÖP Company does not provide any express</div>	<div>Security Instructions</div> <div>or implied guarantees for the content or services provided. MOONDRÖP Co. expressly declares that it does not assume any implicit guarantees, or through regulations, common law, or other means (including but not limited to trademarks and other intellectual property laws. Such content and services are only for personal non-commercial use. Without the permission of the content owner or service provider, you may not be able to use any content or service.</div> <div>Explicit permission of the application content or service provider, you may be able to modify,copy,republish, update, print, transmit, translate, or repost any content or service displayed through this device. sell, create new derivative works, develop or distribute in any way.</div> <div>Third-party content and services are provided. For any purpose, MOONDRÖP Co. does not guarantee for and use copyright, liability,</div>
<div>Security Instructions</div> <div>timeliness, legally or completeness."</div> <div>Third-party services may be stopped or interrupted at any time, and MOONDRÖP Co. is not responsible or guarantee for any content or the time period during which the service is available. The content and services are provided by third parties through networks and transmission equipment</div> <div>any, and heavy traffic can cause danger.</div> <div>Do not record voice memo.</div> <div>Recording a language memo while driving may distract your focus on the primary responsibility of driving safely.</div> <div>According to the traffic situation, decide whether to answer the call reasonably. Answer calls when not moving forward or in traffic jams. Try to call after parking.</div> <div>Do not engage in strenuous or excited conversations to avoid distraction. Please let the caller know that you are driving.</div> <div>Properly maintain and use equipment</div>	<div>Security Instructions</div> <div>Keep the equipment dry</div> <div>Moisture and liquid can damage equipment parts or circuits.</div> <div>Do not turn on the device when it is wet. If the device is turned on, turn it off (if the device cannot be turned off, please maintain the status quo). Then dry the equipment with a towel and use it after it is completely dry.</div> <div>Do not expose the device to direct sunlight for a long time, such as on the dashboard of a car. Do not store the device with metal objects such as coins, keys and necklaces.</div> <div>•The equipment is equipped with a built-in liquid indicator.</div> <div>Water damage to the equipment will invalidate the manufacturer's warranty.</div> <div>The device should be stored on a flat ground if the device falls, it will be damaged.</div> <div>The device can be used where the atmosphere temperature is between 0°C and 35°C. You can store the device where the ambient temperature is between -20 °C and 50 °C. Using or</div>	<div>Security Instructions</div> <div>storing the device outside the recommended temperature range may cause damage to the device or shorten battery life</div> <div>•Do not store the device in extremely hot areas, such as in a car in summer, otherwise, the equipment may be damaged or the battery may explode.</div> <div>•Do not expose the device to direct sunlight for a long time, such as on the dashboard of a car. Do not store the device with metal objects such as coins, keys and necklaces.</div> <div>•The equipment may be scorched or malfunction.</div> <div>•If the battery contacts come in contact with metal objects, it may cause a fire.</div> <div>Do not store the device near magnetic fields</div> <div>When exposed to a magnetic field, the device may malfunction or the battery may discharge.</div>	<div>Security Instructions</div> <div>Magnetic strips/cards (including credit cards, phone cards, bank books and boarding cards) may be damaged by magnetic fields emitted by the device when the device is overheated. Otherwise, it may cause low temperature burns, redness and skin pigmentation.</div> <div>After using the device for a long time, pay attention to the heating of the device and avoid contact with the skin for too long.</div> <div>•Do not sit on the device, or keep it direct sunlight with your skin for a long time while the device is charging or connected to the power source.</div> <div>High temperature resistance varies from person to person.</div> <div>Please pay special attention when using it by children, the elderly,Protect hearing and ears when using earplugs</div> <div>Excessive exposure to strong sounds can cause hearing loss.</div>	<div>Security Instructions</div> <div>•Contact with strong sounds while walking may distract you and cause accidents.</div> <div>Always turn down the volume before using earplugs, and use only the lowest volume required to listen to conversations or music.</div> <div>There are foreign objects on the earplugs, and you wear the earplugs for a long time, it may cause ear infections. Please keep the earplugs dry and clean.</div> <div>•In a dry environment, static electricity may accumulate in the earplugs. Avoid using this earplug in a dry environment, or touch metal objects to discharge static electricity before using the earplugs.</div> <div>Do not place equipment and accessories in or near the airbag deployment area. If the equipment is improperly placed, the airbag inflates rapidly, which can cause serious injury.</div> <div>Do not drop the device or cause collision</div>	<div>Security Instructions</div> <div>Precautions for using the device during walking or moving.</div> <div>Always pay attention to your surroundings to avoid harming yourself or others.</div> <div>Do not paint or paste paper on the equipment</div> <div>If you are allergic to the paint or metal parts of the device, it may cause itching, eczema or swelling of the skin. When the above situation occurs, please stop using the device and consult a doctor.</div> <div>Install the device cautiously</div> <div>The device should be placed in a safe location, such as the deployment area. If the equipment is improperly placed, the airbag inflates rapidly, which can cause serious injury.</div> <div>Do not drop the device or cause collision</div>	<div>Security Instructions</div> <div>•The device may be damaged or malfunction.</div> <div>•If the device is bent or deformed, it may damage the equipment or cause personal injury.</div> <div>Ensure the longest service life of the battery and charger</div> <div>•If the battery is used for a long time, the battery may malfunction.</div> <div>•The equipment will discharge if left unused for a long time, and must be recharged before use.</div> <div>When the equipment is not in use, disconnect the power supply.</div> <div>•The battery can only be used for the designated purpose.</div> <div>Follow all the instructions in this manual to ensure the longest service life of the device and battery. The manufacturer will not provide warranty for damage or poor performance caused</div>	<div>Security Instructions</div> <div>by failure to follow the warnings and instructions.</div> <div>The equipment may wear out over time. Although some parts are guaranteed during the validity period, damage or deformation caused by the use of unapproved accessories is not covered by the warranty.</div> <div>Do not disassemble, modify or repair the equipment</div> <div>Any changes or modifications to the equipment will cause the manufacturer to not guarantee the equipment. For repairing, please contact your local MOONDRÖP authorized dealer.</div> <div>Do not disassemble or piece the equipment, as this may cause an explosion or fire.</div> <div>Do not disassemble or reuse the battery.</div> <div>When cleaning the equipment, please follow the following advice</div>	<div>Security Instructions</div> <div>Use a soft and dry cloth to wipe the device, use a brush or other tools to remove the wax/oil or dirt on the earplugs.</div> <div>Clean the battery contacts with a dry cloth.</div> <div>Do not use chemicals or cleaning agents. Otherwise, the surface of the equipment may be discolored or corroded, and it may also cause electric shock or fire.</div> <div>Prevent the equipment from contact with dust, sweat, ink, oil, and chemical products (such as cosmetics, antibacterial sprays, hand sanitizers, detergents and insecticides).Chemicals, the internal and external parts of the device may be damaged, or the performance may deteriorate. If the device comes into contact with any of the above-mentioned substances, please wipe it with a soft, lint-free cloth.</div> <div>Do not use the device for any purpose other than the</div>	<div>Security Instructions</div> <div>designated purpose</div> <div>The device may malfunction.</div> <div>Avoid disturbing others when using the device in public places</div> <div>Only qualified personnel are allowed to repair the device</div> <div>If the equipment is repaired by unqualified personnel, the manufacturer is not responsible for any problems provided through this service.</div> <div>Do not distribute copyrighted content</div> <div>Do not distribute copyrighted material without the permission of the content owner. This behavior violates copyright law. The manufacturer is not responsible for any legal problems caused by any illegal actions by users against copyrighted content.</div>	<div>Security Instructions</div> <div>Disclaimer</div> <div>All content and services available through this device belong to the copyright owner. All rights are reserved. The content, trademarks and other intellectual property laws. Such content and services are only for personal non-commercial use. Without the permission of the content owner or service provider, you may not be able to use any content or service.</div> <div>Explicit permission of the application content or service provider, you may be able to modify,copy,republish, update, print, transmit, translate, or repost any content or service displayed through this device. sell, create new derivative works, develop or distribute in any way.</div> <div>Third-party content and services are provided. For any purpose, MOONDRÖP Company does not provide any express</div>	<div>Security Instructions</div> <div>or implied guarantees for the content or services provided. MOONDRÖP Co. expressly declares that it does not assume any implicit guarantees, or through regulations, common law, or other means (including but not limited to trademarks and other intellectual property laws. Such content and services are only for personal non-commercial use. Without the permission of the content owner or service provider, you may not be able to use any content or service.</div> <div>Explicit permission of the application content or service provider, you may be able to modify,copy,republish, update, print, transmit, translate, or repost any content or service displayed through this device. sell, create new derivative works, develop or distribute in any way.</div> <div>Third-party content and services are provided. For any purpose, MOONDRÖP Co. does not guarantee for and use copyright, liability,</div>