

SR-SWM_WirelessMouse

User Manual - Black and White Printing

Placed behind the product

Back

Front

2 in

2 in

2.75 in

WARNING

This device is not a toy and should be kept away from children. The product must not be dropped or subjected to impact. Do not use the device in humid or in extremely hot / cold environments. Do not use chemicals or abrasive detergents to clean the product. Please return for repairs if the product is defective. The warranty is invalid if the product has metal rust, water damage, or other natural oxidation.

WARRANTY

This product has a 1 year warranty against defects in manufacturing under regular consumer use. For instructions about how to obtain warranty service for your product, please contact Customer Service: info@primebrands-group.com.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



©2023 Prime Brands Group. All rights reserved. All trade names are registered trademarks of the respective manufacturers listed. Made in China.
Prime Brands Group • Brooklyn, NY 11232 • www.soarspaces.com

SOAR.



Wireless mouse & mouse pad combo

User Manual

Inside


Inside

2.75 in

Thank you for purchasing the SOAR Wireless Mouse. This manual will familiarize you with the product and its use. Please retain for warranty information and reference. Included: Wireless Mouse, USB Fob, & User Manual

PRODUCT KEY

- | | |
|-----------------|------------------------|
| 1. Left Click | 5. Battery Compartment |
| 2. Right Click | 6. Wireless USB Fob |
| 3. Scroll Wheel | 7. Optical Lens |
| 4. DPI Button | |



INSTALLATION

1. Open the Battery Compartment (5) and remove the Wireless USB Fob (6).
2. Place a single AA battery into the Battery Compartment (5). AA battery not included. Replace the battery compartment cover.
3. Plug the Wireless USB Fob (6) into your computer or device.
4. The wireless mouse should begin to work automatically. If it does not, open the bluetooth menu in your device and select it to connect. Once paired successfully it will automatically connect.

OPERATION

Press the DPI button to cycle through resolutions. By changing the DPI, you can instantly adjust pointer speed for precision tasks, such as in-game targeting or photo editing. The greater the number of DPIs, the higher the mouse sensitivity, and the faster the pointer speed.

TROUBLE SHOOTING

- If the cursor doesn't move when you move the mouse...
- Check the MicroUSB receiver connection. Try inserting it into another USB port on your computer.
 - Take the battery out and reinstall it. Replace the battery with one that has a full charge.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.