

Model: MLSH8






ISED Certification No.:26807-MLSH8

FCC ID: 2AYGE-MLSH8

Manufacturer: MeLaSen Electronics Ltd.

Address:No.29 Industrial Road, Xiaolan Industrial Estate, Xiaolan Town, Zhongshan, 528415 Guangdong, P.R. China

REMOTE CONTROL OPERATING INSTRUCTIONS

1.  All ON/ OFF button.
2. Press and release the  button, the fan will turn ON and OFF accordingly.
3. Press and release the  button, the light will turn ON and OFF accordingly.
4. Press **+** to increase speed and **-** to decrease speed. You can select fan speed 1-6.
5. Press **+** to increase brightness and **-** to decrease brightness.
6. Press and release the button  will activate the Comfort Breeze mode. Alternates through speeds 1-5.
7. Press and release the  button to change the light colour from warm light to white light.
8. Press the (2H/4H/8H) buttons to automatically turn the fan off after 2, 4 or 8 hours.

Install two 1.5V battery into the remote control. To prevent damage to the remote control, remove the battery if not used for long periods of time.




WARNING: Do not short-circuit, disassemble, heat up, connect improperly, or dispose of used batteries in fire. Do not recharge or mix batteries with used or other battery types. Immediately remove used batteries.



WARNING: a) The cells shall be disposed of properly, including keeping them away from children; and b) Even used cells may cause injury.




WARNING: Chemical Burn Hazard. Keep batteries away from children. Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.





LEARNING PROCESS




NOTE: After the AC power is on, do not press any other button on the remote control before pressing the  (ON/OFF) button. Doing so will cause the procedure to fail.

Should you desire to use another remote control unit with your new fan, install one using the steps below:

- Turn the main power source off to begin the learning process.
- Return the power to the unit.
- Within 3 seconds of turning the fan's AC power ON, press and release the  button and then press and release the  button to enter the learning function. A beeping sound is emitted when pairing is complete.

INSTALLING THE REMOTE CONTROL HOLDER

- Install the remote control holder spacer onto the wall using two remote control holder screws, and then attached the remote control holder onto the spacer, ensure two parts fit together and no gaps, install the remote control holder screws.



Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.